

CDX2000 / 13.56 MHz & 400 kHz
FP5315RF



CDX2000 / 13.56 MHz & 400 kHz
Dual RF Generator
Operator's Manual



FOR SALES AND SERVICE PLEASE CALL:

PTB SALES T :: 626.334.0500
service@ptbsales.com
www.ptbsales.com

DATE SERVICED: _____

VIEW OUR INVENTORY

COMDEL

Copyright © 2006 by Comdel, Inc.

The information contained in this manual is proprietary to Comdel, Inc. and is protected by copyright and trademark laws. You may not modify, copy, reproduce, republish, post, transmit, or distribute in any way any material from this manual except as may be expressly permitted in writing by Comdel, Inc.

Comdel, Inc. • 11 Kondelin Road, Gloucester, MA 01930 • Phone: 978-282-0620 • www.comdel.com

Table of Contents

1	Safety Information	1
2	Description / Specification	4
	A. Electrical Specifications.....	4
	B. Protection Features.....	6
	C. Control Signals & Rear Panel Connections	6
	D. Mechanical Specifications.....	7
	E. Environmental Specifications	8
	F. Testing Specifications.....	8
	G. Packaging & Shipping Specifications	8
3	Unpacking and Inspection	9
4	Maintenance	9
5	Preparation for Use	9
	A. Line Requirements	9
	B. Cooling Requirements.....	9
	C. Installation Requirements	10
6	Operating Instructions	10
	A. Local Operation	10
	B. Remote Control Operation	11
7	Theory of Operation	12
	A. AC Interlock System.....	12
	B. DC Power Supply	12
	C. Oscillator Control Board.....	13
	D. Driver.....	14
	E. PA 1250S Power Amplifier.....	14
	F. LF1250 Power Amplifier	14
	G. Directional Coupler Board.....	14
	H. CDX Controller.....	15
	I. CDX Autotune Parameters	15
8	Certification	16
9	Customer Service	17

List of Figures


FP5315RX	CDX2000 Block Diagram
FA0900RX	AC Interlock assy schematic
FA0500RX	Hall Effect Current Monitor assy schematic
FA0442RX	Oscillator Control assy schematic
FA0129RX	Directional Coupler assy schematic
FA0614RX	CDX Interface assy schematic
FA0604RX	CX Microcontroller assy schematic
FA0605RX	Softkey Input Interface assy schematic
FP5315RX.dwg	Facilities Control drawing

Before installing equipment, carefully read and familiarize yourself with the entire operations manual. Observe and obey all WARNING and CAUTION notes provided.

1 Safety Information

Warning Label and Safety Marking Explanations:

The following symbols and terms may be found on an instrument or used in this manual.



The CE mark indicates compliance with all currently applicable directives and standards.



This label indicates a general warning or caution condition.



This symbol indicates the presence of high voltages in or around the unit.



This symbol indicates that the component or circuit is short circuit protected.



This symbol indicates the presence of RF energy in or around the unit.



This symbol indicates a protective earth ground connecting point.



This label indicates a presence of high voltage in or around the equipment, which may cause severe injury or death. All appropriate precautions should be observed when installing, operating or servicing this equipment.



This label indicates the presence of Radio Frequency energy in and around the equipment, which may cause burns or other injuries. All appropriate precautions should be followed when installing, operating or servicing this equipment.

The **WARNING** heading used in this manual explains dangers that might result in personal injury or death. **Always read the associated information** very carefully before performing the indicated procedure.

The **CAUTION** heading used in this manual explains hazards that could damage the unit. Such damage may invalidate the warranty.

MUST – This word is understood to indicate a mandatory condition.

HIGH VOLTAGE – Voltages greater than 50 volts DC or 25volts AC and known to cause death or serious injury if contacted.

SERVICE – Any operation of maintenance, repair, calibration or similar activity other than the normal operation of the unit.

QUALIFIED SERVICE TECHNICIAN, QUALIFIED ELECTRICIAN, QUALIFIED PERSONELL These terms indicate persons specifically trained to install, service or other wise handle electronic equipment of the character and hazard potential of this unit.

End User Labeling

The system installer should obtain and apply all appropriate safety and warning labels required by the end user's local fire department jurisdiction and Occupational Health and Safety Administration over and above those supplied by the generator manufacturer.

Read And Understand This Section Fully Before Installing or Operating This Equipment.

WARNING: This equipment must be installed, operated and serviced only by trained, qualified persons.

General Safety Requirements



- **WARNING:** Hazardous Voltages and RF voltages are present inside this unit, which may cause injury or death. To prevent electrical shock and or RF burns, never operate this equipment with the covers removed. Never operate without an appropriate cable connected between the RF output connector on the rear panel and the load.
- **CAUTION:** There are no user or operator serviceable parts inside this equipment. Refer all service to a qualified service technician.
- This equipment must be bonded to Protective Earth (safety ground) prior to operating the unit. Safety ground connection must be made at the unit's rear panel designated 1/4" - 20 threaded ground stud. The ground wire should be a #14 awg or equivalent (minimum) green/yellow lead.
- Replace fuses only with identical type and rating parts. Installation and connection of this equipment must only be performed by a qualified electrician.



- **HEAVY OBJECT CAUTION:** A heavy object caution exists for equipment weighing more that 51 lbs or 23 kg. Use lifting aids to install unit, such as chain lifts or hooks and straps, attached to the four handles at the sides and front of unit. Guide unit into final location using care to keep hands and body parts clear of unit.

CE Mark Specific Safety Requirements

- This equipment meets all applicable safety directives (as specified in prEN50178) required to qualify for the application of the CE marking.
- This equipment must be installed in accordance with the applicable requirements, or prEN50178 and EN60204-1 / IEC-204-1.
- This equipment is qualified to operate at Pollution Degree II and Insulation Category II.
- The installation of this equipment must assure that the AC power input connector (UL/CSA) is not accessible to the user/operator. Access may be gained only by a qualified service technician. AC Mains connector installation must be in accordance with local requirements.
- This unit provides appropriate separation between all interface, mains and output circuits in accordance with 5.2.18 of prEN50178.

Interlock System

- The low voltage (24 V) safety interlock circuit is designed to disable the unit in the event of an interlock fault condition. At a minimum, interlock protection is located at the removable top cover, bottom cover and RF output connector safety cover.
- End user's system should provide indication to the operator of the interlock fault condition.
- Low voltage power for the interlock circuit is supplied by a step down transformer located inside the unit. This transformer is designed to provide safe low voltage operation and provide isolation from the main AC line.

Lockout/Tagout

Prior to performing system maintenance, repair or other service operations the generator must be locked out and tagged out to prevent accidentally energizing the system.

The following steps should be performed only by a qualified service technician:

- Disconnect AC input power to the generator.
- Mount a suitable "Clamshell" type lockout device to the AC input plug such as a Hubbell # HLD2 or equivalent. Follow all manufacturers' directions for the lockout device.
- Secure the lockout device with an appropriate padlock or safety lock.
- Apply a lockout warning tag to the lock out device.

The Lockout / Tagout device should not be removed until system service is completed and it has been determined appropriate to reconnect and operate the generator.

2 Description / Specification

The CDX 2000's high frequency (HF) section provides up to 1000W of power, with optional frequencies anywhere from 2 to 60 MHz. The low frequency (LF) section can deliver 1000W, with optional fixed or variable frequencies ranging from 20 to 450 kHz. The LF section also features an optional phase locked output, which eliminates the need for matching networks in many applications.

Sharing a common cooling system and DC power source, the CDX 2000 simplifies facility requirements and reduces spare parts inventory. Each section responds to completely separate remote control commands.

The dual control board performs many functions, including: Pulse-width power control; protection circuitry; system status indicators; power metering; remote interface; and protection circuitry.

A. Electrical Specifications

Description	Specifications
AC Input Voltage:	187-229 VAC, no neutral, 3 Phase with PE ground
AC Line Frequency:	47-63 Hz
AC Input Current:	12 Amps max./Phase
Input Fusing:	20A circuit breaker
Output Characteristics: (The following specifications, unless otherwise stated, are for both 13.56 MHz and 400 kHz outputs [for full AC input voltage and frequency range])	<ul style="list-style-type: none"> • 0 to 1000 W continuous forward power at the units rear bulkhead RF connector into a 1.25 VSWR load (all phases) as reference to 50 ohms. • The unit shall be capable of simultaneously supplying 1000 W of power at 400 kHz into a 50 ohm power load and 1000 W of power at 13.56 MHz into a separate 50 ohm power load. • The 13.56 MHz output shall deliver 0 to 1000 W continuous forward power into a load which consists of a 50 ohm coaxial cable (any electrical length) feeding a matching network that is connected to a nonlinear plasma source. • The 400 kHz output shall deliver 0 to 1000 W continuous forward power into a L-C parallel resonant load which is inductively coupled to the above mentioned plasma. The 400 kHz RF feed is tapped into the inductor (of the L-C resonator) so that the input impedance with the plasma present is very close to 50 ohms at the resonance frequency. The 400 kHz output will self tune to the resonance of the L-C resonator by means of a microprocessor controlled frequency tuning algorithm. • Each output section shall have at least 50 dB of isolation from the other by means of internal DC power supply isolation and RF shielding. This shall be measured with each output loaded with a 50 ohm power load at full output power. • The actual forward RF output power is to track the command setpoint for any load conditions where the reflected power is less than: <ul style="list-style-type: none"> ○ 200 W for the 13.56 MHz output ○ 200 W for the 400 kHz output
Accuracy/Regulation:	+/- 3.0% of setpoint, from 10% to 100% max output, as measured by either the actual output power and/or the analog read back signal on Pin 3.

Linearity:	+/- 3.0% deviation from a straight line for successive requested setpoint power increment changes, from 10% to 100% max output, as measured by either the actual output power and/or the analog read back signal on Pin 3.
Short Term Stability:	+/- 1.0% for any given output power setpoint during one continuous hour of output.
Long Term Stability:	+/- 5.0% for any given output power setpoint during 3 years of continuous output.
Rise Time:	Less than 100 ms; from leading edge of enable signal to 90% of power level requested.
Zero Setpoint:	Less than 5.0 W actual output power and less than 5.0 W read back power when setpoint signal is at zero or at a negative voltage.
High Frequency 13.56 MHz Section Output Frequency and Stability:	13.56 MHz +/- 0.005%
Low Frequency 400 kHz Section Output Frequency Range and Auto Tuning:	<ul style="list-style-type: none"> The 400 kHz Section shall have an output frequency range of 380 kHz to 420 kHz. The unit shall include an auto-tune feature to self adjust frequency for the lowest VSWR over this range. The auto tune feature should operate independent of the length of coaxial cable used to interface the output to the plasma/resonant load. The auto tuning frequency sweep will be of a continuous nature or comprised of discrete frequency steps of step size no larger than 100 Hz. This should be capable of auto tuning to within 0.8 kHz of the actual resonant frequency. The auto tune circuit shall lock to the lowest VSWR within 2 seconds.
Output Filtering: (for full power into 50 ohms)	<p>13.56 MHz Output:</p> <p>Harmonic Signals: less than -40 dBc Spurious Signals: less than -50 dBc AM & FM Noise: less than -60 dBc (@ 50 kHz offset)</p> <p>400 kHz Output:</p> <p>Harmonic Signals: less than -40 dBc Spurious Signals: less than -50 dBc AM & FM Noise: less than -50 dBc (@ 20 kHz offset)</p>
RF Coupling:	Due to RF coupling in the plasma chamber the 400 kHz output section design may require a 13.56 MHz dissipation or filter circuit so that the coupled 13.56 MHz power does not disturb the 400 kHz output section in any way. Similarly, it may be necessary to also ensure that 400 kHz power does not couple into the 13.56 MHz output section and cause any disturbances.

B. Protection Features

Description	Specifications
Mismatch Protection:	Continuous operation into any impedance mismatch condition without damage or malfunction; forward power foldback shall occur within 500us if reflected power exceeds: <ul style="list-style-type: none"> • 200 W for the 13.56 MHz Output Section • 200 W for the 400 kHz Output Section
AC Line Protection:	A manually resettable circuit breaker on the rear panel opens upon overcurrent conditions.
RF Output Power Connection Interlock:	Hardwired interlock that disables the input AC power contactor upon removal of either of the RF output cables.
Safety Interlock:	Disables the input AC power contactor via either of the control I/O connection signals; open between Pins 11 & 12.
Over Temperature Fault:	Output disabled on high internal temperature.
Control Signal Protection:	Unit not to be damaged if a short circuit or up to 30 volts AC or DC is placed between any input signal, return signal, and ground.

C. Control Signals & Rear Panel Connections

Description	Specifications
Signal Input Impedance:	10K ohms, minimum
Signal Input Isolation:	1000 VAC MIN to the A/C supply line
Rear Panel Electrical Connections:	All electrical connections shall be placed at least 75mm (3") from the right and 100mm (4") from the left side of the rear panel when viewed from the rear for clearance purposes.
Input Power Connection:	Line cord to be 4 mm ² (12 AWG) conductor (three phase & ground); line cord jacket material to be type "STO" gray; line cord to be crimped to NEMA L15-20P style plug; line cord length to be 1.37 m +/- .15 m (4.5 ft. +/- 6.0") as measured from the rear panel exterior to the strain relief end of plug. Reference MARINCO part number 2015P AM3. MARINCO: One Digital Dr., Novato, CA 94949; Phone (415) 883-3347
Output Power Connectors:	Two Type "N" female coaxial bulkhead connectors.
Control I/O Connector:	Two 15 pin sub miniature "D" type (female) receptacles. I/O connector #1 for the 13.56 MHz section and I/O connector #2 for the 400 kHz section.
Chassis Ground:	Stud with two kept nuts and star washers located on the right side of the rear panel as viewed from the rear of the unit; lower right hand location is preferred. "PE Ground symbol" marking to be located visible next to stud.

Control signals and pinout descriptions for both 13.56 MHz and 400 kHz:

Signal Pin	Name	Type	Description
2	Ref Power Output	AO	0 to +10 VDC = 0 to 200 W linear
3	Forward Power Output	AO	0 to +10 VDC = 0 to 1000 W linear
4	Power Enable	DI	Enables RF output power with an external contact closure to Pin 9. (24 Volts; 0.5 amps MAX. SWITCHING)
5	Remote Setpoint Input	AI	0 to +10 VDC = 0 to 1000 W linear
6	Remote Common	AGND	Return for Pins 2, 3, 5
7	RF Power On Output	DO	+5 VDC = RF ON; OV = RF OFF
8	Over-temperature Output	DO	Pin gets pulled to ground via 1N4001 diode.
9	Power Enable Common	DGND	Return for Pin 4, 7, 8
11	Safety Interlock	INTLK	Interlock is made with external contact closure to Pin 12 which enables the AC input power contactor. (24 VDC; 0.5 amps MAX SWITCHING.) Maximum external loop resistance: 8 ohms.
12	Interlock Loop Return	INTLK	Return for Pin 11

NOTE: all unlisted pins are not connected.

D. Mechanical Specifications

Description	Specifications
Size:	432 mm x 173 mm x 483 mm (17"W x 6.8"H x 19"D) maximum chassis dimension
Weight:	61.4 kg (135 lb.) maximum
Mounting:	Standard 19" EIA rack mounting adapters with 7" front panel. Front panel to be attached flush with bottom of power supply chassis.
Color and Finish:	Front panel to be the only surface to be painted gray with contrasting blue alpha-numeric reference designators. All other surfaces have a coated finish such as gold zinc chromate, gold alodyne, or equivalent.
Water Connections:	1/4" NPT female, one inlet and one outlet for water cooling of amplifier sections. The water connections shall be placed at least 75 mm (3") from the right and 100 mm (4") from the left side of the rear panel when viewed from the rear for clearance purposed.
Front Panel and Indicators and Actuators:	<ul style="list-style-type: none"> All front panel indicators will be displayed on a 20 X 2 character alpha-numeric display. All settings (in local control mode) will be made from a single rotary encoder or three soft key actuators.
Handles:	<p><i>Front Panel:</i> Two handles (left & right) to be mounted on the front panel exterior, evenly spaced on center.</p> <p><i>Side Panels:</i> One handle to be mounted on the left and right side panel exteriors, evenly spaced on center, if weight exceeds 22.73 kg (50 lb.)</p>
Warning Labels:	<ul style="list-style-type: none"> Safety Labels for hazardous voltages, Heavy Object, and Caution for lifting by water fittings are to be provided on operator visible areas of the generator. IEC standard symbols in user visible areas for start, stop, enable and cautionary conditions, PE ground, high temperatures and RF energy present. Special marking available at customer's specifications

E. Environmental Specifications

Operating Temperature & Humidity	
Operating range:	+10 to +40° C (50 to 104° F) ambient, 5-85% R.H. (non-condensing, no formation of ice), 86-106 kPa. Temperature, humidity and air pressure operating range class 3K3 per prEN50178.
Cooling Inlet Air:	+5 to +35° C max (41 to 95° F)
Inlet Water Cooling Requirements:	6 l/m (1.6 GPM) @ 414 kPa (60 psi) max, +5° to max 25° C (40° F to 77° F)
Coolant type:	Water
Storage and Transportation	
Storage temperature/humidity/air pressure:	-25 to +70° C (class 1k4 per prEN50178), 5 - 95% humidity (non-condensing, no formation of ice, class 1k3), 70-106 kPa (class 1k4).
Transport temperature/humidity/air pressure:	-25 to +70° C, 5 - 95% humidity, 70-106 kPa (class 2k3).

This equipment has been designed to be compliant with FCC Part 18 emission standards for EMI/RFI radiation. Radiated emissions shall also not exceed maximum levels permitted by ANSI C95.1-1982 standards on safety levels with respect to human exposure to RF and electromagnetic fields from 300KHz to 100GHz.

F. Testing Specifications

Production Acceptance Test: Each unit will be required to "pass" production acceptance testing and a "Final Test Report" will be generated to document results.

Production Acceptance Testing process shall include as a minimum: Complete Parametric/Functional Tests covering: line regulation, calibration, linearity, burn-in, over-temp test, open circuit test, MAX power test, harmonic distortion, AC ripple, and remote interface tests. Data sheet for each generator to be shipped with unit.

G. Packaging & Shipping Specifications

1. Accessories Supplied
 - Final test results
 - Operating manual
2. Shipping

NOTE: If there is a conflict between this document and customer Purchase Order then the latter supersedes.

NOTE FOR REPAIRS: Unless repairs have accessories included with them and have them listed on the Return Material Authorization (RMA) Tag, returned materials will not have to fulfill procedural requirements for accessories.

3 Unpacking and Inspection

1. Carefully unpack the unit and inspect for any obvious signs of physical damage that might have occurred during shipment.
2. Check the outside of the unit for missing or loose mounting screws or broken parts.
3. If there is shipping damage or the unit fails to operate properly upon receipt, report damage to the carrier immediately and notify Comdel factory within 30 days of receipt of unit. Failing to report any damage within this time period is the same as acknowledging that the unit was received undamaged.
4. If returning the product for repair you must:
 - Return the unit in the original, or equivalent, shipping container
 - Receive a Return Materials Authorization (RMA) number from the factory prior to the return of the product to Comdel for repair
 - Place RMA numbers clearly on the shipping container or on the packing slip

CAUTION: Breaking the seal or removing the warranty decal from this unit will void the warranty. If internal damage is suspected, contact factory for assistance.

4 Maintenance

The CDX2000 is designed to operate unattended for long periods of time. Should periodic maintenance or service be required, it should only be performed by qualified service persons. Contact the factory for maintenance or service recommendations.

5 Preparation for Use

A. Line Requirements

The CDX2000 is designed to operate from a 208 VAC, three phase line. The system will still function within specifications when the line voltage fluctuates between 187 volts and 229 volts. Voltages over the recommended 208 VAC, however, reduce the safe performance margins designed into the system and should be avoided. The system draws a maximum of 12 Amps per phase when used to drive a load of 50 ohms. Under conditions of mismatch, the amplifier could draw slightly more current.

Nominal Input: 208 VAC, 3 Phase
 50/60 Hz
 20 Amps

B. Cooling Requirements

The ambient air temperature should not exceed 40° C. There should be enough room over the top of the amplifier and along the sides to permit an unobstructed airflow through the unit. Water temperature should not exceed 25° C, and should not fall below a temperature where excess condensation could develop within the unit. Water volume should be at least 6 l/m (1.6 GPM) and pressure kept below 414 kPa (60 PSI).

C. Installation Requirements

1. This equipment must be installed in accordance with the applicable requirements of prEN50178 and EN60204-1 / IEC-204-1.
2. This equipment is qualified to operate at pollution degree II and installation category II.
3. This equipment is intended to be powered from a 208 VAC, 3 Phase source, no neutral connection used. For use at other voltages, a safety isolation transformer must be used to power this equipment in accordance with the requirements of EN60742 / IEC-742.
4. The installation of this equipment must assure that the AC power connector, (UL/CSA) and line cord is not accessible to the user/operator. Access may be gained only by a qualified service technician. AC Mains connector installation to be in accordance with local requirements.
5. The unit provides appropriate protective separation between all interface, mains and output circuits in accordance with section 5.2.18 of prEN50178.
6. Connect a 50 ohm load to the RF output of the amplifier.
NOTE: Load and coaxial cable should have a minimum 1000 watt power handling capacity.
7. With circuit breaker "OFF" connect the power line to the unit.

CAUTION: There are no user serviceable parts inside this equipment. Refer all service to a qualified service technician.

6 Operating Instructions

The CDX2000 may be operated either locally at the front panel or remotely through the two 15 pin subminiature D connector (P1 and P2) on the rear panel.

A. Local Operation

NOTE: AC interlock Pins 11-12 must be connected to power up the unit and RF ENABLE Pins 4-9 must be connected for the unit to be operated. These jumps must be made on both I/O connectors.

1. Check to see that there is clearance around the unit for proper air flow and that a proper RF load is connected to each RF output connector at rear of unit.
2. Connect unit to 208VAC nominal, three phase and turn on main power breaker at rear of unit.
3. The CDX2000 should power up automatically (autostart enabled) when AC power is applied and the rear panel circuit breaker is in the 'ON' position. If the LED at red pushbutton (AC OFF) marked 'O' is on solid either the AC power was shut off via the AC OFF button or the autostart feature is not enabled. The autostart feature is enabled via a jumper (P8) on the interface assembly (FA0614RX) mounted behind the front panel display. If the AC OFF LED is off, then check AC line power. If LED is flashing then check RF output connector interlock switch, top cover interlock switch, or interlock loop, Pins 11 and 12 of rear panel connectors P1 and P2.
4. Push AC ON green pushbutton marked 'I'. The AC ON LED should be illuminated after the mains contactor closes.
5. The front panel display should show the model/frequency of the unit and the software version number for the first two seconds. The front panel display should show 'RM' for remote control. A double-push (pressing the button twice within one second) of the mode button (>>) on the front panel will switch the generator to local control. To switch back to remote operation double push the mode button (>>) again.
6. In remote mode the display shows the forward and reflected power of the HF side on top and the forward and reflected power of the LF side on the bottom. The frequency of the LF side is displayed in the lower left corner. In remote mode the LF generator is always in auto tune mode. When the

output of one side is enabled the letter H (HF) or L (LF) will blink and the green LED on the RF ON button will illuminate.

7. In local mode the display will show which RF output is currently controlled from the front panel in the upper left corner. The default is "HF" for the 13.56 MHz output. To switch to the "LF" 400 kHz output press the mode button (>>) once. The forward power, reflected power and setpoint of the output under control are displayed. The setpoint is adjusted by turning the encoder. The output frequency of the LF side is displayed above the setpoint. In the LF mode pressing the select button (>) will switch the generator to manual frequency control. The display will change from AFC (auto) to MFC (manual) and turning the encoder will now adjust the frequency of the LF output. Pressing the select button (>) again will change the LF output back to auto tune.
8. Enable RF by pushing the blue RF button on the left side of the front panel. The RF button LED should illuminate, the display will flash 'RF', and readings of forward and reflected power should appear. If the display shows 'CHECK RF INTERLOCK', this means that the RF enable Pins 4 and 9 of the appropriate rear panel connector are not connected.
9. RF is disabled by pushing the RF button again, by removing RF interlock by disconnecting Pin 4 and 9 of the appropriate rear panel connector, or by interrupting the AC mains via the AC interlock loop, the stop softkey, or the circuit breaker located on the rear panel.
10. The CDX2000 regulates forward power based upon the setpoint selected by the large data encoder knob on the front panel.
11. An overtemp condition due to improper clearance around the unit or high ambient temperature will automatically disable both RF outputs on the CDX2000. The front panel display will show 'OVERTEMP'. RF will not be able to be turned on until proper coolant flow/temperature is established.

B. Remote Control Operation

- 1-4. Refer to Control pinout and signal table for the electrical interface specifications. For remote control operation follow the first four procedures for local control as listed above.
5. Remote operation is the power-up default mode. If the current mode of operation is local, then double-push the mode button (>>) until the display shows 'RM' in the upper left corner OR restart the unit by turning AC off then back on.
6. Either RF output is enabled by a contact closure between RF ENABLE Pins 4 and 9 of the appropriate rear panel connector. The RF button should illuminate, the display flash 'H', 'F', or both, and readings of forward and reflected power should appear.
7. The voltage on Pin 5(+) and 6(-) of the P1 and P2 connectors will determine the output power level of each of the generator outputs. A voltage of 0 to 10 volts DC across Pins 5 and 6 (chassis ground) will linearly correspond to an RF output of 0 to 1000 watts.
8. Reflected and forward power can be monitored remotely through Pins 2(+), 6(-) and 3(+), 6(-) respectively on each connector. Both of these balanced analog outputs are 0 to 10 VDC linearly corresponding to 0 to 1000 watts of forward or reflected power.
9. An overtemp condition as stated in #11 above in local will also result in the 'closure' of the OVERTEMP DIGITAL OUTPUT, Pins 8(+) and 9(-) (chassis ground) of both rear panel I/O connectors.
10. When RF is present at either RF output connector, the POWER ON DIGITAL OUTPUT, Pin 7 of the appropriate rear panel connector will be at approximately 5V.

7 Theory of Operation

The CDX2000 is a dual frequency power amplifier for use in OEM applications. The power sources consist of an AC Interlock assembly, DC power supply, a 1000W 13.56 MHz power amplifier and a 1000W 350-450 kHz power amplifier, and associated control systems and monitoring circuits.

13.56 MHz Amplifier

The radio frequency signal is generated locally in the Oscillator Control Module. From this module the signal goes to the driver. The driver further amplifies the signal to approx. 40 Watts to drive the power amplifier. From the PA the signal is fed through a low-pass filter to remove harmonic content. Forward and Reflected control signals are obtained from the output signal as it passes through the power monitor board to the output RF connector. The front panel CDX Controller monitors the user input from either the front panel or rear connector, and monitors the control signals from the RF output power monitor, PA current monitor, and PA overtemp switch. Refer to Figure FP5315RX, CDX2000 BLOCK DIAGRAM, to see how the individual modules are connected together.

400 kHz Amplifier

The radio frequency signal is generated locally on the front panel CDX controller. From this assembly, the signal goes to LF1250 power amplifier (PA). The output of this power amplifier is matched to 50 ohms through a 6 pole low-pass filter. Control signals are obtained from the output signal as it passes through the power monitor board to the RF output connector. The front panel CDX Controller monitors the user input from either the front panel or rear connector, and monitors the control signals from the RF output power monitor, PA voltage sensors, PA current monitor, and PA overtemp switch. Refer to Figure FP5315RX, CDX2000 BLOCK DIAGRAM, to see how the individual modules are connected together.

The LF1250 amplifier's frequency can be manually adjusted between 380-420 kHz from the front panel (local mode only) or the amplifier can Autotune to minimize reflected power. The Autotune algorithm is carried out in the generator's firmware and is optimized to tune quickly in a plasma load. There are some adjustable parameters that can be set via DIP switches on the CX microcontroller assembly located behind the front panel. Adjustment of these switches should not normally be necessary. A description of the switch settings is located under CDX Autotune Parameters at the end of this section.

A. AC Interlock System



WARNING: Never attempt to operate this equipment with any of the interlocks bypassed.

The AC mains to the mains power transformer is switched via relay K1, controlled by the AC INTERLOCK PCB (Figure FA0900RX) mounted on the front panel behind the ON/OFF softkeys. AC power to this interlock system is supplied by 24VAC transformer, which is energized when circuit breaker CB1 on the back panel is thrown.

The AC INTERLOCK PCB supplies the logic to the AC mains control contactor to start and stop the CDX2000 via the front panel softkeys. The PCB's start/stop circuitry is composed of relay logic for safety. The active circuitry (U1A) causes the OFF softkey lamp to flash if the interlock loop is broken.

The interlock 'loop' for the CDX2000 includes the rear panel I/O 15 pin 'D' connector, the top cover, and the RF output connector cover.

B. DC Power Supply

The DC supply consists of a three-phase transformer, full-wave, bridge rectifier and a low-pass filter for the main power voltages. There are three single-phase bridge rectifiers and filters feeding the positive 15 volt, negative 15 volt, and positive 5 volt regulators. A negative 5 volt supply is generated from the regulated negative 15 volt supply. These voltages are used in the control circuitry.

The outputs of this stage are:

1	44 VDC	Unloaded
	37 VDC	100 amps (2000W RF output)
1	+15 VDC Regulated	500 mA max.
1	-15 VDC Regulated	250 mA max.
1	-5 VDC Regulated	250 mA max
1	+5VDC Regulated	1A max

The high current required by the RF power amplifiers (PAs) is monitored by the HALL EFFECT CURRENT MONITOR PCB (Figure FA0500RX) mounted on the 40V DC filter capacitors. This PCB uses a Hall Effect device to monitor the DC current feeding each of the RF power amplifiers.

C. Oscillator Control Board (OCB)

The oscillator control board (Figure FA0442RX) has six parts, oscillator clock, three stages of gain, circuitry for output power control and monitoring circuitry. The oscillator clock is a TTL compatible output device that determines the frequency of operation. This square signal is amplified by three tuned stages of gain, producing a relatively clean sinusoidal 1 watt output. The DC voltage that powers the last gain stage is adjustable through control transistor Q5 to control the RF output level of the OCB.

The gain control circuitry smoothes output control and stabilizes output power against line and load variations and limits output power during high VSWR conditions. Control is achieved through the LM 356 operational amplifier, IC1. This op-amp compares the forward power signal (from the power monitor board) to that of the DC reference level applied to the non-inverting input. The reference level is set either from the front panel potentiometer or from Pin 5 of the J1 connector.

The LM 356 drives the gain control transistor, Q5, until enough signal from the forward power detector in the directional coupler is applied to the inverting input to the op-amp. When the inverting signal equals the reference voltage on the non-inverting input the drive level holds constant.

The non-inverting input is also the point to which some of the protection circuits connect. The CDX controller pulls this point down when load conditions bring the amplifiers near their over-voltage, or over-current limits. This limits the drive to the amplifiers until the match between the generator and the load is corrected.

The reflected power limiter performs in the same way when the signal from the reflected power detector in the directional coupler reaches a pre-set limit. The Q6 transistor does the pull-down function until SWR conditions are within safe limits. The OCB also includes linearizing circuitry allowing both forward and reflected analog power level signals to appear at connector J1 as linear representations of the incident and reflected RF output power. Two squaring ICs U2 and U4 are used to condition the square law signals from the directional couplers.

Typical Specifications (OCB)

Output load impedance	50 ohms
Output RF power level	1 watt (max)
Input power Pin 10	+15 VDC at 170 mA max
Pin 8	-5 VDC at 24 mA max
Remote power control input impedance	
Pin 2 on J1	2 K ohm
Reflected power limit	Internally set to 100W

D. Driver

The CDX2000 driver is a two-stage Class "C" amplifier with feedback. The first transistor amplifies a 1 watt (typical) input from the OCB to about 5 watts. The circuitry between the two stages include two wideband impedance matching transformers and a loss section. The loss section provides added stability to the system and isolation between stages. The second stage of the driver sends 20 watts (max) to the driver output connector. There are no adjustments or tuning required for this module.

Typical Specifications (Driver)

Gain	15 dB
Input power	1 watts (max)
Output power	50 watts
Input impedance	50 ohms
Output impedance	50 ohms
Collector voltage at full power *	40 VDC
Current at full power *	1.4 A

* 1250 watts into 50 ohm resistive load

E. PA1250S Power Amplifier

The PA1250S uses four power transistors arranged in four pairs of push-pull Class "C" amplifiers. The input power from the driver is matched with a wideband transformer, T1. The driver input is then split into four signals and fed into four push-pull transformers, T2. Each of these transformers drives the bases of each pair of power transistors, Q1-Q8. The transistors are operated common emitter with feedback.

The collector signals are coupled by a four push-pull transformers. The output of these transformers is once again added together in a four-way hybrid combiner. There are no adjustments on the PA1250S.

Typical Specifications (PA1250S)

Gain	15 dB
Input power	20 watts
Output power	1500 watts (min)
Input impedance	50 ohms
Output impedance	50 ohms
Collector voltage *	37 VDC
Current draw *	50 ADC

* At 1250 watt system output into 50 ohm resistive load

F. LF1250 Power Amplifier

The LF1250 power amplifier in the CDX2000 is an eight device push-pull Class 'D' amplifier, with all devices mounted on a water-cooled copper heatsink. Each device (transistor) is rated to produce over 300 Watts of power, giving a total potential output power of 2500 watts per amplifier. This conservative approach gives a large margin of reliability and immunity to large load impedance fluctuations and gives the CDX2000 the ability to deliver large amounts of power into less than ideal load conditions. The output devices are FETs with paralleled gates. The gate drive consists of two FET gate drive ICs U1 & U2. Peak voltage detector diodes D9 & D10 are used by the front panel monitoring circuitry to limit peak voltages seen by the devices. The output impedance of the LF1250 amplifier is about 15 ohms.

G. Directional Coupler Board

The directional coupler board (Figure FA0129RX) is a detector which produces voltages proportional to the square of both forward and reflected power for both the 13.56 MHz and 400 kHz RF outputs. The signals from the detectors are produced from current and voltage taps off the output lines.

In the 13.56 MHz amplifier the forward and reflected signals are fed into the OCB where they are linearized. They are then fed to the CDX controller where they are reproduced to the remote interface connector and displayed on the front panel. The reflected power signal is only present when the generator is driving a load that is not purely resistive, or not 50 ohms. This signal is also used to drive the OCB VSWR shutdown circuitry.

In the 400 kHz amplifier the forward and reflected signals are linearized and output to the CDX controller where they are displayed on the front panel and buffered for the remote interface connector.

H. CDX Controller

The CDX controller is comprised of four PC boards mounted to the left side of the front panel:

1. CDX INTERFACE PCB

The function of the CDX Interface PCB (Figure FA0614RX) is to condition all of the analog and digital inputs and outputs for the CX Microcontroller. This PCB board also provides the protection control circuitry to limit forward power in cases of high PA current or high PA RF voltage. This protection function is handled by U2. The reflected power protection circuit for the LF PA is located at U1D.

2. CX MICROCONTROLLER PCB

This PCB (Figure FA0604RX), mounted under the CX INTERFACE PCB, contains a 16 bit microprocessor, memory, digital I/O, and analog I/O to control and monitor all activities of the CDX2000. If for any reason the program is terminated or gets lost, the watchdog timer U6 automatically restarts the system. U6 also monitors VCC for low voltage conditions. If VCC drops below 4.5V, the system is shut down via uP reset line, U1-71.

If the optional RS-232 serial port is utilized, U7 and associated components supplies the interface.

U14 provides the 5V or 10V reference for the A/D (U11) and D/A (U13) converters.

3. SOFTKEY INPUT INTERFACE PCB

This PCB (Figure FA0605RX) is mounted under the CX MICROCONTROLLER PCB and contains the softkey sense pads and buffer circuitry to interface all front panel user interface to the CX Microcontroller.

4. 20 x 2 CHARACTER ALPHA NUMERIC FLORESCENT DISPLAY PCB

This PCB, also mounted under the CX MICROCONTROLLER PCB, provides the display, high voltage power supply, drive circuitry, and microprocessor to interface the 20 x 2 character display to the CX Microcontroller data bus.

I. CDX Autotune Parameters

The parameter settings in the CDX2000 software V3.09 are adjustable via the dip switch settings on the microcontroller board. The settings are only recognized and adjusted during initialization. The settings are displayed for one second during the software initialization routine. The frequency tuning span is 380-420 kHz. The minimum step size is 10Hz. The following parameters can be varied, with the factory default values in BOLD type:

1. **Gain:** The gain is an arbitrary number that is multiplied by an error signal (proportional to rfl/fwd) to determine the size of the frequency step adjustment. By setting the value of dip switch positions 1&2 the gain number is varied as follows:

0	15
1	20
2	25
3	30

2. **Lock:** The lock setting determines the percent (of FWD) rise of RFL that the tuning algorithm will tolerate after passing through a null. If the RFL reaches this number the autotune will lock at the null frequency setting. Lock is adjusted by setting dipswitch positions 3&4. The Lock settings vary as follows:

0	1
1	2
2	3
3	5

3. **Band:** The band setting determines when the autotune algorithm will attempt to retune based on the rise in the RFL by percent of FWD. The band is adjusted by setting dip switch positions 5&6 and varies as follows:

0	.5
1	1
2	2
3	3

4. **Scale:** The scale setting determines whether the frequency step size is proportional to the SWR or the square root of the SWR. The scale is set by switch 7. Typically the square root setting will tune faster:

0	SQUARE ROOT
1	LINEAR

5. **Start:** The start setting determines whether the frequency starts at MIN frequency and tunes up or starts at MAX frequency and tunes down. The start is adjusted by switch 8:

0	START LOW
1	START HIGH

8 Certification

1. This unit carries the ETL safety compliance mark to UL standard UL-1012.
2. This unit is SEMI F47 voltage sag immunity tested.
3. This unit is designed and labeled in compliance with CE mark certification requirements. The manufacturer will supply a Declaration of Conformity as required.

9 Customer Service

Comdel field services, technical support, and repair services are available to all customers and for both warranty and non-warranty products. When sending equipment to the factory for service or calibration, you need a Return Material Authorization (RMA) number to ensure that we can properly track your equipment.

Technical Support

Technical support is available by phone during regular business hours at any one of our worldwide field offices or authorized agents.

Comdel Support on www.comdel.com

The Comdel website offers a complete list of sales and service offices, product troubleshooting tips through the Frequently Asked Questions (FAQ) page, an online request form for RMA numbers, and access to RF & DC product manuals.

Factory Service & RMA Information

Comdel field services, technical support, and repair services are available to all customers and for both warranty and non-warranty products. When sending equipment to the factory for service or calibration, you need a Return Material Authorization (RMA) number to ensure that we can properly track your equipment.

Obtaining an RMA Number

- To complete an online request for an RMA number log on to www.comdel.com and click on Factory Service under the Sales & Service Menu or for direct access go to <http://www.comdel.com/pages/sales/rma.php4>
- Call 978-282-0620 or 800-468-3144. If this is a machine-down situation, call the factory immediately.

Note: We will respond to all e-mail requests by the next business day.

Customer Support and Worldwide Office Contacts

For customers located within the United States, you can reach us by phone, fax, or e-mail.

Corporate Headquarters ♦ (Authorized Repair Depot)

11 Kondelin Road

Gloucester, MA 01930

Phone 800-468-3144 or 978-282-0620 (M-F 8:00 a.m. - 5:00 p.m. EST)

Fax: 978-282-4980

E-mail: info@comdel.com

Comdel US Regional Office

Comdel California, USA ♦ (Authorized Repair Depot)

Phone: 408-727-5254

Fax: 408-727-4433

For customers located outside the United States, please contact your local Comdel office or Distributor. (Consult attached directory.)

International Support

We currently provide authorized product repairs and technical support through the following U.S.A. and International Comdel locations marketed with ♦ Authorized Repair Depot (ARD). These offices have experienced technicians that can assist in arranging for product returns or on-site assistance.

The Comdel authorized repair depots stock parts and test equipment that support most Comdel products. Customers are encouraged to discuss specific service support needs with their local Comdel office to ensure prior product support preparation is arranged.

Other Comdel sales and service distributors are available to support facilitating return of Comdel products to the most appropriate service repair depot.

Comdel authorized depots offer application support, RF training, and product design assistance. All are fully supported by the product marketing and engineering team at Comdel's headquarters.

International Offices

EUROPE

Comdel United Kingdom ♦ (ARD)

Phone: +44-1256-766914 or +44-1256-766917

Fax: +44-1256-766915

Email: steve_ottaway@comdel.com

MIDDLE EAST

Israel

Odem Scientific Applications Ltd.

Phone: +972-8-9366101

Fax: +972-8-9366102

Email: ori@odemltd.com

ASIA

Comdel Seoul, Korea ♦ (ARD)

Phone: +82-2-565-4780

Fax: +82-2-564-5398

Email: eric_joo@comdel.com

Singapore/Malaysia

DAL Engineering (S) PTE, Ltd. ♦ (ARD)

Phone: +65-6-743-5538

Fax: +65-6-743-5539

Email: david_wong@comdel.com

Taiwan, ROC

FairTech Corp. ♦ (ARD)

Phone: +886-3-5723257

Fax: +886-3-5727302

Email: farcorp@ms25.hinet.net

China

Beijing Leyfond Vacuum Tech. Co., Ltd.

Phone: +86-10-82843366

Fax: +86-10-82842835

Email: fangliwu@leyfond.com

JAPAN

Comdel Branch Office Japan ♦ (ARD)

Phone: +81-47-369-9393

Fax: +47-369-3317

Email: big-sakamoto@pra.co.jp

PRA Ltd. ♦ (ARD)

Phone: +47-369-3389

Fax: +47-369-3317

Email: m.ozawa@pra.jp

Comdel Warranty

Seller fully warrants that equipment, service, software, repair or parts supplied shall conform to the description in the quotation and agrees to repair or replace F.O.B. shipping point, any parts (excepting expendable items such as semiconductors and vacuum devices), services, or repairs that fail due to defects in material or workmanship within (1) one year of start-up of equipment or (24) twenty four months after shipment, whichever occurs first, or in the case of service or repair, within (1) one year of rendering service or repair. At Buyers request, failure analysis will be provided for all in-warranty failures returned by Buyer to Comdel Gloucester. Liability of Seller under this warranty shall exist provided that: Buyer exposes the product to normal use and service; in case of shipping damage, Buyer notifies Seller within 30 days of receipt of goods; the Buyer receives a Return Materials Authorization (RMA) number from Seller prior to the return of product for repair; if upon examination of such product by Seller it is disclosed that a defect in materials and/or workmanship does exist, and the defect in the product was not caused by improper conditions, misuse, abuse or negligence; and that Sellers warranty decals have not been removed or tampered with and the equipment has not been repaired or modified by anyone other than Seller's authorized personnel. Other than those expressly stated herein, **there are no other warranties of any kind, expressed or implied, and specifically excluded, but not by way of limitation, are the implied warranties of fitness for particular purpose and merchantability.**

It is understood and agreed that Seller's liability, whether in contract, in tort, under any warranty, in negligence or otherwise shall not exceed and Buyer's remedy is limited to either (i) repair or replacement of the defective parts F.O.B. shipping points, correction of the defective service or repair, or at Seller's option (ii) return of the product and refund of the purchase or service price. Under no circumstances shall Seller be liable for special, indirect, incidental, or consequential damages. The price stated for the equipment, service, repair or parts is a consideration in limiting Seller's liability. No action, regardless of form, arising out of the transactions of this agreement may be brought by Purchaser more than one year after the cause of action has accrued. The warranty for the equipment, service, repair or parts proposed in this quotation is as stated in the above paragraphs. It is not re-stated nor does it appear in any other form.

AUTHORIZATION TO MARK

This authorizes the manufacturer to apply the ETL mark to certified products; also to the multiple listee model numbers as listed on the correlation page of the Listing Report where applicable; when made in accordance with the accompanying descriptions and drawings under the conditions set forth in the Certification Agreement herein:

Applicant: Comdel, Inc.
11 Kondelin Road
Gloucester, MA 01930

Contact: Bob Dettorre

Manufacturer: Same as Applicant

Reference Report No.: 3027022

Product Covered: CDX-2K w/DevNet/208V, CDX-2K w/DevNet/480V

Description: Dual RF Generator

Standard(s): UL 1012, Sixth Edition, 1997

This procedure, with all revisions, etc., is the property of Intertek Testing Services and is intended solely for the guidance of the listee and the representative of Intertek Testing Services, and is not transferable.

Issued by: Intertek Testing Services, 24 Groton Avenue, Cortland, NY 13045-2014 USA



Authorized by:

William T. Starr
William T. Starr
Certification Manager

Date:

July 10, 2002

Control Number:

2001247



REV	DESCRIPTION	DATE	APPROV
CONDEL INC.			
64"	MATERIAL:	TITLE : CDX-2000 ASSEMBLY	
05"		DOCUMENT #	DATE:
	FINISH:	PROJECT :	DR :
		FILE NAME : EPM31106F	CHK :