

# INSTRUCTION MANUAL

---

## MULTI-STAGE DRY VACUUM PUMP

**MODEL ESR20N**

**MODEL ESR80WN**

**MODEL ESR200WN**

**STANDARD MODEL**

**200-220V (50/60Hz)**



FOR SALES AND SERVICE PLEASE CALL:

**PTB SALES**

T :: 626.334.0500  
service@ptbsales.com  
www.ptbsales.com

DATE SERVICED: \_\_\_\_\_

***VIEW OUR INVENTORY***



**Caution:**

Please read and understand this INSTRUCTION MANUAL thoroughly before using this equipment.

Be sure to keep this INSTRUCTION MANUAL on hand for future reference

To Facility and Tool Manufactures:

Be sure to distribute this INSTRUCTION MANUAL to all end-user personnel actually operation this equipment.

※「Model 000」 in this INSTRUCTION MANUAL is our model code

**ISSUED BY PRECISION MACHINERY GROUP**

Do not reproduce or reprint any portion of this manual without permission.  
Manufacturer reserves the right to discontinue or change any specifications or designs without notice and without incurring obligations.  
Model OOO in this catalog is our model code.

All rights reserved, copyright EBARA

## Environmental Basic Policies

It is our responsibility, as people of the earth, to protect nature's irreplaceable treasures and to pass them on to future generations.

As we undertake our business activities, we will establish environmental management systems and implement ongoing improvements and reviews, while striving to promote harmony between technology and nature, prevent environmental pollution, and improve the overall results of our environmental management activities. We are aware that environmental protection and management activities are the responsibility of all managers and employees of the Corporation, and each person will demonstrate this awareness when carrying out his or her duties.

We will widely publicize these basic policies to regional societies and the general public and work to make Ebara's position on the environment clear to society in general.

---

## Safety Information

It is essential that those operating this pump should have the knowledge to identify and avoid hazardous conditions associated with the pump.

Inadequate or rash operation may cause dangerous and serious accidents.

Before installation and operation, the operator should first have a good knowledge of the pump construction, operation procedure, and its hazards.

The operator should read through this instruction manual and other documents issued by EBARA in detail.

If you have any questions on pump operation, safety, and maintenance, please do not hesitate to contact EBARA directly. Refer to Global network for contact address.

Three terms designating the level of hazard are used in this manual.

 <b>DANGER</b>	Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.
 <b>WARNING</b>	Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	Indicates an imminently hazardous situation that, if not avoided, may result in minor or moderate injury. This term may also be used as a warning for situations liable to damage equipment

## Important Prior Warnings

 <p><b>DANGER</b></p> 	<p>Keep out from under the pump when lifted. Only qualified personnel shall unload and lift the pump. Keep pump at horizontal position when lifted. Do not lift the pump without eyebolt spacer.</p>
 <p><b>WARNING</b></p>	<p>Be careful not to overturn the pump when pushing and pulling it sideways, because the pump is narrow in comparison to its height.</p>
 <p><b>WARNING</b></p> 	<p>Only a qualified electrician should perform electrical works, observing all national and local electrical regulations.</p>
 <p><b>WARNING</b></p> 	<p>Interrupt Earth Leakage Breaker (ELB) before starting on Cut and lock out power before beginning wiring and or maintenance work. Do not switch on the power supply to the pump until work is completed and pump and piping are returned to safe operating condition.</p>
 <p><b>WARNING</b></p> 	<p>Supply N2 gas to the exhaust piping when necessary to dilute the flammable or toxic gas down to a safe concentration.</p>
 <p><b>WARNING</b></p> 	<p>Purge with sufficient N2 gas before removing and cleaning the vacuum and exhaust piping. Do not let inflammable, toxic or dangerous materials disperse and guard against contact with the human body. Always work in a location with an escape route in an emergency.</p>
 <p><b>WARNING</b></p>	<p>Do not use the pump for another process without a previous overhaul. Gases or reaction products remaining in the pump will react and lead to accidents with the formation of large amounts of byproducts.</p>

 <b>WARNING</b> 	<p>Pump oil may be contaminated with process byproducts. Treat it as a hazardous waste. See Table 3.1 for oil quantities.</p>
 <b>WARNING</b> 	<p>Exhaust from pumps handling process gases should be connected to an appropriate exhaust abatement system that is equipped with discharge quality monitors to provide warnings and shut down the process gas flow if gas concentrations exceed allowable limits.</p>
 <b>WARNING</b> 	<p>Check for gas leaks after installing and maintaining the piping. Gas leaks will result in the discharge of harmful and dangerous substances and in abnormal reactions due to the ingress of air into the pump. When checking for gas leaks by pressurization, please pressurize by less than 0.05 MPa into the purge port and do check.</p>
 <b>WARNING</b>	<p>Do not alter the pump member nor change any parts without EBARA's consent or approval.</p>
 <b>WARNING</b> 	<p>The pump casing and exhaust piping become extremely hot during operation and remain hot for some time after stopping. Be sure that pump and exhaust piping do not come in contact with humans or inflammable substances. Do not remove pump enclosure panels during operation</p>
 <b>WARNING</b>	<p>Check Safety Interlock functions periodically (every 6 months) to confirm correct operation.</p>
 <b>CAUTION</b>	<p>Disposal of process by-products shall be strictly in accordance with all local and national environmental and safety regulations</p>
 <b>CAUTION</b>	<p>Disposal of Printed circuit board containing lithium battery shall be strictly in accordance with all applicable local and national environmental regulations.</p>

 <b>WARNING</b>	In designing the dry pumps, Ebara does not assume risks caused by hazardous chemical reactions resulted from simultaneous injection or mixture of multiple process gases in the pumps, and the pump is not equipped with a protection against the dangers from such pump usage. The tool suppliers and users must pay attention not to simultaneously inject or mix those gases.
--	--

 <b>WARNING</b>	Do not perform a withstand voltage test. Failure to comply could result in damage to the sensitive devices.
--	---

 <b>CAUTION</b>	Never operate the pump without pump cover for safety.
--	---

Following safety warning labels are attached to pump covers.

1. High temperature warning
2. Hazardous voltage warning
3. Hazardous materials warning
4. Electric charge mark
5. Hazardous weight danger
6. High temperature eyebolt warning

1. High temperature warning

Hot surface may burn or cause injury.


Allow the piping and casing to cool before servicing.



2. Hazardous voltage warning

Hazardous Voltage may shock, burn, or cause death.

Turn power off and lockout before servicing.




### 3. Hazardous materials warning

In case of hazardous materials are handled. Run the pump only with N<sub>2</sub> gas purge before servicing. Take adequate measures against dangerous reaction and contact with human body.




### 4. Electric charge mark



### 5. Hazardous weight danger

Heavy weight may cause severe injury or death due to overturning or falling pump. Keep out from under the lifted pump.  
 Raise all adjuster-feet fully when moving.



- 6. High temperature eyebolt warning  
Hot surface may burn or cause injury.  
Allow the eyebolt to cool before servicing.

	<b>⚠ WARNING 警告</b>
	Hot Surfaces. Will Cause burn. Do not touch eyebolts during pump running for some time after stops.
	高温部あり。火傷のおそれがあります。 ポンプ運転中及び停止後しばらくの間はアイボルト部に 触れないで下さい。 C-7110-317-0001

---

## Standard Limited Warranty

The terms of this Warranty limit the liability of EBARA CORPORATION. Please read it carefully.

### Duration

For new pumps, the Warranty period shall be one (1) year from the date of commencing operation by user or 18 months from shipment by EBARA, whichever comes first. This Warranty does not apply to service beyond these time periods.

For overhauled pumps, the warranty period shall be six (6) months from shipment by EBARA.

### Coverage

For the duration of the Warranty period, EBARA warrants this ESA pump from failure due to defects in materials or workmanship. For such failures, EBARA will, at its option, either replace or repair the pump free of charge

Such repair or replacement will not extend the duration of the warranty beyond the original period.

For repairs not covered under this Warranty, EBARA will charge the customer for parts and labor.

### Exclusions and Limitations

This Warranty does not cover the following:

1. Failure due to operating the pump in a manner or under conditions other than as described in the instruction manual.
2. Failure due to corrosion, byproducts or foreign material entering the pump.
3. Failure due to fire, flood, earthquake, Acts or God, Acts of War or other circumstances beyond EBARA's control.

Disassembly or repair of the pump by parties other than EBARA or EBARA-authorized suppliers will void this Warranty.

EBARA's liability is limited to repair or replacement of the pump under Warranty. EBARA accepts no liability for consequential damages, including injury to personnel and damage to facilities, tools or product.

EBARA makes no Warranty of merchantability, beyond statutory requirements, or of fitness for a specific purpose.

## Contents

Environmental Basic Policies .....	i
Safety Information .....	ii
Important Prior Warnings.....	iii
Standard Limited Warranty .....	ix
Contents .....	x
1. Foreword.....	1
2. Introduction .....	1
2.1 Introduction.....	1
2.2 Environmental Concerns .....	2
3. Product Description .....	3
3.1 Outline.....	3
3.1.1 Pump Module .....	3
3.1.2 N2 Gas .....	3
3.1.3 Cooling Water .....	4
3.1.4 Exhaust.....	4
3.2 Control System .....	4
3.2.1 Warning .....	4
3.2.2 Operation Status Control .....	5
3.3 Detailed Specifications.....	6
Table 3.1 Specifications.....	6
OUTLINE DRAWING MODEL ESR20N .....	7
OUTLINE DRAWING MODEL ESR80WN .....	8
OUTLINE DRAWING MODEL ESR200WN .....	9
Performance Curve MODEL ESR20N .....	10
Performance Curve MODEL ESR80WN .....	11
Performance Curve MODEL ESR200WN .....	12
4. Installation .....	14
4.1 Location .....	14
4.2 Piping.....	16
4.2.1 Vacuum and Exhaust Piping.....	16
4.2.2 Cooling Water Piping.....	17
4.2.3 N2 Gas Piping .....	18
4.2.4 Ventilation Duct .....	19
4.3 Electrical Wiring.....	20
4.3.1 Power Supply Wiring .....	20
4.3.2 Control Signal Wiring .....	21

---

5. Power Supply for the Options .....	26
6. LCD Controller .....	27
6.1 LCD Outline .....	27
6.2 LCD Indication.....	28
6.3 Setting the operational mode.....	32
6.3.1 Setting the pump operation control mode.....	34
6.3.2 Setting the DIP switch .....	34
6.3.3 Setting the pump running mode.....	35
6.3.4 Setting the normal rotational speed.....	35
6.3.6 Setting the WARNING value for the back pressure (option) ...	38
6.4 Dip Switch.....	39
6.5 DIP Switch setting display .....	44
6.6 Starting/stopping the pump with the LCD controller .....	46
7. Operation .....	47
7.1 Before Starting .....	47
7.2 START/STOP .....	50
7.2.1 LOCAL (Pump Side) Start/Stop .....	51
7.2.2 REMOTE Start/Stop .....	52
7.2.3 COMMUNICATION Start/Stop.....	52
8. Maintenance and Inspection .....	54
8.1 Internal energies .....	54
8.1.1 Power source .....	54
8.1.2 Cooling water .....	54
8.1.3 Nitrogen gas.....	54
8.2 Routine Inspection.....	54
8.3 Vacuum and Exhaust Piping.....	56
8.4 Lubricant Oil.....	57
8.5 Spare (Maintenance) Parts List.....	62
8.6 List of wastes during maintenance .....	63
8.7 Overhaul .....	64
9. Disconnection and Transportation .....	65
10. Troubleshooting.....	67
10.1 Troubleshooting (1) Basic trouble .....	67
10.2 Troubleshooting (2) WARNING .....	69
10.3 Troubleshooting (3) ALARM.....	71
10.4 Troubleshooting (4) Option .....	74

## 1. Foreword

We appreciate that you have selected an EBARA MODEL ESR Series dry vacuum pump. This pump has been manufactured with much care and attention so that it can be operated safely and satisfactorily.

Incorrect operation will result in lack of performance and cause accidents and injuries to personnel.

**[ NOTE ]** This instruction manual contains all necessary information on operation and maintenance of the pump.

Be sure to operate the pump correctly in accordance with these instructions to ensure a long service life.

Keep this instruction manual in a suitable place for immediate reference whenever needed.

## 2. Introduction

### 2.1 Introduction

Check the following items on receipt of the pump package.

(1) Check that the nameplate affixed to the outer cover of the pump to confirm that the pump supplied agrees with your order.

Check the accessories against the packing list and the previously submitted drawings and documents to confirm that the all ordered accessories have been supplied.

(2) Check whether damage has occurred or screws/bolts have worked themselves loose in transit.

 <p><b>CAUTION</b></p>	<p>Notify EBARA without delay when damage is discovered or when components are missing. Do not use when a leak is present as this will result in accident.</p>
---	--

(3) Store the pump in a dry and clean place if it is not installed at once after delivery.

Temperature : 5-40°C

Humidity : 80% or less

(4) Do not stack the pump. Pump must be placed in an upright position.

## 2.2 Environmental Concerns

Handling or operating the unit other than specified may induce adverse impacts on the environment. Follow the descriptions below to handle, operate, and maintain the unit.

- (1) Ask an authorized waste-disposal company to dispose packing materials from uncrating according to laws and ordinances applicable to the waste.
- (2) Failure to do the unit maintenance (including overhaul) may trigger accidents causing injury or death, unit troubles, or environmental pollution. Plan the maintenance and perform it periodically to operate the unit efficiently.
- (3) To dispose the unit, follow effective laws and ordinances applicable in the area where the unit is installed.
- (4) To dispose the lubricant oil and chemicals, follow effective laws and ordinances applicable in the area where the unit is installed.

 <b>WARNING</b>	If the pump becomes damaged during shipment or if parts are missing, immediately contact EBARA. If a leaking or damaged product is used, an accident resulting in injury or death could occur or the product could become further damaged. Even if leakage occurs, take measures to ensure they will not be directly discharged from the site, as such leakage also wastes resources.
--	---

 <b>CAUTION</b>	If the product is not to be immediately installed, store it in a clean, dry location.
--	---

### 3. Product Description

#### 3.1 Outline

The MODEL ESR series dry vacuum pump has a compact design and includes various sensors and controls to enhance reliability and operation.

##### 3.1.1 Pump Module

The pump is a Roots type vacuum pump which rotates a pair of non-contact multi-stage rotors synchronized by timing gears. In the unit, a Booster Pump (BP) and the Main Pump (MP) are connected in series for ventilation.

The timing gears and bearings are enclosed in a compartment which is independent of the casing. For lubrication Perfluoro-Polyether (PFPE) oil and grease are used.

The pumps of this series are factory filled with lubrication oil. Use only the recommended lubrication oil grades shown in specification Table 3.1 for replenishing or replacing.

##### 3.1.2 N2 Gas

N2 gas is supplied to seal the shaft section. This protects the penetration to bearing section, such as corrosive gas (MODEL ESR20N can be set a seal N2 to 0 for uses such as L/L process which does not use corrosive gas).

To reduce pump corrosion due to process gas or accumulation of reaction by-products, N2 gas is supplied to each pump component as dilution purge gas.

N2 gas can be saved by stopping the dilution N2 with a selector valve, when process does not produce corrosion and reaction by-products.

The correct amount of N2 gas is supplied for those two types of purge operation, by adjusting the regulation pressure to the specified value.

### 3.1.3 Cooling Water

Because the pump compresses gas from a vacuum to atmospheric pressure, compression heat is generated. Therefore cool the motor with cooling water.

The cooling water connector takes the form of a coupler for easy connection and disconnection.

### 3.1.4 Exhaust

A check valve is provided as a standard accessory to prevent reverse flow of gas from the exhaust through the pump to the vacuum chamber when pump is stopped.

## 3.2 Control System

MODEL ESR series dry vacuum pumps have a built-in measuring unit consisting of an Earth Leakage Breaker (ELB), an electro-magnetic switch and a control circuit.

To improve reliability and safety, the condition of each utility and pump section is monitored by a sensor.

During pump operation all operating conditions are monitored, including power supply, cooling water flow, N<sub>2</sub> gas flow, casing and motor coil temperature, motor speed, and electric power for motor.

Continuous operation is possible when there is a momentarily power failure of 1 sec or less.

### 3.2.1 Warning

To assure the reliability of the pump as a vacuum exhaust system, the pump protection system generates two levels of alarm: WARNING and ALARM.

A WARNING signal is generated when pump operation exceeds the normal range. It therefore only draws attention that the normal operating values are not adhered to but does not signify that danger is imminent. The pump will continue to operate in this condition.

An ALARM signal output is generated and the pump will stop automatically when the upper mechanical safety limit is reached during pump operation.

When an ALARM output is suddenly generated, while the plant unit is operational, a WARNING signal will be generated to ensure that the plant operation is not discontinued. This enables the operator to check the pump after the equivalent of one cycle has been completed.

Be sure to contact EBARA Corporation for details on checking the WARNING and ALARM setting conditions.

- Note that the warning indications of the MODEL ESR series are different from the conventional ones.

	Conventional	MODEL ESR series
Alarm 1 (Pump operation continued)	ALARM	WARNING
Alarm 2 (Pump stop)	TRIP	ALARM

### 3.2.2 Operation Status Control

The sensor data are displayed on the LCD display provided on the controller to facilitate operation status control and daily inspection.

All WARNING and ALARM signals are displayed on the LCD display. For remote operation and monitoring, the signals are available as individual and group outputs.

### 3.3 Detailed Specifications

The following tables and figures should be consulted for pump specification, dimension and performance details.



**Table 3.1 Specifications**

Model		MODEL ESR20N	MODEL ESR80WN	MODEL ESR200WN
Pumping Speed		1300 - 2000 L/min	4000 - 8500 L/min	10000 - 20000 L/min
Ultimate Pressure		2.0 Pa (2000 L/min) 2.7 Pa (1300 L/min)	0.2 Pa	0.13 Pa
Connection	Gas Inlet	NW40	NW50	NW100
	Gas Outlet	NW40	NW40	NW40
Approx. Power at Ultimate Pressure (Max. Power)		0.7 kW (2.5 kW)	1.0 kW (4.5 kW)	1.1 kW (5.0 kW)
Utility	Cooling Water	Connection Rc3/8 (Coupler)		
		Pressure [Gauge Press.] Differential Press.: Min. 0.1 MPa Supply: Max. 0.4 MPa		
		Flow Rate 2 - 8 L/min		
		Temperature Max. 30°C		
	N2 Gas	Connection 1/4" Tube Fitting (Same as SWAGELOK)		
		Pressure [Gauge Press.] Supply: 0.1 - 0.7 MPa [Setting: 0.04 - 0.07 MPa]		
		Approx. Flow Rate [N2-0 Mode]	19 - 22 Pa m <sup>3</sup> /s [0 Pa m <sup>3</sup> /s]	19 - 22 Pa m <sup>3</sup> /s [3.4 Pa m <sup>3</sup> /s]
	Duct Ventilation *	Connection d 50 mm x L 50 mm		
		Pressure -196 Pa		
		Approx. Flow Rate 0.5 m <sup>3</sup> /min		
Lubrication Oil	Brand BARRIERTA J100ES (NOK)			
	Quantity	50 cc	300 cc	300 cc
Approx. Weight		90 kg	180 kg	250 kg
Power Supply	Phase/Volt/Freq.	3 Phase, 200-220V , 50 / 60Hz		
	Power Capacity	4.0 kVA	7.0 kVA	8.0 kVA
	Connection	Japan Aviation Electronics Industry		
		JL04V-2E20-4PE-B	JL04HV-2E22-22PE-B	
Control Signal		D-sub 15 Pin + D-sub 25 Pin		
Communication		RS-232C D-sub 9 Pin x 2		
ELB Rating		15 A	30 A	

[Note] The ambient temperature of the pump installation place shall be 30 degrees of centigrade of lower.

REVOLUTIONS		DATE	BY
No.	DESCRIPTION		MP.
1	CHANGE THE N2 VALVE POSITION.	07/05/15	Y. H. T. S.


**METRIC**



EBARA SERIAL NO.		CUSTOMER	
MODEL	ESR20N	SET POINT USER	
DESIGNED BY	K. TAMAKI	DATE	
DRAWN BY	T. SUGIURA	TYPE	W8 - 0533592
CHECKED BY		TITLE	VACUUM PUMP OUTLINE DRAWING
DATE		SCALE	1:1
BY		REV.	1

EBARA SERIAL NO.		CUSTOMER	
MODEL	ESR20N	SET POINT USER	
DESIGNED BY	K. TAMAKI	DATE	
DRAWN BY	T. SUGIURA	TYPE	W8 - 0533592
CHECKED BY		TITLE	VACUUM PUMP OUTLINE DRAWING
DATE		SCALE	1:1
BY		REV.	1


▨ : HEAT INSULATOR



REV.	DESCRIPTION	DATE	BY	APP.

EYEBAR - REF. No.		CUSTOMER	
MODEL /	ESR80W(N)	SET POINT USER	
DESIGNED BY	K. YAMAGISHI No. E-17	DESIGNED BY	VACUUM PUMP
DRAWN BY	T. KAWAHARA No. E-17	DRAWN BY	OUTLINE DRAWING
CHECKED BY	H. FUJITA No. E-17	CHECKED BY	SCALE
			1:5
			DATE
			NO.
EBARA CORPORATION		W 0 - 0270195	





REVISIONS		DATE	BY	APP.
DESCRIPTION				
CUSTOMER		EBARA CORP. INC.		
PROJECT	ESR200W (IN)	DESIGNED BY	K. YAMAGISHI, Mr. ECH	
APP'D BY		CHECK'D BY	T. KAMAHARA, Mr. ECH	
TITLE		VACUUM PUMP OUTLINE DRAWING		
SCALE		1:1.5		
DRAWING NO.		W 8 - 0270137		
DRAWING DATE				






Fig. 3.1 MODEL ESR20N Performance Curve




Fig. 3.2 MODEL ESR80WN Performance Curve





Fig. 3.3 MODEL ESR200WN Performance Curve



NOTE: The MODEL ESR20N pump is supplied without a booster pump (BP).

Figure 3.4 System Flow

## 4. Installation

Be sure to take the following cautions and instructions into account when installing the pump.

### 4.1 Location

- (1) This pump is designed for indoor installation. To install the pump, select a place with little exposure to dust and humidity and not subject to dew condensation. Also allow for sufficient space to ensure easy pump installation and disassembly for maintenance.


In case of installing interface box to the pump, the distance between pump and interface box shall be 3m or less.

 <b>CAUTION</b>	Install pump in a location at an ambient not exceeding 30°C. Particular caution is required when the pump is operated in an enclosed room.
--	--

 <b>CAUTION</b>	A gap of at least 50mm should be left open for ventilation between the pump cover and the adjacent equipment.
--	---

- (2) In the case of MODEL ESR20N


Casters and adjusters of four each are attached under the pump base. When moving the pump, lift up all of the four adjusters. To lift them up, use the wrench and turn them to the left.



**Fig. 4.1 Caster (MODEL ESR20N)**

In the case of MODEL ESR80WN/ MODEL ESR200WN

Four integral mobile support units consisting of a caster and a height-adjustment foot each are provided underneath the pump base. To move the pump, raise the four adjustment feet by turning the holding nuts in the counterclockwise direction.



**Fig. 4.2 Caster (MODEL ESR80WN/MODEL ESR200WN)**

 <b>WARNING</b> 	<p>Be careful not to overturn the pump when pushing and pulling it sideways, because the width of the pump is small to its height.</p>
 <b>CAUTION</b>	<p>The neck portion of the casters will vibrate during caster movement. Be sure to keep your fingers and feet out.</p>
 <b>CAUTION</b>	<p>Do not step on the pump or place objects on it.</p>

(3) To fix the pump, turn the adjusters to the right to lower them.

(4) Adjust the height of the feet evenly to ensure that the pump base is level.

The difference in height between the two sides of the pump base shall not exceed 1mm.

The adjustment allowance is approximately 15 mm.

<b>NOTE</b>	<p>If the pump is not leveled, shortage of the lubrication oil supply to the bearing may be caused.</p>
<b>NOTE</b>	<p>To prevent vibrations and airborne noises, keep horizontal level of pump with the adjustment feet.</p>

## 4.2 Piping

### 4.2.1 Vacuum and Exhaust Piping

Connect the vacuum and exhaust pipes to the suction and exhaust flanges.

A narrow clearance is maintained in the pump for rotor rotation. The ingress of foreign objects into the pump interior will therefore prevent the pump from operating. Be sure therefore to heed the following cautions when making the pipe connections.

- a) Remove all foreign matter from inside the piping.
- b) When connecting be sure that no dirt or dust particles adhere to the flange surfaces and/or that the flange surfaces are damaged.  
Provide a suitable means of preventing the ingress of reaction by-products adhering to the APC valve and wafer fragments. For this purpose, a filter may be installed.
- c) The weight of the pipes attached to the pump can cause misalignment and leaks from the flange connections. Be sure therefore to support the piping properly and not to apply undue force when aligning the flange faces.  
It is recommended to insert flexible bellows when connecting the pipes to the suction and exhaust flanges of the pump.  
The length of the flexible bellows on the vacuum (suction) side will vary according to the vacuum drawn. Be sure to connect so that no undue force can be applied to the flexible bellows.

 <p><b>WARNING</b></p> 	<p>Be sure to check for leaks after you have installed the pump. Leaks will cause serious danger due to the discharge of harmful and hazardous substances and the occurrence of unpredictable reactions associated with the admission of air into the pump. When checking for gas leaks by pressurization, please pressurize by less than 0.05 MPa into the purge port and do check.</p>
---	--

 <p><b>CAUTION</b></p>	<p>Exhaust pipes made of materials that tend to transmit sound, such as vinyl chloride, may conduct pump exhaust sound, letting loud noise out. To solve such noise problems, attach a silencer (optional).</p>
---	---

### 4.2.2 Cooling Water Piping

Be sure to connect the cooling water pipes to the correct inlet and outlet ports. The connector ports are provided with couplers. Push in the plug till the end of socket. Socket sleeve returns to front. (Fig. 4.3)


Be sure that the supply/return plugs are not connected in reverse. The diameters are slightly different. In/Out markings are provided on each plugs.

When the coupler is pulled out the water pipe will be automatically blocked. Use cooling water corresponding to the specifications of Table 4.1 below.

**Table 4.1 Industrial Water Supply Quality Specification**

(Japan Industrial Water Association, Industrial Water Quality Standards Committee)

Turbidity	(ppm)	20
pH		6.5-8.0
Alkalinity(CaCO <sub>3</sub> )	(ppm)	75
Hardness(CaCO <sub>3</sub> )	(ppm)	120
Evaporation residue	(ppm)	250
Chlorine ion	(ppm)	80
Iron	(ppm)	0.3
Manganese	(ppm)	0.2



**Fig.4.3 Coupler**

 <p><b>WARNING</b></p> 	<p>In the case of removing the coupler, at first close the valve of cooling water supply line and next remove the coupler from the cooling water supply.</p> <p>In the case of connecting the coupler , connect it with the cooling water return (ret. outline drawing).</p> <p>If the above is neglected, pressure in the cooling water piping rises rapidly and there is a possibility to cause the water leak.</p>
---	---

 <p><b>CAUTION</b></p> 	<p>Even when the cooling water flow rate drops, the pump will continue to operate for 5 minutes.</p> <p>The material selected for the water piping of facility side should have a heat resistance so that it can withstand a maximum temperature of at least 70°C at the operating pressure.</p>
---	--

<p><b>! WARNING</b></p> 	<p>In the case of removing the coupler, at first close the valve of cooling water supply line and next remove the coupler from the cooling water supply.</p> <p>In the case of connecting the coupler, connect it with the cooling water return (ret. outline drawing).</p> <p>If the above is neglected, pressure in the cooling water piping rises rapidly and there is a possibility to cause the water leak.</p>
---	--


<p><b>! CAUTION</b></p> 	<p>Even when the cooling water flow rate drops, the pump will continue to operate for 5 minutes.</p> <p>The material selected for the water piping of facility side should have a heat resistance so that it can withstand a maximum temperature of at least 70°C at the operating pressure.</p>
---	--

### 4.2.3 N2 Gas Piping

Cut tube at right angles and make the end-face perfectly smooth. Then connect the tube to the tube fitting assembly of the N2 gas purge port. The tube is a push-fit onto the shoulder of the tube fitting assembly.

Secure the tube fitting assembly properly and tighten the retaining nut by hand. After this, use a tool to tighten the nut further by 1 + 1/4 turns.

To connect the tube again after this, install the tube already fitted to the ferrule and re-tighten the retaining nut slightly after the initial tightening (generally, tighten by a further quarter turn after tightening by hand).



**Figure 4.4 Tube Fitting Assembly**

<p><b>! CAUTION</b></p>	<p>For safety, be sure to use N2 gas which purity is more than 99.999%.</p> <p>Impurities of N2 gas may cause an accident when the pump is used for exhausting toxic and/or inflammable gases.</p>
-------------------------	--

#### 4.2.4 Ventilation Duct

To exhaust hot air, suck off the air inside the cover from the ventilating duct port at the top of the pump cover. Without proper ventilation, the temperature inside the cover will continue to rise until an ALARM is generated. This will result in serious problems.

The pump does not provide gas leak detector. So it is recommended that gas leak detector should be installed in duct piping to take exhaust flow interlock.

A substance which does not corrode with used gas shall be used as the material of the exhaust duct.

In case of detecting gas leakage, stop the gas flow into the equipment.

 <b>CAUTION</b> 	<p>For safety, be sure to ventilate through the ventilation duct when the pump is used to exhaust toxic and/or inflammable gases. Do not combine the ventilation duct with the pump exhaust piping .</p>
---	--

 <b>CAUTION</b>	<p>Even when the pump is used for exhausting process gases that are not toxic and/or inflammable, do not combine the ventilation duct with the pump exhaust piping. The exhaust noise of the pump will give rise to acoustic resonance inside the pump unit and result in an abnormal noise being generated.</p>
--	--

 <b>CAUTION</b>	<p>Never operate the pump without pump cover for safety.</p>
--	--

### 4.3 Electrical Wiring

 <p><b>WARNING</b></p>	<p>Be sure to keep the power supply to the pump turned off and locked out until you have finished the wiring and connecting work. Also interrupt Earth Leakage breaker (ELB) during this.</p>
---	---

 <p><b>WARNING</b></p>	<p>Only qualified electricians shall carry out electrical wiring.</p>
---	---

 <p><b>CAUTION</b></p>	<p>Do not apply the power supply from the pump's power pack to any other equipment as this will result in malfunctioning of the control units and in pump failure.</p>
---	--

#### 4.3.1 Power Supply Wiring


 <p><b>WARNING</b></p>	<p>Use the correct wiring materials and size to match the operating conditions in accordance with the power consumption rating and ambient air temperature of the pump.</p>
---	---

 <p><b>CAUTION</b></p>	<p>Be sure to connect the grounding wire.</p>
---	---

 <p><b>CAUTION</b></p>	<p>Wiring should be hard-wired or using twist-lock Hubbel-type connector at power source side.</p>
---	--

Wire the connector for the main power supply (3-phase, 200-220V and 50Hz/60Hz).  
Fig. 4.5 and Tables 4.2 and 4.3 show the connector pin assignment.

**Table 4.2 Pin Assignment  
of Power Supply Receptacle**



No.	Phase
A	R
B	S
C	T
D	GND

**Fig 4.5 Power Supply Receptacle**  
(As seen from connecting side)

**Table 4.3 Receptacle Specification**

Pump model	MODEL ESR20N	MODEL ESR80WN	MODEL ESR200WN
Receptacle type	JL04V-2E20-4PE-B	JL04HV-2E22-22PE-B	
Recep. Manufacturer	Japan Aviation Electronics Industry Co., Ltd.		
Adapted plug type	JL04V-6A20-4SE-EB	JL04V-6A22-22SE-EB	
Suitable wire	AWG #14		AWG #10
Power capacity kVA	4.0	7.0	8.0


#### 4.3.2 Control Signal Wiring

Connect wires to the control connector for remote operation and remote monitoring.

Tables 4.4, 4.5, 4.6 and 4.7 and Figs. 4.6 and 4.7 show the pin assignment.

**Table 4.4 Receptacle Specification**

Connector No.	Connector type
CN-Z	15 pin D sub-miniature Female receptacle (In accordance with SEMI E73)
CN-Y	25 pin D sub-miniature Female receptacle



**Fig. 4.6**  
**15 Pin D Sub-Miniature Female Receptacle**  
 (As seen from connecting side)

**Table 4.5 Control Connector Pin Assignment (CN-Z)**

Pin. No.	Signal name	I/O	Signal type
1	MP START (+)	IN	Run : CLOSE, Alternate
2	BP START (+)	IN	Run : CLOSE, Alternate
3	MP START STATUS (+)	OUT	Run : CLOSE, Alternate
4	BP START STATUS (+)	OUT	Run : CLOSE, Alternate
5	WARNING STATUS (+)	OUT	WARNING : OPEN, Alternate
6	ALARM STATUS (+)	OUT	ALARM : OPEN, Alternate
7	REMOTE STATUS (+)	OUT	REMOTE : ON
8	-		
9	MP START (-)		
10	BP START (-)		
11	MP START STATUS (-)		
12	BP START STATUS (-)		
13	WARNING STATUS (-)		
14	ALARM STATUS (-)		
15	REMOTE STATUS (-)		




Fig. 4.7

**25 Pin D Sub-Miniature Female Receptacle**

(As seen from connecting side)


**Table 4.6 Control Connector Pin Assignment (CN-Y)**

Pin No.	Signal name	I/O	Signal type
1	RESET (+)	IN	RESET:CLOSE
2	SAVING ENERGY CONTROL (+)	IN	SAVING :ENERGY CLOSE,Alternate
3	RESERVED (+)	IN	
4	PUMP N2 VALVE CONTROL (+) *1	IN	VALVE CLOSE:CLOSE, Alternate
5	EXHAUST N2 VALVE CONTROL (+) *1	IN	VALVE CLOSE:CLOSE, Alternate
6	EMO STATUS (+)	OUT	Abnormality : OPEN,Alternate
7	PUMP N2 WARNING STATUS (+)	OUT	Abnormality: CLOSE,Alternate*2
8	EXHAUST N2 WARNING STATUS (+) *1	OUT	Abnormality : CLOSE,Alternate*2
9	SAVING ENERGY STATUS (+)	OUT	SAVING ENERGY:CLOSE, Alternate
10	RESERVED (+)	OUT	
11	RESERVED (+)	OUT	
12	RESERVED (+)	OUT	
13	-		
14	RESET (-)		
15	SAVING ENERGY CONTROL (-)		
16	RESERVED (-)		
17	PUMP N2 VALVE CONTROL (-) *1		
18	EXHAUST N2 VALVE CONTROL (-) *1		
19	EMO STATUS (-)		
20	PUMP N2 WARNING STATUS (-)		
21	EXHAUST N2 WARNING STATUS (-) *1		
22	SAVING ENERGY STATUS (-)		
23	RESERVED (-)		
24	RESERVED (-)		
25	RESERVED (-)		

\*1 This item is optional.

\*2 Switching to N.C. is allowed by changing the DIP switch settings (see 6.4 DIP Switch).

**Table 4.7 CN-Z & CN-Y Signal Contacts**



 <b>CAUTION</b>	Do not wire vacant pins.
 <b>CAUTION</b>	Apply a 12V DC power for input signals on the pump side. Do not apply this voltage on the equipment side. The output signals are generated from an open collector output. Apply a voltage not exceeding 50V DC on the equipment side.
 <b>CAUTION</b>	Be sure to wire all signals with the correct polarity (SIG./COM.)
 <b>CAUTION</b>	When output signals are used to energize an inductive load such as a relay, be sure to insert a diode (100V, 1A class) in order to absorb the back electromotive force due to surge currents.

## 5. Power Supply for the Options


This Power Supply is used for the option which are listed below.  
(Cannot be used for other purposes.)

ADAPTER for Central Monitoring System  
Interface Controller  
N2 Solenoid Valve

 <b>DANGER</b>	Power Supply for the options is kept applying voltage when Earth Leakage Breaker (ELB) turns on during the pump is supplied the power.
 <b>WARNING</b>	Do not use the power supply for other purposes.

## 6. LCD Controller

### 6.1 LCD Outline



[Buttons]	START	For start of MP and BP
	STOP	For stop of MP and BP
	▲ ▼	For changing LCD indication
	RESET	For resetting WARNING and ALARM
	BZ. OFF	For "buzzer mute in WARNING / ALARM "
	PRG.	For changing screen of pump status and Dip Switch selection
	ENTER	For using at DIP switch selection
[LED]	B.P. RUN	BP running
	M.P. RUN	MP running
	LOCAL	LOCAL mode
	WARNING	WARNING condition
	ALARM	ALARM condition
	ERROR	Microprocessor malfunction

**Fig 6.1 LCD controller**

## 6.2 LCD Indication

The operating status of the pump is displayed on the LCD display of the controller. For details of display, see Tables 6.1.

**Table 6.1 LCD controller indication**

No	ITEM	INDICATION
1	Power	B P : # # . # # K W M P : # # . # # k W
2	Control mode Pump running mode	C O N T R O L : L O C A L M O D E : N O R M A L
3	Alarm history (Indication of history)	A L A R M / W A R N I N G H I S T O R Y ?
4	Pump type Pump unit No.	* * * * * & & & & & & &
5	Total operation time	O P E . T I M E # # # # # h
6	Back pressure (option)	B A C K P R E S S U R E # # . # k P a
7	Pump N2 gas flow	P U M P N 2 F L O W # # . # P a m <sup>3</sup> / s
8	Cooling water flow	W A T E R F L O W # # . # L / m i n
9	Pump casing temperature	C A S I N G T E M P . # # # ° C
10	Motor speed	B P : # . # k m i n - 1 M P : # . # k m i n - 1
11	WARNING/ALARM	\$ \$ \$ \$ \$ : \$ \$ \$ \$ \$ \$ \$ \$ % \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$

- Two control modes are available: LOCAL “(local operation)” and “REMOTE (remote operation)”.
- Two running modes are available “NORMAL (rate operation)” and “S.ENERGY (energy-saving operation)”
- " % " shows present number of WARNING/ALARM.
- Upper row "\$\$\$\$\$\$" distinguishes between WARNING/ALARM and indicates the position where WARNING/ALARM has occurred.  
Lower row "\$\$\$\$\$\$" displays details of WARNING/ALARM.

5. Total pump operating time gives the total hours of operation after shipment from the factory.
6. The display will return to the motor current indication when no operation takes place after the lapse of 1 minute.
7. Use the Display Select Switch (▲ ▼) to change the display.  
The WARNINGS/ALARMS that have currently been generated can be displayed with the Display Select Switch.

See Fig. 6.2 for the key operation of the pump operation status display.




Fig. 6.2 Key operation for the pump operation status display screen

Table 6.2 Alarm code list

ALARM name	Code		WARNING name	Code	
	1st code	2nd code		1st code	2nd code
MP casing temp.	50	01	Pump N2 zero mode error (※only MODEL ESR20N)	14	00
BP motor temp.	51	00	Pump N2	18	01
MP motor temp.	52	00	MP casing temp.	05	01
BP overload 1(Thermal)	54	00	BP motor temp.	24	00
MP overload 1(Thermal)	55	00	MP motor temp.	23	00
BP overload 2	67	00	High back pressure (▲)	21	00
MP overload 2	68	00			
BP step out	69	00	High board inner temp.	13	00
MP step out	70	00	MP driver case temp.	31	10
Power failure	64	00	BP driver case temp.	31	11
BP's driver protective circuit activated (OC)	66	01	MP driver inner temp.	31	12
BP's driver protective circuit activated (OV)	66	02	BP driver inner temp.	31	13
BP's driver protective circuit activated (OL)	66	03	Inner communication error (MP driver)	31	01
BP's driver protective circuit activated (OH1)	66	04	Inner communication error (BP driver)	31	02
BP's driver protective circuit activated (OH2)	66	05	Inner communication error (IO)	31	03
BP's driver protective circuit activated (CPF)	66	06	Inner communication error (AI)	31	04
BP's driver protective circuit activated (PF)	66	07	Low cooling water	00	01
BP's driver protective circuit activated (STA)	66	08	Cooling water ValveError (▲)	00	02
MP's driver protective circuit activated (OC)	65	01			
MP's driver protective circuit activated (OV)	65	02			
MP's driver protective circuit activated (OL)	65	03			
MP's driver protective circuit activated (OH1)	65	04			
MP's driver protective circuit activated (OH2)	65	05			
MP's driver protective circuit activated (CPF)	65	06			
MP's driver protective circuit activated (PF)	65	07			
MP's driver protective circuit activated (STA)	65	08			
Water leakage (▲)	53	00			
High back pressure (▲)	63	00			
Emergency stop (EMO) (▲)	59	00			
Low cooling water	81	90			

The mark "▲" indicates the item is optional.

### 6.3 Setting the operational mode

This section describes how to set the operational mode. In the normal state, the LCD controller displays pump status. To display the operational mode setting screen, press the key “**PRG.**” for three seconds or longer. Pressing the key for one second or longer again returns to the pump status display screen. Table 6.3 below shows indications and the details of the operational mode setting.

**Table 6.3 Operational mode setting screen**

Item	Indication	Description
Setting the pump operation control mode	SET CONTROL MODE?	Switches the control modes: local and remote.
Setting the DIP switch	SET DIP SW?	Performs the DIP switch settings (see 6.4).
Setting the pump running mode	SET RUNNING MODE?	Switches the running modes: NORMAL and S. ENERGY.
Setting the rotational speed in the NORMAL mode	SET NORMAL SPEED?	Sets the pump rotational speed in the NORMAL mode.
Setting the rotational speed in the S. ENERGY mode	SET S.ENERGY SPEED?	Sets the pump rotational speed in the S. ENERGY mode.
Setting the WARNING value for the back pressure (option)	SET ALARM SP BACK PRES.?	Sets the WARNING value for the back pressure.

Keys work as below for the setting screen.

- START : Valid
- STOP : Stops the pump.
- RESET : Resets WARNING and /or ALARM.
- BZ.OFF : Switches the DIP switch No.
- ▲ : Sets the DIP switch to ON. Switches the display of the operational mode setting screen.
- ▼ : Sets the DIP switch to OFF. Switches the display of the operational mode setting screen.
- ENTER : Determines the selected setting.

See Fig. 6.3 for how to set the operational modes.





Fig. 6.3 How to set the operational mode

### 6.3.1 Setting the pump operation control mode



REMOTE MODE: Enables the remote operation  
(start/stop with external signals)


LOCAL MODE: Enables the local operation  
(start/stop with the LCD controller)

The mode which is currently not set is displayed.

If you do not need to set, press the key

**PRG.** to go back to the previous screen.


### 6.3.2 Setting the DIP switch



The up and down arrow keys, “▲” and “▼,” turn On and OFF the DIP switch.  
The key **BZ.OFF** switches the selection from 1 to 8.

See 6.4 for details of the DIP switch.

### 6.3.3 Setting the pump running mode



S.ENERGY MODE: Enables the energy-saving operation

NORMAL MODE: Enables the rated operation.


The mode which is currently not set is displayed.

If you do not need to set, press the key

**PRG.** to go back to the previous screen.

### 6.3.4 Setting the normal rotational speed

(1) Setting the normal rotational speed (BP, MP individual setup)



▲ ▼ Use the up and down arrow keys to change the setting value.

▲: Increase the setting speed by 0.1 kmin<sup>-1</sup>.

▼: Decrease the setting speed by 0.1 kmin<sup>-1</sup>


Upper limit MP: 6.0 kmin<sup>-1</sup>, BP: 6.0 kmin<sup>-1</sup>

Lower limit MP: 4.0 kmin<sup>-1</sup>, BP: 3.0 kmin<sup>-1</sup>

**Table 6.4 Rotational speed and pumping speed**

Model	Rotational speed (rpm)		Pumping speed (L/min)
	Booster pump	Main pump	
MODEL ESR20N	—	4000	1300
	—	4600	1500
	—	5000	1650
	—	5500	1800
	—	6000	2000
MODEL ESR80WN	3000	4000	4000
	3700	4500	5000
	4400	4900	6000
	5000	5400	7000
	6000	6000	8500
MODEL ESR200WN	3000	4000	10000
	3600	4400	12000
	4500	5000	15000
	5400	5600	18000
	6000	6000	20000

## (2) Setting the normal rotational speed (Pumping speed setup)




SET PUMPING SPEED: MP/BP rotational speed set up by choosing pumping speed.

**Table 6.5 Pumping speed according to model**

PUMP MODEL	*1	*2
MODEL ESR20N	1300 L/min	2000 L/min
MODEL ESR80WN	4000 L/min	8500 L/min
MODEL ESR200WN	10000 L/min	20000 L/min

### 6.3.5 Setting the rotational speed in the S. ENERGY mode



▲ ▼ Use the up and down arrow keys to change the setting value.


▲: Increase the setting speed by  $0.1 \text{ kmin}^{-1}$ .

▼: Decrease the setting speed by  $0.1 \text{ kmin}^{-1}$

Upper limit MP, BP: The value lower than the set value for the rated speed

Lower limit MP:  $1.0 \text{ kmin}^{-1}$ , BP:  $1.0 \text{ kmin}^{-1}$

### 6.3.6 Setting the WARNING value for the back pressure (option)



▲ ▼ Use the up and down arrow keys to change the setting value.

▲: Increase the setting value by  $0.5 \text{ kPa}$ .

▼: Decrease the setting value by  $0.5 \text{ kPa}$ .

Upper limit:  $30.0 \text{ kPa}$

Lower limit:  $5.0 \text{ kPa}$

Factory setting:  $20.0 \text{ kPa}$

WARNING reset value: Set value  $-2.0 \text{ kPa}$

## 6.4 Dip Switch

Set the dip switches to select the operating modes as shown in Table 6.4 / 6.5.

**Table 6.6 Dip Switch-A Settings**

No.	Mode	Off	On	Default
1	Data length	7 bits	8 bits	On
2	Cooling water & N2 monitoring	Constant	Only during operation	Off
3	Buzzer	Not used	Used	On
4	Operation switched to Remote	According to signal	PUMP STOP	Off
5	External start/stop signal	Alternate (Level)	Momentary (Pulse) (▲)	Off
6	Pump N2 mode * <sup>1</sup>	Standard mode	Pump N2-0 mode	Off
7	Dilution N2 mode * <sup>2</sup>	Standard mode	Dilution N2-0 mode	Off
8	BP operation in Remote	Automatic operation	External signal input	Off

NOTE \*1: It is used for MODEL ESR20N.

(▲):Option

NOTE \*2: It is used for MODEL ESR80WN/ MODEL ESR200WN.

**Table 6.7 Dip Switch-B Settings**

No.	Mode	Off	On	初期値
1	----	----	----	----
2	----	----	----	----
3	Cooling water valve control*	Not applied	Applied	Off
4	Pump N2 valve control*	Not applied	Applied	Off
5	Exhaust N2 valve control*	Not applied	Applied	Off
6	Remote interface	Optional	Standard	On
7	Open-phase detection	Standard	Only during countdown	Off
8	LCD screen initialization	Initializes	Not initializes	Off

The items with the mark "\*" are optional.

**Table 6.8 Dip Switch-C Settings**

No.	Mode	Off	On	Default
1	PUMPN2 WARNIG output	NORMAL OPEN	NORMAL CLOSE	Off
2	EXT WARNIG output	NORMAL OPEN	NORMAL CLOSE	Off
3	----	----	----	----
4	----	----	----	----
5	----	----	----	----
6	----	----	----	----
7	----	----	----	----
8	----	----	----	----

- DIP SW-A. No.1 This switch allows you to select the data length out of 7 or 8 bits for the pump running status monitoring with the RS232C communication port.
- DIP SW-A. No. 2 This switch allows you to select out of “Constant” or “Only during operation ” for the cooling water and N2 monitoring. When “Only during operation” is selected for the cooling water monitoring, monitoring will be continued for 15 minutes after the pump operation has stopped for cooling the pump. Note that the N2 purging is recommended to continue during the pump stoppage as well because it will reduce accumulation of by-products and corrosion of the pump.
- DIP SW-A. No. 3 This switch allows you to select whether an acoustic alarm (buzzer) should be sounded or not when a WARNING/ALARM signal has been generated.
- DIP SW-A. No. 4 This switch allows you to select "According to Signal" or "PUMP STOP" when the toggle switch is moved from the LOCAL to the REMOTE position. When the former is selected, the pump is started/stopped in response to the external start signal. When the latter is selected, the pump is stopped regardless of the external signal.

**[ NOTE ]** You can change the setting of No. 3 (Buzzer) and the toggle switch anytime. When the settings other than No. 3 are changed, the LCD controller starts counting down from 10 seconds right after the setting change, which is similar to the situation when the power is on.

DIP SW-A. No. 5 This switch allows you to select "ALTERNATE (Level)" or "Momentary (Pulse)" for starting and stopping the pump under the external signal control. The former means switching on/off of the start signal. The latter means 2 types of pulse signals: ON or OFF.

**[ NOTE ]** Momentary signal of external start/stop signal used only when you use optional interface box.

DIP SW-A. No. 6 This switch allows you to select whether Pump N2 gas is used or not. To perform a process which does not lead to formation of reaction by-products in the pump or which uses non-corrosive gases, set this mode on. By closing the pump N2 valve and sealing the plug of the N2 purge port, the pump can be operated with setting the N2 flow 0 Pa m<sup>3</sup>/s. This mode No. 6 must be used with the N2 gas selector valve in combination. Also, the N2 purge port must be sealed in this case.

**[ NOTE ]** The N2 gas selector valve is positioned on the front panel at the right when viewing facing the pump front panel (operating panel).

DIP SW-A. No. 7 This switch allows you to select whether the dilution N2 gas is used or not. To perform a process which does not lead to the formation of reaction by-products in the pump or which uses non-corrosive gases, set this mode On. By closing the N2 gas selector valve, the N2 gas can be saved. This mode No. 7 must be used with the N2 gas selector valve in combination.

**[ NOTE ]** The N2 gas selector valve is positioned on the front panel at the right when viewing facing the pump front panel (operating panel).


**[ NOTE ]** It will take ten odd seconds will take until the flow has stabilized after you have operated the N2 gas selector valve.

- DIP SW-A. No. 8 This switch allows you to select “Automatic operation” of “External signal output” for the BP operation in the remote mode. When the former is selected, BP is automatically operated. When the latter is selected, BP is started/stopped in response to the external signal input.
- DIP SW-B. No.3 This switch allows you to select whether the cooling water valve is used or not when the valve is attached on the pump cooling water inlet. It allows you to control the cooling water supply to the pump. This is an optional item.
- DIP SW-B. No. 4 This switch allows you to select whether the pump N2 valve is used or not when the valve is attached on the N2 line in the pump unit. It allows you to control the N2 supply to the pump. This is an optional item.
- DIP SW-B. No. 5 This switch allows you to select whether the exhaust N2 valve is used or not when the valve is attached on the dilution N2 line for the exhaust gas after the pump unit. It allows you to control the dilution N2 gas supply for the exhaust gas. This is an optional item.
- DIP SW-B. No. 6 This switch allows you to select "Option" or "Standard" for use of the MODEL ESR-dedicated interface.  
To use the interface: set the switch to OFF.  
Not to use the interface: set the switch to ON.
- [ NOTE ]** With this switch set to OFF, signal output from the control signal connectors (CN-Z and CN-Y) that are directly connected to the pump is prevented although that from the MODEL ESR-dedicated interface is allowed.
- DIP SW-B. No.7 This switch allows you to select the open-phase detection mode.

- 
- DIP SW-B. No.8      This switch allows you to select "Initializes" or "Not initialize" for LCD screen display (by default, the screen display returns to a current reading display in 60 seconds).
- DIP SW-C. No.1      This switch allows you to select "NORMAL OPEN" or "NORMAL CLOSE" for PUMP N2 WARNING output.
- DIP SW-C. No.2      This switch allows you to select "NORMAL OPEN" or "NORMAL CLOSE" for EXT N2 WARNING output.

[ notes ] In the case of DIP switch set-up, please keep default setting of no selection DIP switch No. If you change DIP switch of no selection, it may be cause of some trouble.

### 6.5 DIP Switch setting display




**Fig 6.4 LCD controller**


Key functions will be as follows on the setting display.

- START : Invalid
- STOP This stops pump operation.
- RESET This resets trip and alarm.
- BZ.OFF This switches the dip switch numbers.
- ▲ This sets the selected dip switch ON.
- ▼ This sets the selected dip switch OFF.
- ENTER Move display level. Or indicate set up conditions.

#### DIP Switch-A



#### DIP Switch-B



\* indicates the dip switch number (1 to 8) currently you are setting.

**Fig 6.5 DIP Switch**

**[NOTE]** Duration of pump operation, dip switches, except A-3 (BUZZER), can not be used for parameter setting.

**[NOTE]** When parameter setting of the dip switches, other than dip switch-A No.3 (BUZZER), is performed, the LCD controller counts down 10 seconds, the same as at the power on state, right after the completion of the parameter setting.

**[NOTE]** If any warning or alarm occurs during the parameter setting, the setting session will be stopped automatically and the display will be changed to the warning & alarm display screen.

**[NOTE]** The dip switch setting at the time of shipment from the factory are as follows.

Data length	:	8bits
BUZZER	:	USE
Operation switched to Remote	:	According to signal
External START/STOP Signal	:	ALTERNATE signal
Pump N2 Mode	:	Standard Mode
dilution N2 Mode	:	Standard Mode
BP Operation in Remote	:	Automatic Operation

## 6.6 Starting/stopping the pump with the LCD controller

Maximum two LCD controllers can be connected. Note only one of them can start and stop the pump (the other shows the pump operational statuses).

The controller of which LED "LOCAL" is lit on has precedence over the other to control the start and stop operation.

If only one controller is connected, the controller starts and stops the pump.

	One controller connected	Two controller connected
START/STOP	Allowed	The one with its LED "LOCAL" lit on is allowed.

When you use two controllers, disconnect the one which you will not use for the operation from the pump once. Then, attach it again.

## 7. Operation

### 7.1 Before Starting

- (1) Turn on the cooling water supply and check that there are no leaks at the pipe connections.

 <b>CAUTION</b>	Without sufficient cooling water, the pump temperature will rise and problems such as rotor contact will occur.
--	---

[ **NOTE** ] The pump unit itself has no cooling water flow adjustment valve.

- (2) Turn on the N2 gas supply.

Check that the regulator attached to the pump is closed. (It is closed when the pressure adjustment knob is fully turned in the counterclockwise direction.) Open the main valve and check that there are no N2 gas leaks from the pipe connections.

Slowly turn the pressure adjustment knob clockwise to set the pressure (gauge pressure) to 0.05 MPa first. Then press the red stopper to lock the knob in position.

 <b>WARNING</b> 	Be sure to purge with N2 gas in order to prevent corrosion and reduce the formation/deposition of reaction by-products in the pump. When inflammable and/or toxic gases are diluted with N2 to the safe concentration, be sure to maintain a separate supply of N2 gas to the pump exhaust pipe.
---	--

 <b>CAUTION</b>	Abrupt rotation of the pressure adjustment knob will cause the pressure indicator needle of the regulator to wobble and result in an inaccurate pressure display.
--	---

 <b>CAUTION</b> 	Unless a sufficient supply of N2 gas is maintained, serious problems will occur such as oil back flow or pump corrosion and accretion of reaction by-products.
---	--

In the case of MODEL ESR20N

Operate the N2 gas selector valve in accordance with the dilution N2 mode set by DIP switch-A No. 6.

If DIP Switch is set to OFF            Open Valve.

If DIP Switch is set to ON            Close Valve.

**[ NOTE ]** For normal operation, open the N2 gas selector valve. Set dip switch-A No. 6 to ON when the production process does not lead to the formation of reaction by-products in the pump or when the process uses non-corrosive gases. Then close the pump N2 valve and the plug stop of the N2 purge port is carried out, N2 can be set to 0 and it can operate. Be sure always to use the N2 gas selector valve and dip switch-A No. 6 in combination. Please be sure to carry out the plug stop of the N2 purge port in that case.

**[ NOTE ]** When the pump is operated with N2 set to 0, be sure to close the pump N2 valve. If not, the lubrication oil may flow back to the suction side.

**[ NOTE ]** Two Pump N2 valves are positioned at right side when viewing facing the pump front panel (operating panel).

In the case of MODEL ESR80WN/MODEL ESR200WN

Operate the N2 gas selector valve in accordance with the dilution N2 mode set by DIP switch-A No. 7.

If DIP Switch is set to OFF            Open Valve.

If DIP Switch is set to ON            Close Valve.

**[ NOTE ]** For normal operation, open the N2 gas selector valve. To save N2 gas set close the valve when the production process does not lead to the formation of reaction by-products in the pump or when the process uses non-corrosive gases.

**[ NOTE ]** The N2 gas selector valve is positioned on the front panel at the right when viewing facing the pump front panel (operating panel).

**[ NOTE ]** It takes 10 odd seconds until the flow has stabilized after you have operated the N2 gas selector valve.

- (3) Turn on the power supply to the pump.
- (4) The LCD controller counts down 10 seconds after placing the Earth Leakage Breaker (ELB) into the ON position.
- [ NOTE ]** The pump cannot start while the measuring instruments are warming up for 10 seconds after the ELB is placed in the ON position.
- (5) Check on the WATER FLOW display of the LCD Controller that the cooling water flow rate is 2L/min. or more.
- (6) Re-check on the PUMP N2 FLOW display of the LCD Controller that the dilution N2 gas flow rate is within the 18 - 22Pam<sup>3</sup>/s range. Also check that the pressure gauge shows a reading of 0.04 - 0.07MPa.  
After setting the pressure, press the red stopper to lock the knob in position.  
In this condition, the shaft sealing N2 flow rate is 4.6 - 6Pam<sup>3</sup>/s.  
(The shaft sealing N2 flow rate is contained in pump N2 flow rate currently displayed on the LCD controller.)
- (7) When the WARNING/ALARM display appears on the LCD controller or when any abnormal symptoms are found other than the display, take action in accordance with 10. "Troubleshooting."  
Even when the cause of the WARNING/ALARM display has been removed, it is maintained until the RESET signal is entered. Either press the RESET button or enter an external RESET signal from the control signal connector.  
In the BUZZER Enabled mode using DIP switches, it is possible to stop the buzzer by pressing the BZ.OFF button when the alarm is being generated.
- (8) When the pump exhaust pipe is equipped with a valve, open this valve before starting the pump.

 <b>CAUTION</b> 	Problems will occur when the pump is operated with the valve closed as the exhaust pipe will be pressurized.
---	--

## 7.2 START/STOP

The toggle and DIP switches can be set at any time to select the LOCAL / REMOTE / COMMUNICAION modes and BUZZER Enabled function. Set in accordance with the operating conditions. (See 6.3. Setting the operational mode.)

<p> <b>WARNING</b></p> <p></p>	<p>The pump will remain at a very high temperature even after it has been stopped. Be sure therefore to leave the cooling water on for about one (1) hour after the pump has been stopped.</p> <p>When the cooling water is stopped at once after the pump stops, pressure in the cooling water piping rises. And there is a possibility to cause the water leak.</p>
--	---

<p> <b>WARNING</b></p> <p></p>	<p>The pump and exhaust piping will remain at a high temperature during operation and for a short time after the pump has stopped.</p> <p>Be sure to avoid contact and keep inflammable substances out of reach.</p> <p>Do not remove the outer cover during operation.</p>
---	---

<p> <b>CAUTION</b></p>	<p>When the production process leads to react by-products in the pump or when the process handles corrosive gases, be sure not to stop the pump until after at least 30 minutes of stopping the process gases.</p>
---	--

<p> <b>CAUTION</b></p> <p></p>	<p>Process gases will remain in the vacuum pipes and the pump even after the pump has been stopped.</p> <p>Be sure therefore to purge for at least 1 hour after the pumps has been stopped.</p> <p>Do not discontinue the N2 purge when the pump is stopped only for a short time.</p>
--	--

**[ NOTE ]** Do not exhaust the process gases until at least 30 minutes after the pump has been started. The pump casing temperature will stabilize after about 4 hours and it is recommended not to start exhausting the process gases earlier than this.

When DIP switch-A No. 4 is placed into the ON position and the toggle switch is changed from the LOCAL to the REMOTE setting the pump will stop regardless of the external signal input.

## 7.2.1 LOCAL (Pump Side) Start/Stop

### a) START

Press the START button on the controller.

The Main Pump (MP) will start and the M.P. RUN lamp on the controller will light.

After MP rotation reaches 3000 rpm, the Booster Pump (BP) will start automatically and the B.P. RUN lamp on the controller will light.

The current is indicated on the display during pump operation.

For other status display indications, refer to Table 6.1.

**[ NOTE ]** The pump will not start when an WARNING/ALARM has been generated. When the START button is pressed, "STARTFAIL" will appear on the display.

### b) STOP

Press the STOP button on the controller. The MP and BP will stop simultaneously.

The RUN lamp goes out and the display gives a power reading of 0.0kW.

## 7.2.2 REMOTE Start/Stop

### a) START

Enter the external "MP" start signal input from the control connector. The MP starts.

In the case of DIP SW A-8 ⇒ OFF : After "MP" rotation reaches 3000 rpm, "BP" will start automatically.

In the case of DIP SW A-8 ⇒ ON : After "MP" rotation reaches 3000 rpm, input the external "BP" start signal. BP will start.

The power is indicated on the display during pump operation. For other status display indications, refer to Table 6.1.

**[ NOTE ]** The pump will not start when an WARNING/ALARM has been generated. When a START signal is entered, "STARTFAIL" will appear on the display.

### b) STOP

Interrupt the external MP start signal and the pump will stop.

## 7.2.3 COMMUNICATION Start/Stop

### a) START

Enter the external "MP" start signal input through the communication connector. The MP starts.

In the case of DIP SW A-8 ⇒ OFF : "MP" rotation reaches 3000 rpm, "BP" will start automatically.

In the case of DIP SW A-8 ⇒ ON : "MP" rotation reaches 3000 rpm, input the external "BP" start signal. BP will start.

In the automatic BP operating mode, the BP can be started/stopped automatically. When the BP is operated under external start command input, apply the external BP start command to the communication connector. The power is indicated on the display during pump operation. For other status display indications, refer to Table 6.1.

**[NOTE]** The pump will not start when an ALARM/WARNING has been generated. When a START signal is entered, "STARTFAIL" will appear on the display. BP can be started/stopped by the external signal when the DIPswitch set accordingly.

b) STOP

Interrupt the external MP start command and the pump will stop.

**\*Please refer to the COMMUNICATION SPECIFICATIONS for details.**

## 8. Maintenance and Inspection

### 8.1 Internal energies

Following items show internal energies that shall be considered before start service maintenance.

#### 8.1.1 Power source

This dry pump is supplied with AC200V power source. Aside from the pump, the accessory power source locating in the vicinity of the power connectors are supplied with voltage even when the pump is completely stopped. To conduct pump maintenance or service, be sure to keep the power supply to the pump turned off and lock-outed and then unplug the power cable.

#### 8.1.2 Cooling water

This dry pump is supplied with cooling water at pressure of maximum 0.4 MPa. Disconnection of the cooling water resulted from improper handling may cause electrification and unit damage. For service and transportation, unplug the cooling water connection plugs on the inlet and outlet, and seal off with plastic cap. The self-sealing plug is used for the cooling water connection plug in these pumps.

#### 8.1.3 Nitrogen gas

This dry pump is supplied with nitrogen gas at pressure of maximum 0.7 MPa for diluting and sealing inside the pump. For service and transportation, close the supply-source valve to reduce the pressure with the regulator and detach the gas connection. Close nitrogen port with blank off plug. If the pump has already operated with process gases, purge the residual gases with nitrogen gas after stopping the pump operation. Then, conduct maintenance.

### 8.2 Routine Inspection

Check periodically that ALARM signal is not output on the LCD controller or remote output.

**Table 8.1 Typical check items**

No.	Item	Sensor	Interval (recommended)
1	Motor Current	CT	1 time/week
2	N2 Gas Flow	Flow sensor	
3	Vibration / Noise	-----	
4	Cooling water flow	Flow sensor	
5	Pump casing Temp.	T/C	
6	Color of lubrication oil	-----	1 time/month

When the WARNING/ALARM display appears, take action in accordance with Section 10. "Troubleshooting."

If the lubrication oil amount is lower than the lower limit line of the oil level gauge, supply the lubrication oil. See the section 8.3 "Lubrication oil" when adding the oil.

 <b>WARNING</b> 	Switch off the power supply to the pump first and interrupt the Earth Leakage Breaker (ELB) and lockout before you start on maintenance.
--	--

 <b>WARNING</b> 	The pump and exhaust piping will remain at a high temperature during operation and for a short time after the pump has stopped. Be sure to avoid contact and keep inflammable substances out of reach. Do not remove the outer cover during operation.
--	---

Even when the cause of the WARNING/ALARM signal has been removed the signal will be maintained until the RESET signal is entered. After you have taken the remedial action, press the RESET button on the controller or enter the RESET signal from the control signal connector to reset the WARNING.

<b>CAUTION</b>	The pump will not stop when an WARNING signal is generated. When pump operation is continued in this condition a ALARM signal will be generated or a serious breakdown will occur. Be sure therefore to check the pump in accordance with the instructions of Section 10. "Troubleshooting" after the process plant has completed 1 cycle.
----------------	--

<b>CAUTION</b>	When a ALARM signal has been generated in the REMOTE operating mode, do not start the maintenance tasks until you have interrupted the external start signal. When the external ALTERNATE start signal input is maintained, the pump will start while the ALARM is being reset.
----------------	---

If any abnormal symptoms other than those displayed on the LCD controller appear, take action in accordance with the instruction of Section 10. "Troubleshooting".

When the BZ.OFF button is pressed in the BUZZER Enable mode, the buzzer will stop even during a warning status.

### 8.3 Vacuum and Exhaust Piping

 <b>WARNING</b> 	Maintenance on the vacuum and exhaust piping shall be performed by taking proper action to avoid the dispersion of inflammable, toxic and/or hazardous substances and to prevent physical contact with, and absorption of, these substances.
---	--

 <b>WARNING</b> 	The pump and exhaust piping will remain at a high temperature during operation and for a short time after the pump has stopped. Be sure to avoid contact and keep inflammable substances out of reach.
---	--

	Do not remove the outer cover during operation.
--	---

 <p><b>WARNING</b></p> 	Be sure to check for gas leaks after you have finished pipe maintenance work. Leaks will cause serious danger due to the discharge of harmful and hazardous substances and the occurrence of unpredictable reactions associated with the admission of air into the pump. When checking for gas leaks by pressurization, please pressurize by less than 0.05 MPa into the purge port and do check.
---	---

Be sure to following the instructions below when carrying out maintenance work on the vacuum and exhaust piping of the pump.

- (1) Before you remove and wash the piping be sure to purge with a sufficient volume of N2 gas.
- (2) When an exhaust gas scrubber unit is used, close the inlet valve of the exhaust gas scrubber after the N2 gas purge has been discontinued and then remove the piping.
- (3) Be sure to switch off the power supply.
- (4) After you have washed the piping do not reconnect until it has dried completely.

#### 8.4 Lubricant Oil


 <p><b>CAUTION</b></p>	Do not start filling oil until the interior pump pressure has reached atmospheric pressure. The chamber containing the oil is under low pressure (vacuum) so that a significant leak will occur causing substantial damage to the pump when the oil filling plug is removed with the pump operating
---	---

 <p><b>CAUTION</b></p> 	Waste oil shall be disposed of by industrial waste disposal dealer in accordance with Material Safety Data sheets. (Appendix 1,2)
---	---

If the oil level is lower than the lower limit line of the oil level gauge in daily inspection and maintenance, supply the oil is needed.

Follow the steps below to supply the oil.

- (1) Stop the pump and remove the outer side cover on the pump. (See Fig. 8.1)



**Fig. 8.1 How to remove pump covers**

- (2) After you have waited until the internal pump pressure returns to atmospheric (normal) pressure, remove the plug from the oil-filler inlet. (See Fig. 8.2.)
- (3) Check the level through the window of the gauge. Then, add the oil so that the level is between the upper and lower limit lines (see Fig. 8.2, 8.3 and 8.4).
- (4) After you have checked that there are no depositions and fragments adhering to the O ring attached to the plug, close the oil-filler inlet.
- (5) Please check the air leak after supplying lubricating oil.




Fig. 8.2 Oil filler inlet, oil level gauge, and oil drain port positions




Fig. 8.3 Oil Level Gauge (BP)




Fig. 8.4 Oil Level Gauge (MP)

<b>CAUTION</b>	Be sure only to use the lubricant listed in specification tables 3.1.
<b>CAUTION</b>	When the lubrication oil level exceeds the upper limit, the oil may leak to the pump side. Thus, be sure not to exceed the upper limit line when adding the oil.
<b>CAUTION</b>	When the lubrication oil level is lower than the lower limit line, serious failure may be caused. If you find out the shortage, add the oil immediately.

## 8.5 Spare (Maintenance) Parts List

Following parts are needed for maintenance in customers' site.

**Table. 8.2 Spare (Maintenance) Parts List**

### 1. Standard consumption Part.

Parts' Name	Type	Part No.
PFPE oil	BARRIERTA J100ES	C-0402-000-0111

### 2. Recommendable Part for Safe Operation.

Parts' Name	Type	Part No.
O-ring (Viton A)	NW40	C-1210-352-0001
	G55 (For Exh. check valve)	C-1210-089-0201

### 3. Recommendable Parts for Safe Operation.

Parts' Name	Type	Part No.
Exhaust check valve	32X80L	C-2244-031-0001

### 4. Recommendable Spare Parts (Not needed for each pump.)

Parts' Name	Type	Part No.
Oil level gauge (BP)	-----	C-3126-006-0011
Oil level gauge (MP)	-----	C-5222-005-0001
Water flow sensor	10 L/min	C-5138-061-0001
N2 flow sensor (MODEL ESR20N)	84.4 Pa m3/S	C-5138-062-0001
N2 flow sensor (MODEL ESR80WN/MODEL ESR200WN)	84.4 Pa m3/S	C-5138-062-0111
T/C bolt	T TYPE, M8	C-1019-121-0001
N2 gas pressure regulator	R31-200-C121	C-2250-101-0001
Motor driver (MODEL ESR20N)	MP	C-5152-096-0001
Motor driver (MODEL ESR80WN)	BP	C-5152-098-0001
	MP	C-5152-096-0001
Motor driver (MODEL ESR200WN)	BP	C-5152-097-0001
	MP	C-5152-096-0001

Following labels are attached to pump covers. When they are hard to read for discoloring or peeling off, please stick them again as directed.

**Table. 8.3 Labels**

Label's Name	Parts No.
[DANGER] HAZARDOUS WAIGHT DANGER LABEL	C-7110-316-0001
[WARNING] HAZARDOUS VOLTAGE WARNING LABEL	C-7110-313-0001
[WARNING] HIGH TEMPERATURE WARNING LABEL	C-7110-312-0001
[WARNING] HAZARDOUS MATERIAL WARNING LABEL	C-7110-314-0001
[WARNING] HIGH TEMP. EYEBOLT WARNING LABEL	C-7110-317-0001
[CAUTION] CHARGE MARK LABEL	C-7110-315-0001

## 8.6 List of wastes during maintenance

Table 8.4 lists wastes from general user maintenance. Dispose the wastes properly according to your local waste disposal regulations in each area.

**Table 8.4 List of wastes during maintenance**

Part	Equipped on	Remarks
Lubricant oil	Inside of pump module. See section 8.4.	Refer to Appendix 1,2 or Material Safety Data Sheet.
Lithium battery	CPU board. (No necessary to replace at usual maintenance.)	Refer to Appendix 3 or Material Safety Data Sheet.
O-ring	Connection of vacuum line	Usual industrial waste.

## 8.7 Overhaul

Some parts used in this dry pump are consumables. Overhauls including periodical component replacement and inspections ensure safe and high-performance pump operations.

The overhauls require well-trained personnel who have up-to-date knowledge of the pump structure and are familiar with hazardous chemical gases and safe work procedures. Factories where the overhauls are conducted must be equipped with special tools and facilities as well as exhaust air ducts to protect against toxic gas hazards.

Ebara-designated overhaul factories provide services with well-trained personnel and relevant facilities supported by an established supply system of up-to-date pump information and genuine brand name parts. These advantages offer users superior overhaul services for the pumps in various states.

Ebara recommends the users to send the pumps for the periodical overhaul to the Ebara-designated factories. These factories equip special tools, sufficient evacuation duct

Contact EBARA Sales office or Overhaul service center for detail.

To avoid dangers potentially encountered during pump overhauls, follow instructions below to send your pump to an Ebara-designated factory for overhaul or repair.

- (1) Fill all necessary items in a form shown in Appendix 5 and fax it in advance to Ebara Service Center or one of the agents listed in Section 11 of this manual. Ask Ebara service center for latest form. The original copy must accompany the pump you send. Failure to meet these requirements may restrict Ebara from providing any overhaul services to avoid associated risks.
- (2) When you send back the pump to service center in the United States, contact Ebara Service Center first to obtain a RMA number for identification. Enter this RMA number to an Environmental Health & Safety Clearance Form shown in Appendix 5. Ask Ebara Service Center for latest form. Then, fax it in advance to Ebara Service Center and attach its original copy to the pump you send. Be sure to take these prior actions; otherwise Ebara refuses any overhaul services to avoid associated risks.

## 9. Disconnection and Transportation

 <b>WARNING</b> 	<p>When the pump has been used for exhausting highly toxic gases such as arsenic and mercury compounds, be sure to contact EBARA Corporation before you return the pump. Refer to Appendix 4 and 5 for the format required when customer returns their pump to Ebara service center for overhaul or rebuild.</p>
---	--

 <b>CAUTION</b> 	<p>In the interest of safety during the transportation, disassembly and cleaning of the pump be sure to take note of the gases that have been handled.</p>
---	--

To disconnect and transport the pump, proceed as follows.

- (1) Stop the pump and replace all gases inside the pump by purging them with N<sub>2</sub> gas.
- (2) Switch off the power supply to the pump and remove the power and signal wires.
- (3) After you have fully closed the N<sub>2</sub> regulator remove the N<sub>2</sub> pipe, seal off the N<sub>2</sub> purge port with a sealing flange.
- (4) Remove the cooling water pipes.
- (5) Remove the vacuum and exhaust pipes and completely seal off the suction and exhaust ports of the pump with a blind flange or similar seal. Seal off all process gas discharge points such as the differential port by using a blind flange.


[ notes ] Differential port is option.

- (6) Attach the LCD controller on the front panel of the control board. Fix it with the tape.
- (7) Wrap the pump in a vinyl sheet.
- (8) Use the eyebolts provided on the pump for slinging the pump to load and unload. Fasten eyebolts completely and push in until flush with the seating surface. For sling, use a wire with a length so that the slinging angle (that is, the angled subtended by the two wires) is within 60 degrees.

 <p><b>DANGER</b></p>	Do not enter the zone underneath the suspended pump.
--	--

 <p><b>WARNING</b></p>	<p>For lifting the pump, use only qualified operator personnel. Be sure that the wire rope and crane used for lifting the pump are in proper order and match the weight of the pump.</p> <p>To prevent unequal weight distribution, suspend the pump by ensuring that the slinging angle remains symmetrically centered.</p>
---	--

 <p><b>CAUTION</b></p>	<p>In case of sling and transportation, be sure not to remain leaning more than 10 deg against a horizontal for 5 minutes. If not, oil leakage will occur.</p>
---	--



**Fig. 9.1 Slings the Pump**

- (9) When options such as an interface box are attached to the pump, be careful to avoid damage due to contact by the wire rope.
- (10) For transportation, secure the pump by lowering the adjustment feet. Place a protective cloth around the pump to avoid shock and position protective members between the outer cover and the wires in order to distribute the load of the fastening wires.

To avoid dangers potentially encountered during pump overhauls, follow instructions shown in section 8.7, Appendix 4 or 5 to send your pump to an Ebara-designated factory for overhaul or repair.

## 10. Troubleshooting

### 10.1 Troubleshooting (1) Basic trouble

 <p><b>WARNING</b></p> 	<p>Interrupt Earth Leakage Breaker (ELB) before starting on wiring and maintenance work.</p> <p>Do not switch on the power supply to the pump until work is completed.</p>
 <p><b>WARNING</b></p> 	<p>The pump casing and exhaust piping become extremely hot during operation and for some time after stopping.</p> <p>Be sure that pump and exhaust piping do not come in contact with humans or inflammable substances.</p> <p>Do not remove the pump cover during operation.</p>
 <p><b>WARNING</b></p> 	<p>Check for gas leaks after installing and maintaining the piping. Gas leaks will result in the discharge of harmful and dangerous substances and in abnormal reactions due to the ingress of air into the pump. When checking for gas leaks by pressurization, please pressurize by less than 0.05 MPa into the purge port and do check.</p>

Abnormal symptom	Check Item	Corrective Action
Earth Leakage Breaker is activated. (Leakage detector is on.)	Incorrect wiring	Check wiring.
	Short circuit	Replace or overhaul pump.
Power LED does not come on.	No power supply to pump.	Check power supply.
	connector is not connected.	Connect power connector.
	ELB is not ON.	Place ELB to ON.
Nothing appears on LCD	ELB is not ON.	Place ELB to ON.
	Disconnection of the LCD's connector	Connect LCD's connector
	Instrument failure	Replace instruments.
MP does not start when applying START button.	"Remote" mode has been selected.	Set switch to "Local" mode.
	Start-up conditions are not satisfied. ("Startfail" is displayed.)	Satisfy all start-up conditions.
	Instrument failure	Replace instrument.
MP does not start when entering external "MP start" signal input.	"Local" mode has been selected.	Set switch to "Remote".
	Start-up conditions are not satisfied. ("Startfail" is displayed.)	Satisfy all start-up conditions.
	Instrument failure	Replace instrument.
BP does not start.	BP start signal is not entered in REMOTE mode.	Enter the start signal.
	Instrument failure	Replace instruments.
Abnormal noise Excessive vibration	Adjustment feet are not applied.	Use the adjustment feet.
	Some object is making contact with the outer cover.	Remove the object.
	The fastening screws of the outer corer have worked themselves loose.	Tighten the fastening screws.
	Parts of the pump are damaged.	Replace or overhaul pump.
Vacuum pressure increase.	Accumulation of by-products in pipes.	Clean piping.
	N2 pressure setting is high.	Set pressure for correct value.
	Leak from vacuum piping.	Check piping.
	Accumulation of by-products in pumps.	Replace or overhaul pump.
**MEMORY ERROR** is displayed on LCD after activating ELB or changing the dip switch setting	None	Need "Countermeasure against electric Noise" to pump.

## 10.2 Troubleshooting (2) WARNING

 <b>WARNING</b> 	<p>Interrupt Earth Leakage Breaker (ELB) before starting on wiring and maintenance work.</p> <p>Do not switch on the power supply to the pump until work is completed.</p>
 <b>WARNING</b> 	<p>The pump casing and exhaust piping become extremely hot during operation and for some time after stopping.</p> <p>Be sure that pump and exhaust piping do not come in contact with humans or inflammable substances.</p> <p>Do not remove the pump cover during operation.</p>
 <b>WARNING</b> 	<p>Check for gas leaks after installing and maintaining the piping. Gas leaks will result in the discharge of harmful and dangerous substances and in abnormal reactions due to the ingress of air into the pump. When checking for gas leaks by pressurization,</p> <p>please pressurize by less than 0.05 MPa into the purge port and do check.</p>

Display	Symptom	Check Item	Corrective Action
WARN: WATER FLOW LOW ###.#	Water flow is reduced.	Coupler is disconnected.	Connect coupler.
		Pressure is not sufficient.	Apply sufficient pressure.
		Root valve is closed.	Open valve.
		Water pipe is clogged.	Clean or replace piping.
		Tube fittings are loosened.	Re-tighten.
		Instrument failure	Replace instrument.
		Outlet & inlet pipes are reverse. (flow value 0 L/min)	Connect pipes correctly.
WARN: PUMP N2 FLOW LOW	Pump N2 flow is reduced.	N2 port is not connected.	Connect N2 pipe fitting.
		Primary pressure is insufficient.	Apply sufficient pressure.
		Regulator setting value LOW.	Increase pressure setting.
		N2 pipe is clogged.	Replace N2 piping.
		Leaks on N2 pipe.	Check the fittings.
		Instrument failure	Replace instrument.
WARN: CASING TEMP HIGH	Casing temperature rises.	Duct ventilation insufficient	Ventilate sufficiently.
		Pump back pressure rises.	Check exhaust pipe
		Increase of the gas load.	Reduce the inflow gas amount.
		Accumulation of by-product	Replace or overhaul pump.
		Cooling water flow is reduced.	Increase cooling water flow.
WARN: BP MOTOR TEMP HIGH  WARN: MP MOTOR TEMP HIGH	Booster Pump (BP) motor coil temp. rises.  Main pump (MP) motor coil temp. rises.	Cooling water flow is reduced.	Cool pump thoroughly and reset.
WARN: ## COMM.ERROR	Communication is not established.	Connection error of the instrumented units	Check the connection of the instrumented unit.
		Instrument failure	Replace instrument.
ALARM: PUMP BOX TEMP HIGH	Temp. rises in pump cover.	Duct ventilation not sufficient	Ventilate sufficiently.
		Cooling water flow is reduced.	Increase cooling water flow.
WARN: OIL LEVEL LOW	Oil level is low.	Check oil level. (See Fig.8.1)	Charge lubrication oil.
WARN:PUMP N2 VALVE ERROR	N2 valve open.	Setting is N2 0 mode	Close N2 valve. (at the side of pump)

After you have taken the remedial actions above, reset the pump. If the problem that has caused the WARNING signal still remains, the WARNING display will appear again even after you have reset.

### 10.3 Troubleshooting (3) ALARM

 <b>WARNING</b> 	<p>Interrupt Earth Leakage Breaker (ELB) before starting on wiring and maintenance work.</p> <p>Do not switch on the power supply to the pump until work is completed.</p>
 <b>WARNING</b> 	<p>The pump casing and exhaust piping become extremely hot during operation and for some time after stopping.</p> <p>Be sure that pump and exhaust piping do not come in contact with humans or inflammable substances.</p> <p>Do not remove the pump cover during operation.</p>
 <b>WARNING</b> 	<p>Check for gas leaks after installing and maintaining the piping. Gas leaks will result in the discharge of harmful and dangerous substances and in abnormal reactions due to the ingress of air into the pump. When checking for gas leaks by pressurization, please pressurize by less than 0.05 MPa into the purge port and do check.</p>

Display	Symptom	Check Item	Corrective Action
ALARM: WATER FLOW LOW	Water flow is reduced.	Coupler is disconnected.	Connect coupler.
		Pressure is not sufficient.	Apply sufficient pressure.
		Root valve is closed.	Open valve.
		Water pipe is clogged.	Clean or replace piping.
		Tube fittings are loosened.	Re-tighten.
		Instrument failure	Replace instrument.
		Outlet & inlet pipes are reverse. (flow value 0 L/min)	Connect pipes correctly.
ALARM: CASING TEMP H.HIGH	Pump casing temp. rises.	Insufficient ventilation	Ventilate sufficiently
		Pump back press. rises.	Check exhaust pipe & silencer.
		Increase of the gas load.	Reduce the inflow gas amount.
		Cooling water flow is reduced.	Cool pump thoroughly and reset.
		Accumulation of by-products	Replace or overhaul pump.
ALARM:BP MOTOR TEMP H.HIGH ALARM:MP MOTOR TEMP H.HIGH	Booster Pump (BP) motor coil temp. rises. Main Pump (MP) motor coil temp. rises.	Cooling water flow is reduced.	Cool pump thoroughly and reset.
		Motor failure	Replace or overhaul pump.
ALARM:BP MOTOR OVERLOAD  ALARM:MP MOTOR OVERLOAD	BP motor current rises. (thermal relay trip)	Pump back press. rises.	Check exhaust pipe & silencer.
		Increase of the gas load.	Reduce the inflow gas amount.
	MP motor current rises. (thermal relay trip)	Rotor makes contact. (Accumulation of by-products) (Substance plunge)	Replace or overhaul pump.
		Open phase	Loss of the phase in power source
		Instrument failure	Replace instrument.
ALARM:BP MOTOR STEP OUT  ALARM:MP MOTOR STEP OUT	Booster Pump (BP) motor step out  Main Pump (MP) motor step out	Pump back press. rises.	Check exhaust pipe.
		Increase of the gas load.	Reduce the inflow gas amount.
	Can not restart	Rotor makes contact. (Accumulation of by-products) (Substance plunge)	Replace or overhaul pump.
		Instrument failure	Replace instrument.

ALARM: BP DRIVER ###	BP Motor driver protection	Insufficient ventilation	Ventilate sufficiently.
		Pump back press. rises.	Check exhaust pipe.
		Increase of the gas load.	Reduce the inflow gas amount.
ALARM: MP DRIVER ###	MP Motor driver protection  Can not restart	Rotor makes contact. (Accumulation of by-products) (Substance plunge)	Replace or overhaul pump.
		Cooling water flow rate is reduced.	Cool pump thoroughly and reset.
		Motor driver has broken down.	Replace motor driver.
		Instrument failure	Replace instrument.
ALARM: PHASE ERROR	Open phase	Incorrect wiring	Check power supply
		Starting during WARNING/ALARM status	Make sure that all starting conditions are met.
ALARM:STARTFAIL ALARM/WARN EXIST	Start fault	Instrument failure	Replace instrument.

After you have taken the remedial actions above, reset the pump. If the problem that has caused the ALARM signal still remains, the ALARM display will appear again even after you have reset.

During REMOTE operation carry out the above procedures after you have turned off the external start signal.

When the external start signal remains on in the ALTERNATE mode, the pump will start immediately when the RESET signal is applied.

## 10.4 Troubleshooting (4) Option

 <b>WARNING</b> 	<p>Interrupt Earth Leakage Breaker (ELB) before starting on wiring and maintenance work.</p> <p>Do not switch on the power supply to the pump until work is completed.</p>
--	--

 <b>WARNING</b> 	<p>The pump casing and exhaust piping become extremely hot during operation and for some time after stopping.</p> <p>Be sure that pump and exhaust piping do not come in contact with humans or inflammable substances.</p> <p>Do not remove the pump cover during operation.</p>
--	---

 <b>WARNING</b> 	<p>Check for gas leaks after installing and maintaining the piping. Gas leaks will result in the discharge of harmful and dangerous substances and in abnormal reactions due to the ingress of air into the pump. When checking for gas leaks by pressurization, please pressurize by less than 0.05 MPa into the purge port and do check.</p>
---	--

Display	Symptom	Check Item	Corrective Action
ALARM: WATER LEAKAGE	Water leakage	Tube fittings are loosened.	Re-tighten.
		Instrument failure	Replace instrument.
ALARM: BACK PRESS.HIGH	Exhaust pressure rises.	Exhaust valve is closed.	Check exhaust pipe.
		Instrument failure	Replace instrument.
WARN: PRESS. HIGH ##.#	Exhaust pressure rises.	Exhaust valve is closed.	Check exhaust pipe.
		Instrument failure	Replace instrument.
ALARM: EMERGENCY STOP	Emergency Stop switch	Stop by emergency Stop button.	Check that pump can be operated and turn the button head to release lock.

After you have taken the remedial actions above, reset the pump. If the problem that has caused the TRIP signal still remains, the TRIP display will appear again even after you have reset.

During REMOTE operation carry out the above procedures after you have turned off the external start signal.

When the external start signal remains on in the ALTERNATE mode, the pump will start immediately when the RESET signal is applied.