

### **Use with Firmware Release V1.19 or higher**

# MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY

MODEL NUMBER	STOCK NUMBER
HF2/230	1-264-03
HF2/380	1-264-03-01
HF2/460	1-264-03-02
HF2/208	1-264-03-03
HF2S/230	1-265-03
HF2S/380	1-265-03-01
HF2S/460	1-265-03-02
HF2S/208	1-265-03-03

Units with the built-in Weld Sentry Option also require User's Manual No. 990-291

#### WARNING

Please be sure to read all personnel and equipment safety precautions noted in this manual.



**VIEW OUR INVENTORY** 

### ©1998, 2002 Unitek Miyachi Corporation

The engineering designs, drawings and data contained herein are the proprietary work of UNITEK MIYACHI CORPORATION and may not be reproduced, copied, exhibited or otherwise used without the written authorization of UNITEK MIYACHI CORPORATION.

Printed in the United States of America.

Revision	EO	Date	Basis of Revision		
А	ENRG-RLSE	3/95	Released original manual.		
В	None	9/95	Reorganize manual into chapters.		
С	None	1/96	Amend to Firmware V1.17 or higher.		
D	None	2/96	Update cover stock numbers		
Е	None	4/97	Amend to Firmware V1.19 or higher.		
F	17472	6/98	<ol> <li>Remove existing calibration procedure and reference User Calibration Procedure 994-001.</li> <li>Miscellaneous corrections.</li> <li>Remove SAVE error.</li> </ol>		
G	18951	8/01	<ol> <li>Include EO# 17693 in manual.</li> <li>Add latest version of Operator Guide.</li> </ol>		
Н	19012	9/01	<ol> <li>Include EO# 118951 in manual.</li> <li>Add latest version of Operator Guide.</li> </ol>		
J	19146	1/02	<ol> <li>Include EO# 19012.</li> <li>Miscellaneous Corrections.</li> <li>Add Appendix F, Quality Resistance Welding Solutions, and Appendix G, Replacement of Programmed Integrated Circuits.</li> </ol>		
K	20016	5/04	Updated wire data.		

#### **REVISION RECORD**

### FOREWORD

The purpose of this manual is to supply operating, maintenance and service personnel with the information needed to properly and safely operate, maintain and service the Unitek Peco Model HF2 2 kHz High Frequency Resistance Welding Power Supply.

Should questions arise, or if you have suggestions for improving this manual, please contact:

Unitek Miyachi Corporation 1820 South Myrtle Avenue P.O. Box 5033 Monrovia, CA 91017-7133 Telephone:(626) 303-5676 FAX:(626) 358-8048 E-mail: info@unitekmiyachi.com

## NOTICE

Unitek Miyachi Corporation may be released from all warranty obligations if repairs or modifications are made by persons other than its own service personnel, or authorized representatives' personnel, unless such repairs or modifications are specifically authorized in writing by the Unitek Miyachi Corporation.

### WARNING

Contact with voltages present in this power supply may cause serious or fatal injuries. Please read the manual completely and note all cautions and warnings before attempting to install, operate or maintain the power supply.

### CONTENTS

	Page
CHAPTER 1: DESCRIPTION	
HF2 description	1-1
CHAPTER 2: GENERAL SET-UP	
Required Connections	2-1
Physical Space Requirements	
HF2 Weld Control Dimensions	
HF2 Weld Transformer Dimensions	
Power Line Voltage, Current, And Wire Size Requirements	
Insulation Requirements	
Power Line Fuse Requirements	
HF2 Weld Transformer Electrical Specifications	
HF2 Welding System Maximum Secondary Loop Resistance	
HF2 Maximum Secondary Loop Resistance Measurement	
HF2 Weld Control To HF2 Weld Transformer Connections	
HF2 Weld Transformer To Weld Head Connections	
Weld Sentry Option	
Help Screen Languages	
CHAPTER 3: WELDING SYSTEM SET-UP	
Welding System Set-Up Guide	
General Programming Instructions	
Unitek Peco Force Fired. Foot Actuated Weld Head System	
Weld Head Set-Up	
Firing Switch Cable Connection	
Ouick Start Programming Guide	
Unitek Peco Force Fired, Single Air Actuated Weld Head System	
Weld Head Set-Up	
Firing Switch Cable Connection	
Weld Head Valve Driver No. 1 Connection	
Foot Switch Connection	
Single Air Regulator Adjustment (Model 80 Series)	
Dual Air Regulator Adjustments (Model 180 And Model 90 Series)	
Quick Start Programming Guide	
Unitek Peco Force Fired, Dual Air Actuated Weld Head System	
General Information	
HF2 Control, Jumper Modifications	
Weld Head Set-Up	
Firing Switch Cable Connection	

### **CONTENTS** (Continued)

#### Page

#### CHAPTER 3: WELDING SYSTEM SET-UP (Continued)

Weld Head Valve Driver Connections	
Foot Switch Connection	
Dual Air Regulator Adjustments	
Quick Start Programming Guide	
Non-Force Fired, Single Air or Cam Actuated Weld Head System	
LC To HF2 Control Electrical Connections	
PLC Timing Diagram	
Quick Start Programming Guide	
Non-Force Fired, Multiple Air Actuated Weld Head System	
CHAPTER 4: CONTROLS	
HF2 Weld Control - Front Panel	
HF2 Weld Control - Rear Panel Inputs and Outputs	
Power	
Fuses F1 and F2	
Sensing Port	
Sensing Port - Connector Pin Assignments	
Output	
Foot Switch Connector	
Single-Level Foot Switch	
Two-Level Foot Switch	
Firing Switch Operation	
Mechanical Firing Switch Cable	
Optical Firing Switch Connector	
Mechanical Firing Switch - 3-Wire Connection	
Opto Coupler Firing Switch - 3-Wire Connection	
Control Signals Connector	
Control Signals - Pin Assignments	
Control Signals - Remote Weld Schedule Selection Input	
Control Signals - Emergency Stop Input	
Control Signals - Process Inhibit Input	
Control Signals - Output Relays	
Relay K1	
Relay K2	
Accessory Port	
Air Valve 1 and Air Valve 2 Driver Connectors	
Air Valve 1 Driver	
Air Valve 2 Driver	

## **CONTENTS** (Continued)

Page

CHAPTER 5: PROGRAMMING MODES	
Help Screens	5_1
Machina States	
Wald Graph Run State	
Basic Weld Monitor Pun State	
Alphanumaria Dun Stata	5.2
No Wold State	5.2
Standby State	5.2
Alarm State	5 2
Fire State	
Menu State	5.2
Program State	
Wald Graph Dragram State	
Alphanymaria Dragram State	
Alphanumenc Plogram State	
Dalay 1 Dual Air Haad Operation	
Kelay I - Dual All Head Operation	
CHAPTER 6: ADVANCED WELDING FUNCTIONS	
Weld Functions	
Basic Weld	
Weld / Repeat	
Quench/Temper	
Pre/Postheat	
Up/Down Slope	
Braze	
Rollspot	
Seam	
Dual Pulse	
Pulsation	
CHAPTER 7: SPECIAL FEATURES	
System Options	
Weld Counter	
Copy a Schedule	
System Security	
System Help	
Weld Sentry	
Calibrate HF2	
Reset to Defaults	
Installation	
Transformer Model	7-13

# **CONTENTS** (Continued)

	Page
CHAPTER 8: WELD MONITORING	
Basic Weld Monitor General Description.	8-1
Weld Current and Weld Voltage Measurements	
Data Output Capabilities	
Weld Monitoring Suggestions	
Basic Weld Monitor Programming	8-3
Energy Limit Monitor General Description	
Energy Limit Monitor Programming	
CHAPTER 9: RS-485 DATACOM	
Description	
RS485 Serial Port Connections	
Datacom Software Installation.	
F1:Setup	
F2:Collect Data	
F3:Erase Data	
F4:Exit`	
APPENDIX A: TECHNICAL SPECIFICATIONS	A-1
APPENDIX B: RECOMMENDED SPARE PARTS	B-1
APPENDIX C: ALARM MESSAGES	C-1
APPENDIX D: HELP SCREEN LANGUAGES	D-1
APPENDIX E: THE BASICS OF RESISTANCE WELDING	E-1
APPENDIX F: QUALITY RESISTANCE WELDING SOLUTIONS:	
DEFINING THE OPTIMUM PROCESS	F-1
APPENDIX G: REPLACEMENT OF PROGRAMMED INTEGRATED CIRCUITS	G-1
INDEX	Index-1

#### UNLIFER MEVACINE CORPORATION.

### Declaration of Conformity

Oractivo)(	EMC, LOW FOLTHER, MACHINERY
Type of Equipment	Basingnos Webling Power Ropph Equipment
Applied Standards:	IN-1983 COMPACTOR COMPACTS IN COMPACTS INTENTE IN COMPACTS IN COMPACTS IN COMPACTS IN COMPACTS IN COMP
Model Nex.:	HFOLM, METRICAL MARKEN AND AND AND AND AND AND AND AND AND AN

Authorized Representative Writer Receptor Community

Well Topic Scine BY Englishing 217 Produce 201 2701 AD Historical Hits LAND

Mendature's Name and Address.

UNITER MEYACHI DERPOLATION 1829 South Martin Avenue Menorata, CA. 19807 - D.E.A.

Based on the Stelanstics of Conformity Confidence insued by the test interactions. I device that the oppipment specified above confidence to the found directive and standards.

Plant Managin CA Dife: Deprive 26, 1996 p.l.M. Robert S. Wach ich. 18 18 See Co ß genters / a serie

Robert J. Mulliob Pull Name

Discher of Oudry Amount Title Full Name View President, Engineering

Mark O. Resignabi

This:

# CHAPTER 1 DESCRIPTION

The Unitek Peco High Frequency Inverter (HF2) is a 2 KHz, three-phase, state-of-the-art inverter welding control for joining precision small parts at high speed with controllable rise times using 2 KHz output pulses superimposed on pure DC welding energy. High speed (250 micro-second) digital feedback automatically controls weld current, voltage, or power, providing more welding consistency compared to traditional direct energy (AC) or stored energy (CD) technologies. Microprocessor technology automatically compensates for changes in workpiece resistance, load inductance, weld transformer saturation, and ñ 13% changes in line voltage. The HF2 uses IGBT power device technology for precisely controlling the weld energy at both high and low energy levels.

Easy to use constant weld current, voltage or power feedback ensures repeatable welding and has proven to extend electrode life in many applications by a factor of five or more. A selectable weld energy limiting feature also contributes to repeatable welds and high nugget quality. The user can program the HF2 using a graphical or numerical interface. The Weld Graph Program Mode (Figure 1-1) emulates many of the popular word processing programs by using the front panel cursor keys to easily modify any time period, current, voltage, or power value. The Weld Graph Run Mode (Figure 1-2) gives the user instant visual feedback on the actual current, voltage or power used to make each weld.



Figure 1-1. Program Mode



The HF2's exclusive, context sensitive, User Help Screens quickly guide the user through even the most complex program. Each weld schedule can use any one of 10 different Weld Functions, thus matching the appropriate weld energy profile to the application.

Simple automated welding control is easily accomplished using the BCD Remote Schedule Select feature. For more complex automation processes, a host computer can use the HF2 Bi-Directional RS422/RS485 Communications Port to select HF2 Weld Schedules and receive average weld current and weld voltage data for each weld. Refer to the separate RS-485 Datacom Manual, P/N: 990-058, for Advanced RS-485 Datacom operation. The 2 KHz operating frequency ensures that the HF2 Weld Transformers are light weight and compact, providing a significant advantage when they are built into robotics or automatic machines.

# CHAPTER 2 GENERAL SET-UP

#### **REQUIRED CONNECTIONS**

#### **Physical Space Requirements**

Unitek Peco recommends that the HF2 Weld Control and HF2 Weld Transformer be installed in a well ventilated area that is free from excessive dust, acids, corrosive gases, salt and moisture. Allow sufficient clearance around both sides and back of the HF2 Weld Control and HF2 Weld Transformer so that cooling air may flow properly. Figure 2-1 shows the cooling airflow pattern for the HF2 Weld Control. Figure 2-2 shows the cooling airflow pattern for the HF2 Weld Transformer.



Figure 2-1. HF2 Weld Control Air Flow Pattern



Figure 2-2. HF2 Weld Transformer Air Flow Pattern

#### **HF2 Weld Control Dimensions**

1	Width (in/cm)	/idth (in/cm) Height (in/cm)		Weight (Ibs/Kg)	
	10.5 / 26.7	8.5 / 21.5	15.0 / 38.1	42 / 19	

#### **HF2 Weld Transformer Dimensions**

Model	Height (in/cm)	Width (in/cm)	Depth (in/cm)	Weight (Ibs/Kg)
X2/2000A	7.0 / 17.6	5.4 / 13.8	11.0 / 28.0	14.3 / 6.5
X3/4000A	7.2 / 18.3	7.2 / 18.3	13.4 / 34.0	28.6 / 13
X5/3000A	7.5 / 18.9	7.2 / 18.3	14.2 / 36.0	31 / 14
X11/4000A	7.5 / 18.9	7.2 / 18.3	17.9 / 45.5	46 / 21
X11/4/460A	7.4 / 18.8	7.2 / 18.3	18.9 / 48.5	55 / 25
X3/4/380A	7.2 / 18.3	7.2 / 18.3	13.4 / 34.0	28.6 / 13
X3/4/460A	7.2 / 18.3	7.2 / 18.3	13.4 / 34.0	28.6 / 13

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 2-1

#### Power Line Voltage, Current, and Wire Size Requirements

**WARNING:** The HF2 Weld Control and HF2 Weld Transformer are assembled at the factory for operation at a specific input power line voltage. Serious damage can result if these units are used on different voltage other than the voltage for which they are wired. The HF2 weld transformer input voltage must match the HF2 weld control power line voltage.

Use the following table to select the correct power line circuit breaker and wire gauge size. To minimize peak power losses, use single unbroken wire lines. Note: To minimize peak power losses, Unitek Peco recommended wire gauge sizes exceed the USA National Electrical Code recommendations.

3-Phase Service Voltage (RMS)	3-Phase Service Breaker Current (RMS)	Copper Wire Gauge Size (AWG)
208V to 230V	50A	AWG 8 @ 133 strands
380V to 460V	30A	AWG 10 @ 105 strands

#### Insulation Requirement

Oil-resistant synthetic rubber rated at 90°C and 600V.

#### **Power Line Fuse Requirements**

Service Voltage	Fuse Size: F1, F2	Unitek Peco P/N	
208, 230, 380	3AG, 440 V, 2 A	330-071	
460	3AG, 500 V, 2 A	330-100	

Model	Input Volts (Rms)	Input kva (Rms)	Duty Cycle ( %)	Peak Open Ckt Output Voltage	Peak Output Max. (Amps)	Max Sec Resist. (μΩ)
X3/4/380A	380	9	6	6.5	4,000	500
X3/4/460A	460	9	6	6.5	4,000	500
X3/4000A	230	9	6	6.5	4,000	500
X9/6000A	230	19	6	9.3 (32:1 TR)	4,900	500
X11/4/460A	380	4	5	11.8 (44:1 TR) 10.0 (52:1 TR) 8.6 (60:1 TR) 7.5 (68:1 TR)	4,000 4,000 4,000 4,000	1,300 1,100 950 825
	460	4	5	14.3 (44:1 TR) 12.1 (52:1 TR) 10.5 (60:1 TR) 9.2 (68:1 TR)	4,000 4,000 4,000 4,000	1,300 1,100 950 825
X11/4000A	230	15	5	10.7 10.0 (52:1 TR) 8.6 (60:1 TR) 8.7 8.8 8.9	4,000 4,000 4,000	1,300 1,100

#### **HF2 Weld Transformer Electrical Specifications**

#### TRANSFORMER SPECIFICATION NOTES:

- 1 For the Model X11/4/460A, turns ratios (TR) are selectable by a switch on the transformer rear panel.
- 2 HF2 Weld Control Input voltage selection must be jumpered at E12 on the HF2 Weld PCB as shown in Figure 2-3. E12 is located at the center of the PCB left edge.
- 3 Maximum weld time at Maximum Short Circuit Current is 50 milliseconds.



Figure 2-3. Voltage Jumpers

### **CHAPTER 2: GENERAL SETUP**

#### HF2 Welding System Maximum Secondary Loop Resistance

To use the HF2 Weld Control and HF2 Weld Transformer system to its maximum capability, the Maximum Secondary Loop Resistance must not exceed the values listed in the preceding table. Exceeding these maximums will produce a "FEEDBACK RANGE EXCEEDED" alarm.

#### HF2 Maximum Secondary Loop Resistance Measurement (Figure 2-4)

- 1 Connect a four terminal micro-ohmmeter as shown in Figure 2-4.
- 2 Put the parts to be welded between the electrodes
- 3 Measure the total loop resistance which includes both Weld Cables, Weld Head, Electrodes, and parts.
- If the total loop resistance exceeds the 4 table value. use:
  - A) Larger diameter Weld Cables
  - B) Shorter length Weld Cables, or



#### Figure 2-4. Secondary Resistance Measurement

C) Copper Bus Bars to connect the HF2 Weld Transformer to the Weld Head. If these suggestions do not work, then a different Weld Transformer Model may be required.

**CAUTION:** For product safety, the system power cable and all inter-unit cabling should be as short as possible, and be dressed so that all cables stay separated.

#### HF2 Weld Control to HF2 Weld Transformer Connections (Figure 2-5)

The HF2 Weld Control must always be connected to the HF2 Weld Transformer as shown in Figure 2-5, regardless of what Weld Head System is used.

- Connect the HF2 Weld Control POWER 1 Cable to the line voltage source as specified in *Chapter 2*, *Power Line* Voltage, Current, and Wire Size Requirements.
- 2 Connect the HF2 Weld Control OUTPUT Cable to the matching connector on the HF2 Weld Transformer.
- Connect the HF2 Weld Control SENSING 3 PORT Cable to the matching connector on the HF2 Weld Transformer.



MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 2-4 990-057

#### HF2 Weld Transformer to Weld Head Connections (Figure 2-6)

- 1 Connect the Upper Weld Cable to the Positive Terminal on the HF2 Weld Transformer.
- 2 Connect the Lower Weld Cable to the Negative Terminal on the HF2 Weld Transformer.
- 3 Attach the Voltage Sensing Cable connector to the HF2 Weld Transformer INPUT connector.
- 4 Attach each lead at the opposite end of the Voltage Sensing Cable to each Electrode Holder. Note: Polarity is not important.



# Figure 2-6. HF2 Weld Transformer to Weld Head Connections

- 5 Strain relief each Voltage Sensing lead to its corresponding Electrode Holder so that the lead will not break or move under heavy production operating conditions.
- 6 Do *not* attach the Firing Switch Cable at this time. This procedure is covered in *Chapter 3*.

#### Weld Sentry Option

A small tag displaying the message WELD SENTRY INSTALLED will be attached to the front panel of the HF2 Weld Control if the optional Weld Sentry Module has been installed. Refer to the separate Weld Sentry User's Manual, 990-291 for Weld Sentry operation.

The Built-in Weld Sentry Module can be added to the HF2 Weld Control after purchase by ordering the HF2 Weld Sentry Module, P/N 3-130-01-01.

#### Help Screen Languages

Integrated circuit chip U2 on the Main printed circuit board varies in memory capacity according to the help screen languages available. Refer to *Appendix D* for special jumpering instructions relative to the installation of IC chip U2.

# CHAPTER 3 WELDING SYSTEM SET-UP

### Welding System Set-Up Guide

To complete the welding system installation, select the welding system that best matches your Weld Head configuration using the Welding System Set-Up Guide listed below:

Welding System Set-Up Guide	Page
Unitek Equipment Force Fired, Foot Actuated Weld Head	3-2
Unitek Equipment Force Fired, Single Air Actuated Weld Head	3-4
Unitek Equipment Force Fired, Dual Air Actuated Weld Head	3-9
Non-Force Fired, Single Air or Cam Actuated Weld Head	3-17
Non-Force Fired, Multiple Air Actuated Weld Heads	Not Released

### **General Programming Instructions**

The following nomenclature and symbols will be used for programming the HF2 Weld Control:

- 1 Press and release HF2 Weld Control front panel keys that are enclosed by [] symbols.
- 2 Use the vertical cursor keys [▲▼] in conjunction with the horizontal cursor keys [▲▶] to select or highlight a requested Menu Option, followed by the [ENTER] key.
- 3 Words shown in *UPPER CASE ITALIC* letters indicate *flashing* Menu Options on the HF2 Weld Control LCD Display.

### UNITEK EQUIPMENT FORCE FIRED, FOOT ACTUATED WELD HEAD SYSTEM

#### Weld Head Set-up

- 1 Adjust the Weld Head Force Adjust Knob to produce 5 units of force as displayed on the Force Indicator. For a complete description of force control and its effect on the welding process, please refer to your Weld Head manual.
- 2 Install electrodes in Weld Head Electrode Holders.

#### **Firing Switch Cable Connection**

Connect the Weld Head Firing Switch Cable Connector to the matching cable connector on the rear of the HF2 Weld Control.

#### **Quick Start Programming Guide**

- 1 Set the HF2 Weld Control front panel WELD/NO WELD switch to NO WELD.
- 2 Turn the circuit breaker switch located on the HF2 Weld Control rear panel to ON. After a series of power up screens, the last RUN screen displayed will appear. Press the [CHNG] key to access the Weld Graph RUN screen for the BASIC WELD Function.
- 3 Press [MENU]. The MAIN MENU screen will appear.



Figure 3-1. Firing Switch Cable Connection





- 4 Select TRANSFORMER MODEL. The TRANSFORMER MODEL screen appears.
- 5 Select MULTIPLE HEADS: OFF. If the display reads ON, then press [CHNG] until OFF is displayed.
- 6 Select HEAD 1 : X3/4000-230.
   X3/4000-230 is the default Transformer Model number. Press [CHNG] until the correct Transformer Model that you have purchased appears.

			TRANSFORMER MODEL
MULTI	PLE	H	EADS : OFF
HEAD	1	:	X3/4000-230 46:1 4.0KA
05.01	1		
HEAD	2	:	NONE
HEAD	3	:	NONE
HEAD	4	:	NONE
▲▼se	lec	t,	CHNG Change

- 7 Press [RUN] to return to the Graphical RUN screen.
- 8 Set the HF2 Weld Control front panel WELD/NO WELD switch to WELD.
- 9 Make a test weld by pressing on the Weld Head foot actuator until the HF2 Weld Control fires. The default WELD time of 1 ms and the default CURRENT of 0.5 kA may not be sufficient to make a good weld.
- Press [PROG]. Use the vertical cursor keys [▲▼] to increase the weld CURRENT. Use the horizontal cursor keys [◀▶] to increase or decrease the WELD time. In this example, weld CURRENT has been increased to 0.7 kA and WELD time has been increased to 5ms.

CURREN	T:0 <u>77</u> KA	SCH:00	0 BASIC	WELD : 0005ms	5
0.6					
0.0 ▲▼KA,	<⊳Time,	ENTER N	ext, CH	NG Function	n

- 11 Press [SAVE] to save your program. You are now back in the Weld Graph RUN State.
- 12 Make additional test welds and then reprogram WELD time and weld CURRENT as necessary to make a good weld. Try to use the minimum time and current necessary to make a good weld so that the weld joint heat affected zone will be minimized.
- 13 Up to 128 different weld schedules can be created and saved. To recall any specific weld schedule, press the up or down vertical arrow keys [▲▼] until the desired schedule number appears on the display screen. A faster technique for recalling a specific schedule is to input the Schedule number using the number keys.

### **UNITEK EQUIPMENT FORCE FIRED,** SINGLE AIR ACTUATED WELD HEAD SYSTEM

#### Weld Head Set-up (Figure 3-2)

- Adjust the Weld Head Force Adjust 1 Knob to produce 5 units of force as displayed on the Force Indicator. For a complete description of force control and its effect on the welding process, please refer to your Weld Head manual.
- 2 Install electrodes in Weld Head Electrode Holders
- Connect a properly filtered air line to 3 the Inlet Air Line on the Weld Head Air Valve Driver Solenoid assembly which is located on the back of the Weld Head. Use 0.25 inch O.D. by 0.17 inch I.D. plastic hose with a rated burst pressure of 250 psi. A lubricator should only be used with automated



#### Figure 3-2. Single Air Actuated Weld Head Connections

installations. Turn on the air system and check for leaks.

#### Firing Switch Cable Connection (Figure 3-2)

Connect the Weld Head Firing Switch Cable Connector to the matching cable connector on the rear of the HF2 Weld Control.

#### Weld Head Valve Driver No. 1 Connection (Figure 3-2)

A single air actuated Weld Head has one Solenoid Valve Driver Cable for automatic actuation and timing control by the HF2 Weld Control. The HF2 Weld Control will automatically recognize the solenoid voltage of the Weld Head. Connect the 4 pin black plastic connector on the cable to the matching Air Valve 1 Driver connector located on the HF2 Weld Control rear panel.

#### Foot Switch Connection (Figure 3-2)

- 1 Connect a Model FS1L, 1-Level, or a Model FS2L, 2-Level Foot Switch to the FOOT SWITCH connector located on the HF2 rear panel. The HF2 will automatically recognize which model of Unitek Equipment Foot Switch has been connected.
- 2 1-Level Foot Switch - The l-Level Foot Switch must be fully depressed by the operator. When the Foot Switch closes, the HF2 energizes the Air Actuated Weld Head, causing the Upper Electrode to descend and apply force to the parts. If the Foot Switch is released before the Weld Head applies the Preset Firing Force, the HF2 will automatically return the Upper Electrode to its up position.

3 2-Level Foot Switch - When a 2-Level Foot Switch is pressed to the first level, the HF2 energizes the Air Actuated Weld Head, causing the Upper Electrode to descend and apply force to the parts. If the Foot Switch is released before the operator presses the Foot Switch to the second level, the HF2 will automatically return the Upper Electrode to its up position so that the parts can be repositioned. Once the second level has been reached and the Force Firing Switch in the Weld Head has closed, Weld Current will flow and the HF2 will automatically return the Upper Electrode to its up position.

#### Single Air Regulator Adjustment (Model 80 Series Weld Heads - Figure 3-2)

- 1 Set the HF2 Weld Control front panel WELD/NO WELD switch to NO WELD.
- 2 Turn the Power Switch located on the HF2 Weld Control rear panel to ON. After a series of power up screens, the last RUN screen displayed will appear. Press the [CHNG] key to access the Weld Graph RUN screen for the BASIC WELD function.
- 3 Turn the Air Regulator Clockwise (CW) to produce 10 psi on the Pressure Gauge.
- 4 Press and hold the Foot Switch completely down to close all switch levels. The lower right hand corner of the display should show the status message □ STANDBY □.
- 5 Continuing turning the Air Regulator Clockwise (CW) until the HF2 automatically returns the Upper Electrode to its "up position". The lower right hand corner of the display should now show the status message □ END □ if you have not released the Foot Switch. Release the Foot Switch.
- 6 Note: You have 10 seconds to make the Air Regulator adjustment or a buzzer alarm will sound and the HF2 will automatically return the Upper Electrode to its up position. The status message changes from □ STANDBY □ to □ ALARM FIRING SWITCH □. Press [RUN] to clear the alarm and then repeat steps 4 and 5.







MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 3-5

### CHAPTER 3: WELDING SYSTEM SET-UP

- 7 Adjust the Down Speed Control Knob so the Upper Electrode descends smoothly onto the parts.
- 8 Adjust the Up Speed Control Knob so that the Upper Electrode Holder does not impact upon returning to in "up position".

# Dual Air Regulator Adjustments (Model 180 Series and Model 90 Series Weld Heads - Figure 3-2)

- 1 Turn the Air Regulator located on the right-hand side of the Weld Head Clockwise (CW) to produce 10 psi on the Pressure Gauge.
- 2 Adjust the left-hand side Air Regulator following steps 4, 5, and 6 for the Single Air Regulator Adjustment.
- 3 Re-adjust the right-hand side Air Regulator to produce the same air pressure as finally used on the left-hand side Air Regulator.
- 4 Repeat steps 7 and 8 for the Single Air Regulator Adjustment.

#### **Quick Start Programming Guide**

- 1 Press [MENU]. The MAIN MENU screen will appear.
- 2 Select TRANSFORMER MODEL. The TRANSFORMER MODEL screen appears.
- 3 Select MULTIPLE HEADS: *OFF*. If the display reads ON, then press [CHNG] until OFF is displayed.
- Select HEAD 1 : X3/4000-230.
   X3/4000-230 is the default Transformer Model number. Press [CHNG] until the correct Transformer Model that you k

			TRANSFORMER MODEL
MULTI	IPI	LE	HEADS : OFF
HEAD	1	:	X3/4000-230 46:1 4.0KA 05.0V
HEAD	2	:	NONE
HEAD	3	:	NONE
HEAD	4	:	NONE
▲▼Se	le	ct	:, CHNG Change

the correct Transformer Model that you have purchased appears.

- 5 Press [RUN] to return to the Weld Graph RUN State.
- 6 Set the HF2 Weld Control front panel WELD/NO WELD switch to WELD.
- 7 Make a test weld by pressing on the Weld Head foot actuator until the HF2 Weld Control fires. The default WELD time of 1 ms and the default CURRENT of 0.5 KA may not be sufficient to make a good weld.
- 8 Press [PROG]. Press [ENTER] to change SQUEEZE to WELD, as displayed in the upper right corner. Use the vertical cursor keys [ ] to increase the weld CURRENT. Use the horizontal cursor keys [ ◀▶] to increase or decrease the WELD time. In this example, weld CURRENT has been increased to 0.7 KA and WELD time has been increased to 0.5 ms.

CURREN	Т: 0.7 КА	SCH:0	00 BAS	SIC WE	LD .D : <b>0005</b> m	s
0.8						ĩ
0.6						
0.4						
0.2						L
0.0						
▲▼KA,	<▶Time,	ENTER	Next,	CHNG	Functio	n
	_					

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 3-6 990-057

- 9 Press [SAVE] to save your program. You are now back in the Weld Graph RUN State.
- 10 Make additional test welds and then re-program WELD time and weld CURRENT as necessary to make a good weld. Strive to use minimum time and current necessary to make a good weld so that the weld joint heat affected zone will be minimized.
- 11 Up to 128 different weld schedules can be created and saved. To recall any specific weld schedule, press the up or down vertical arrow keys [▲▼] until the desired schedule number appears on the display screen. A faster technique for recalling a specific schedule is to input the Schedule number using the number keys.

### UNITEK EQUIPMENT FORCE FIRED, DUAL AIR ACTUATED WELD HEAD SYSTEM

#### **General Information**

Dual Air Actuated Weld Head System operation uses sequential action to activate one Weld Head and then a second weld head using a single HF2 Weld Control and HF2 Weld Transformer. The operator must close and release the Foot Switch to initiate each sequential weld. Sequential Weld Head activation ensures that only one weld current path exists at a single point in time. To use multiple Weld Heads simultaneously, refer to *Chapter 3, Non-Force Fired, Multiple Air Actuated Weld Head System*.

### HF2 Weld Control, Jumper Modifications (Figure 3-3)

**Warning:** *Before* modifying jumpers, disconnect the 3-phase input power to the HF2 to prevent serious injury.

- 1 Remove the HF2 Weld Control cover.
- 2 The HF2 Weld Control PCB is located on the right-hand side of the HF2 Weld Control. Locate Jumpers E10 and E11 by looking in the lower right-hand corner of the HF2 Weld Control PCB.
- 3 Using a needle nose pliers, move Jumpers E10 and E11 from the RELAY position to the HEAD2 position.
- 4 Replace the HF2 Weld Control cover.
- 5 Connect 3 phase input power to the HF2.



Figure 3-3. HF2 Jumper Modifications

#### Weld Head Set-up (Figure 3-4)

- 1 Connect the Upper Weld Cable from each Weld Head to the Positive Terminal on the HF2 Weld Transformer.
- 2 Connect the Lower Weld Cable from each Weld Head to the Negative Terminal on the HF2 Weld transformer.
- 3 Adjust each Weld Head Force Adjust Knob to produce 5 units of force as displayed on the Force Indicator. For a complete description of force control and its effect on the welding process, please refer to your Weld Head manual.
- 4 Install electrodes in each Weld Head Electrode Holder.
- 5 Parallel two sets of twisted wire cables to the clip end of the standard Voltage Sensing Cable that is connected to the Weld Transformer front panel. Connect one twisted wire cable to the Left Weld Head electrodes and the other twisted wire cable to the Right Weld Head electrodes.



Figure 3-4. Weld Cable and Air Line Connections for Dual Air Actuated Weld Heads

6 Connect a properly filtered air line to the Inlet Air Line on the Weld Head Air Valve Driver Solenoid assembly which is located on the back of the Weld Head. Use 0.25 inch O.D. by 0.17 inch I.D. plastic hose with a rated burst pressure of 250 psi. Run separate air lines to each Inlet Air Line. Do not split a single 0.25 O.D. line into two lines or the Weld Heads will not have sufficient air flow to work properly. A lubricator should only be used with automated installations. Turn on the air system and check for leaks.

#### Firing Switch Cable Connection (Figure 3-5)

Connect the Weld Head Firing Switch Cable Connector on each Weld Head to the matching connectors on the Model DFS Parallel Switch Box. Connect the Model DFS Firing Switch Cable to the matching cable connector on the rear of the HF2 Weld Control.

#### Weld Head Valve Driver Connections (Figure 3-5)

- 1 Each air actuated Weld Head has one Solenoid Valve Driver Cable for automatic actuation and timing control by the HF2 Weld Control. The HF2 Weld Control will automatically recognize the solenoid voltage of your Weld Head. Connect the 4 pin black plastic connector on the Left Weld Head Solenoid Valve Driver Cable to the matching Air Valve 1 Driver connector located on the HF2 Weld Control rear panel.
- 2 Connect the 4 pin black plastic connector on the Right Weld Head Solenoid Valve Driver Cable to the matching Air Valve 2 Driver connector located on the HF2 Weld Control rear panel.

#### Foot Switch Connection (Figure 3-5)

- 1 Connect a Model FS1L, 1-Level, or a Model FS2L, 2-Level Foot Switch to the FOOT SWITCH connector located on the HF2 rear panel. The HF2 will automatically recognize which model of Unitek Equipment Foot Switch has been connected.
- 2 **1-Level Foot Switch** -- The l-Level Foot Switch must be fully depressed by the operator. When the Foot Switch closes, the HF2 energizes the Air Actuated Weld Head, causing the Upper Electrode to descend and apply force to the parts. If the Foot Switch is released before the Weld Head applies the Preset Firing Force, the HF2 will automatically return the Upper Electrode to its up position.
- **2-Level Foot Switch** -- When a 2-Level Foot Switch is pressed to the first level, the HF2 energizes the Air Actuated Weld Head, causing the Upper Electrode to descend and apply force to the parts. If the Foot Switch is released before the operator presses the Foot Switch to the second level, the HF2 will automatically return the Upper Electrode to its up position so that the parts can be repositioned. Once the second level has been reached and the Force Firing Switch in the Weld Head has closed, Weld Current will flow and the HF2 will automatically return the Upper Electrode to its up position.







- 1 Set the HF2 Weld Control front panel WELD/NO WELD switch to NO WELD.
- 2 Turn the Power Switch located on the HF2 Weld Control rear panel to ON. After a series of power up screens, the last RUN screen displayed will appear. Press the [CHNG] key to access the Weld Graph RUN screen for the BASIC WELD Function.



- 3 Press [MENU]. The MAIN MENU screen will appear.
- 4 Select TRANSFORMER MODEL. The TRANSFORMER MODEL screen appears.
- 5 Select MULTIPLE HEADS: *OFF*. If the display reads ON, press [CHNG] until OFF is displayed.
- 6 Select HEAD 1 : *X3/4000-230*. X3/4000-230 is the default Transformer Model number. Press [CHNG] until the correct Transformer Model that you have purchased appears.
- 7 Press [MENU] to return to the MAIN MENU screen.
- 8 Select OPTIONS. The OPTIONS 1 screen appears.
- 9 Press [▶] to select the OPTIONS 2 screen.
- 10 Select WELD HEAD TYPE: AUTO. Press [CHNG] until the DUAL AIR option appears.
- 11 Press [MENU] to return to the MAIN MENU.

MAI	N MENU
OPTIONS	WELD SENTRY
WELD COUNTER	CALIBRATE HF2
COPY A SCHEDULE	RESET TO DEFAULTS
SYSTEM SECURITY	INSTALLATION
SYSTEM HELP	TRANSFORMER MODEL
<b>▲▲▼▶</b> Select then E	NTER

	TRANSFORMER MODEL
MULTIPLE	HEADS : OFF
HEAD 1 :	K3/4000=230 46:1 4.0KA 05.0V
HEAD 2 :	NONE
HEAD 3 :	NONE
HEAD 4 :	NONE
▲▼Select	, CHNG Change

OPTIONS 1				
POWER UP SCHEDULE	:	AST		
END CYCLE BUZZER	:	OFF		
KEY CLICK	:	ON		
CHAIN SCHEDULES FEATURE	:	OFF		
BASIC WELD MONITOR	:	OFF		
▲▼Select, .LAST, NUMBERS	C	hange,	More	•

OPTIONS 2	2
WELD HEAD TYPE	: NUTO
FOOTSWITCH TYPE	: AUTO
FOOTSWITCH WELD ABORT	: ON
FIRING SWITCH	: 2-WIRE
SWITCH DEBOUNCE TIME	: 10 msec
▲▼Select, CHNG Change,	More Options 🅨

### CHAPTER 3: WELDING SYSTEM SET-UP

- 12 Select COPY A SCHEDULE. The COPY SCHEDULE screen will appear.
- 13 Select the last flashing 0 of TO SCHEDULE [ 0] and use the number keys to change the flashing 0 TO SCHEDULE [ 1].
- 14 Press [ENTER] to complete the schedule copy process and to automatically return to the Weld Graph RUN State.
- 15 Press [MENU] to return to the MAIN MENU.
- 16 Select COPY A SCHEDULE. The COPY SCHEDULE screen will appear.
- 17 Select the last flashing 1 of TO SCHEDULE [ 1] and use the number keys to change the flashing 1 TO SCHEDULE [ 2].
- 18 Press [ENTER] to complete the schedule copy process and to automatically return to the Weld Graph RUN State.
- 19 Press [PROGRAM] twice to select the Alphanumeric PROGRAM screen.
- 20 Press the down vertical cursor key  $[\mathbf{\nabla}]$ until the RELAY 1: NOT USED and RELAY 2: OFF option items appear.

COPY SCHEDULE COPY SCHEDULE [ 1] TO SCHEDULE [ 2] ▲▼Select, NUMBERS Change, ENTER Proceed SCHEDULE: 002 BASIC WELD SYSTEM: AIR AUTO WELD:000000 SQZ WELD HOLD TIME (ms) :0000 0001 0000 CURRENT : 0705 KA AMP • SECONDS LOWER UPPER SENTRY: OFF none none Select, NUMBERS Change SPROGRAM SCHEDULE: 002 BASIC WELD SYSTEM: AIR AUTO WELD:000000 SQZ WELD HOLD

0001

OFF Select, NUMBERS Change PROGRAM

0.05 KA

0000

OFF

21 Select RELAY 1: NOT USED. Press [CHNG] to select the AIR HEAD 2 option.

#### MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 3-13

TIME (ms) :0000

RELAY 1 : NOT USED RELAY 2 : OFF

CURRENT :

COPY SCHEDULE

COPY SCHEDULE [ 0] TO SCHEDULE [ 1]

▲▼Select, NUMBERS Change, ENTER Proceed

- 22 Press [SAVE] to update Schedule 2, then press [CHNG] to automatically return to the Weld Graph RUN State. You are now ready to adjust the Right Weld Head Air Regulators.
- 23 Turn both Air Regulators located on the right-hand side of the Right Weld Head Clockwise (CW) to produce 10 psi on the Pressure Gauge.
- 24 Press and hold the Foot Switch completely down to close all switch levels. The lower right hand corner of the display should show the status message STANDBY.
- 25 Turn the Air Regulator that feeds the Top Right Air Cylinder on the Right Weld Head Clockwise (CW) until the HF2 automatic-ally returns the Upper Electrode to its up position. The lower right hand corner of the display should now show the status message END if you have not released the Foot Switch. Release the Foot Switch.
- 26 NOTE: You have 10 seconds to make the Air Regulator adjustment or a buzzer alarm will sound and the HF2 will automatically return the Upper Electrode to its up position. The status message changes from STANDBY to ALARM FIRING SWITCH. Press [RUN] to clear the alarm, then repeat steps 24 and 25.





STANDBY



27 Re-adjust the Air Regulator that feeds the Bottom Right Air Cylinder on the Right Weld Head to produce the same air pressure as finally used on the Top Air Regulator on the Right Weld Head.

0.0

▲▼Select Schedule

28 Adjust the Right Weld Head Down Speed Control Knob so the Right Weld Head Upper Electrode descends smoothly onto the parts.

- 29 Adjust the Right Weld Head Up Speed Control Knob so that the Right Weld Head Upper Electrode Holder does not impact upon returning to in up position.
- 30 Press [▼] to select SCH:001 BASIC WELD. You are now ready to adjust the Left Weld Head Air Regulators.
- 31 Repeat steps 24 through 29 for the Dual Air Weld Head System, All Regulator Adjustments for the Left Weld Head.

### **Quick Start Programming Guide**

- 1 Make a test weld using Schedule 1 by pressing on the Weld Head foot actuator until the HF2 Weld Control fires. The default WELD time of 1 ms and the default CURRENT of 0.5 KA may not be sufficient to make a good weld.
- 2 Press [PROG]. Press [ENTER] to change SQUEEZE to WELD, as displayed in the upper right corner. Use the vertical cursor keys [▲▼] to increase the weld CURRENT. Use the horizontal cursor keys [▲▶] to increase or decrease the WELD time. In this example, weld CURRENT has been increased to 0.7 KA and WELD time has been increased to 0.5 ms.

CURRENT : DE 7KA	SCH:	001 BA	SIC WI	ELD	
1.0			WE	LD:0005m	S
0.8					1
0.6					
0.2					
0.0					-
▲▼KA, ▲▶Time.	ENTER	Next.	CHNG	Functio	n
_		,			

- 3 Make additional test welds and then re-program WELD time and weld CURRENT as necessary to make a good weld. Try to use the minimum time and current necessary to make a good weld so that the weld joint heat affected zone will be minimized.
- 4 Press [SAVE] to save the updated Schedule 1. You are now back in the Weld Graph RUN State.
- 5 Press [>] to select SCH:002 BASIC WELD. You are now ready to make test welds using the Right Weld Head.
- 6 Repeat steps 1 through 3 using the Right Weld Head.
- 7 Press [SAVE] to save the updated Schedule 2. You are now back in the Weld Graph RUN State and ready to turn on the Chaining Feature, which will enable Schedule 1 to automatically sequence to Schedule 2, then back to Schedule 1.
- 8 Press [MENU] and then select
   OPTIONS. Use the horizontal cursor key [ ◀] to select the OPTIONS 1 screen.
- 9 Select CHAIN SCHEDULES FEATURE: *OFF*. Press [CHNG] to change to *ON*.
- 10 Press [RUN] to return to the Weld Graph RUN State.

OPTIONS 1				
POWER UP SCHEDULE	:	LAST		
END CYCLE BUZZER	:	OFF		
KEY CLICK	:	ON		
CHAIN SCHEDULES FEATURE	:	ON		
BASIC WELD MONITOR	:	OFF		
▲▼Select, .LAST, NUMBERS	C	hange,	More	►
		and a state of the		1

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 3-15

- 11 Press [PROGRAM] twice to select the Alphanumeric PROGRAM screen for Schedule 2.
- 12 Verify that NEXT: 001 is correctly displayed so that Schedule 2 will automatically advance to Schedule 1 after one weld has been completed. If you want to make more than one weld using Schedule 2 before advancing to Schedule 1, change STEP : 00001 to the desired number of welds.

SCHEDULE: 002 SYSTEM: AIR	BASIC W	VELD	NEXT: 001 STEP: 00001
SQZ	WELD	HOLD	
TIME (ms) :0000	0001	0000	
CURRENT :	0.05	KA	
AMP•SECONDS	LOWER	UPPER	SENTRY:
	none	none	OFF
<b>∢</b> ▲♥▶Select,	NUMBERS	Change	PROGRAM

- 13 Press [SAVE] to save the updated Schedule 2.
- 14 Press [ ▼ ] to select SCH:001 BASIC WELD.
- 15 Press [PROGRAM] once to select the Alphanumeric PROGRAM screen for Schedule 1.
- 16 Select NEXT: 001. Change 001 to 002 so that Schedule 1 will automatically advance to Schedule 2 after one weld has been completed. If you want to make more than one weld using Schedule 1 before advancing to Schedule 2, change STEP : 00001 to the desired number of welds.

SCHEDULE: 001 SYSTEM: AIF	BASIC W	VELD	NEXT: 002 STEP: 00001
SQZ	WELD	HOLD	
TIME (ms) :0000	0001	0000	
CURRENT :	0.05	KA	
AMP.SECONDS	LOWER	UPPER	SENTRY:
	none	none	OFF
< <b>▲▼</b> ▶Select,	NUMBERS	Change	PROGRAM

17 Press [SAVE] to save the updated Schedule 1. Press [CHNG] to return to the Weld Graph RUN State. You are now ready to make alternating welds, beginning with Schedule 1, by just pressing on the Foot Switch to activate each weld.

### NON-FORCE FIRED, AIR OR CAM ACTUATED WELD HEAD SYSTEM

#### PLC to HF2 Weld Control Electrical Connections (Figure 3-6)

- 1 Connect your Programmable Logic Control (PLC) or Host Computer output control signals to the HF2 Weld Control inputs using reed relays or the open collector of an opto coupler. The emitter of each opto coupler must be connected to The HF2 Weld Control Rear Panel Control Signals connector, Pin 11.
- 2 For a complete description of how to program Relay 1 and Relay 2, reference *Chapter 5, Programming Modes, Output Relays.*
- 3 For a complete description on how to use the RS-485 Datacom feature, reference *Chapter 9, RS-485 Datacom.*
- 4 All weld schedules must be entered and saved using the HF2 Weld Control Front Panel keys. After saving the desired weld schedules, each schedule can be recalled prior to initiating the welding process cycle by closing the binary Remote Schedule Select lines according to the following table:



#### Figure 3-6. PLC to HF2 Weld Control Electrical Connections

WELD SCHEDULE	20 Pin 1	21 Pin 2	22 Pin 3	23 Pin 4	24 Pin 12	25 Pin 5	26 Pin 14
0	0	0	0	0	0	0	0
1	1	0	0	0	0	0	0
2	0	1	0	0	0	0	0
3	1	1	0	0	0	0	0
4	0	0	1	0	0	0	0
Binary progression from 5 to 126							
127	1	1	1	1	1	1	1

**NOTE:** 0 = Open; 1 = Closed

#### PLC Timing Diagram (Figure 3-7)





#### **Quick Start Programming Guide**

- 1 Set the HF2 Weld Control front panel WELD/NO WELD switch to NO WELD.
- 2 Turn the Power Switch located on the HF2 Weld Control rear panel to ON. After a series of power up screens, the last RUN screen displayed will appear. Press the [CHNG] key to access the Weld Graph RUN screen for the BASIC WELD Function.
- 3 Press [MENU]. The MAIN MENU screen will appear.





MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 3-18 990-057

- 4 Select TRANSFORMER MODEL. The TRANSFORMER MODEL screen appears.
- Select MULTIPLE HEADS: OFF. If 5 the display reads ON, press [CHNG] until OFF is displayed.
- Select HEAD 1 : X3/4000-230. 6 X3/4000-230 is the default Transformer Model number. Press [CHNG] until the correct Transformer Model that you have purchased appears.
- Press [MENU] to return to the MAIN MENU screen. 7
- Select OPTIONS. The OPTIONS 1 or 8 **OPTIONS 2** screen appears. This example shows the OPTION 1 screen.
- 9 Press [  $\triangleleft$  ] to select the OPTIONS 2 screen.
- 10 Select WELD HEAD TYPE: AUTO. Press [CHNG] until the MANUAL option appears. Note: FOOTSWITCH TYPE: AUTO will automatically change to NONE.
- 11 Select FOOTSWITCH WELD ABORT: ON. Press [CHNG] until the OFF option appears.
- 12 12.Press [RUN] to return to the Weld Graph RUN State.

			TRANSFORMER MODEL
MULT	IPI	LE	HEADS : <b>PFF</b>
HEAD	1	:	X3/4000-230 46:1 4.0KA 05.0V
HEAD	2	:	NONE
HEAD	з	:	NONE
HEAD	4	:	NONE
<b>▲▼</b> Se	le	ct	, CHNG Change

OPTIONS I	
POWER UP SCHEDULE	: DAST
END CYCLE BUZZER	: OFF
KEY CLICK	: ON
CHAIN SCHEDULES FEATURE	: OFF
BASIC MONITOR	: OFF
▲▼Select, .LAST, NUMBERS	Change, More 🕨
OPTIONS 2	

ODTTONO 1

OPTIONS	2
WELD HEAD TYPE	: MANUAL
FOOTSWITCH TYPE	: NONE
FOOTSWITCH WELD ABORT	: OFF
FIRING SWITCH	: 2-WIRE
SWITCH DEBOUNCE TIME	: 10 msec
▲▼Select, CHNG Change,	More Options <b>•</b>

- 13 Set the HF2 Weld Control front panel WELD/NO WELD switch to WELD.
- 14 Make a test weld by pressing on the Weld Head foot actuator until the HF2 Weld Control fires. The default WELD time of 1 ms and the default CURRENT of 0.5 KA may not be sufficient to make a good weld.
- 15 Press [PROG]. Use the vertical cursor keys [  $\blacktriangle \nabla$  ] to increase the weld CURRENT. Use the horizontal cursor keys  $[ \triangleleft ]$  to increase or decrease the WELD time. In this example, weld CURRENT has been increased to 0.7 KA and WELD time has been increased to 0.5 ms.

CURRENT: 0.7KA		SCH:000 BASIC			ELD
1.0				WEI	LD:0005ms
0.8					
0.6					
0.4					
0.2					
0.0					
▲▼KA,	<▶Time,	ENTER	Next,	CHING	Function
		tertine and the Const	Andor the Children		

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 3 - 19

### CHAPTER 3: WELDING SYSTEM SET-UP

- 16 Press [SAVE] to save your program. You are now back in the Weld Graph RUN State.
- 17 Make additional test welds and then re-program WELD time and weld CURRENT as necessary to make a good weld. Try to use the minimum time and current necessary to make a good weld so that the weld joint heat affected zone will be minimized.
- 18 Up to 128 different weld schedules can be created and saved. To manually recall any specific weld schedule, press the up or down vertical arrow keys [▲▼] until the desired schedule number appears on the display screen. A faster technique for recalling a specific schedule is to input the Schedule number using the number keys.
- 19 To recall any weld schedule automatically, use the binary Remote Schedule Select Control Lines as discussed under the step 4 of the *PLC to HF2 Weld Control Electrical Connections* section.

### NON-FORCE FIRED, MULTIPLE AIR ACTUATED WELD HEAD SYSTEM

This system configuration is not released.

# CHAPTER 4

#### HF2 Weld Control - Front Panel (Figure 4-1)



Figure 4-1. HF2 Weld Control Front Panel

KEY	DESCRIPTION
[KEYPAD]	Use the numeric keys to enter numeric information. Use the [.] to enter decimal values.
[KEYPAD]	Use the numeric keys to change weld schedules without the need to use the $[\blacktriangle \nabla]$ keys. For example, pressing [1] [0] will recall weld schedule 10.
[▲▼]	In the RUN State, press [ ▲ ] to select a higher number weld schedule or press [ ▼ ] to select a lower number weld schedule.
[▲▼]	In PROGRAM and MENU States, use both [ $\blacktriangle \nabla$ ] to move up and down on the LCD Display to select user options.
[◀▶]	In the PROGRAM and MENU States, use $[\checkmark]$ to select user options.

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 4-1

### CHAPTER 4: CONTROLS

[PROG]	In the RUN State, press [PROG] to enter the Graphical PROGRAM State to make changes to the selected weld schedule fields. Press [PROG] a second time to make changes using the Alphanumeric PROGRAM State. Press [PROG] a third time to make changes to the Weld Sentry programs related to the selected weld schedule. Press [PROG] a fourth time to return to the HF2 Graphical Program screen.
[RUN]	In the PROGRAM State, press [RUN] to exit the PROGRAM State without saving the changed weld schedule. The changed weld schedule will become Weld Schedule 0 and will not be written to permanent memory. Welding parts is done in the RUN State.
[RUN]	In the MENU State, press [RUN] to exit the MENU State and begin welding parts.
[SAVE]	In the PROGRAM State, press [SAVE] to save the selected weld schedule and its related Weld Sentry programs to permanent memory. The HF2 Weld Control will then automatically exit the PROGRAM State and return to the RUN State. [SAVE] has no function in the RUN State.
[MENU]	In either the RUN or PROGRAM States, press [MENU] to provide a menu list of user options which are common to all weld schedules.
[HELP]	Press this key whenever you need HELP or additional information on any user menu option or flashing user programmable field. The HF2 contains a built-in operating manual. Press [HELP] a second time to return to the original State.
[CHNG]	In the PROGRAM State, press [CHNG] to restore the previous contents of a user programmable field.
[CHNG]	In the MENU State, press [CHNG] to select different menu options.
[CHNG]	In the RUN State, press [CHNG] to change the Graphical RUN State screen to the Alphanumeric RUN State screen.
[ENTER]	Press [ENTER] after keying in numeric program data.
WELD/NO WELD SWITCH	Weld current will not flow when this switch is in the NO WELD position. However, operation in the NO WELD switch position permits the HF2 to initiate and execute a complete welding sequence without weld current flowing. Operating the HF2 in the NO WELD position is required to adjust Unitek Peco Weld Heads. This switch must be in the WELD position in order to make a weld.



HF2 Weld Control - Rear Panel Inputs and Outputs

Figure 4-2. HF2 Weld Control Rear Panel

- POWER Refer to *Chapter 2, Power Line Voltage, Current, and Wire Size Requirements,* for complete instructions on how to properly apply power to the HF2 Weld Control.
- FUSES F1, F2 Refer to *Chapter 2, Power Line Fuse Requirements* for complete specifications for Power Line Fuse sizes.
- SENSING PORT

The Sensing Port contains both input and output lines for communicating to the HF2 Weld Transformer and the MA-600 Multiple Weld Head Selection Box. The connector attached to the end of the Sensing Port Cable is a 16 pin Honda, P/N: MC16LSF, (Unitek P/N: 250-235). This connector mates with the connector on the HF2 Weld Transformer.

Pin No.	Wire Color	Description
1	Red	Secondary Weld Current Measurement
2	Red	+12 VDC
3	Red	Secondary Weld Voltage Measurement
4	Red	Weld Transformer Select Line 2 (For MA-600)
5	Red	Weld Transformer Thermo Switch
6	Red	Weld Transformer Select Line 4 (For MA-600)
7	Red	Digital Signal Ground
8	Black	230 VAC Weld Transformer Fan
9	Black	Secondary Weld Current Measurement Return
10	Black	Weld Transformer Select Line 1 (For MA-600)
11	Black	Secondary Weld Voltage Measurement Return
12	Black	Weld Transformer Select Line 3 (For MA-600)
13	Black	Weld Transformer Thermo Switch Return
14	Black	Future Expansion
15	Red	Future Expansion
16	Red	230 VAC Weld Transformer Fan Return

#### **Sensing Port - Connector Pin Assignments**

#### OUTPUT

The Output Cable feeds high voltage, pulse width modulated, primary weld current to the primary winding of the HF2 Weld Transformer. The connector attached to the end of the Output Cable is an AMP 206136-1 (Unitek P/N: 520-115). The mating connector on the HF2 Weld Transformer is an AMP 206137-1 (Unitek P/N: 550-071).

Pin No.	Wire Color	Description
1	Black	Primary HF2 Weld Transformer
2	Red	Primary HF2 Weld Transformer
4	Green	Chassis Ground
6	White	Primary HF2 Weld Transformer Return
7	Orange	Primary HF2 Weld Transformer Return

#### **FOOT SWITCH Connector**

HF2 Weld Control FOOT SWITCH connector uses a 4-pin Amphenol 91-PC4F (Unitek P/N: 550-1-006) bulkhead connector that mates with an Amphenol 91-MC4M (Unitek P/N: 520-1-009).

#### Single-Level Foot Switch (Figure 4-3)

- 1 A Single-Level Foot Switch must be fully depressed by the operator. When the Foot Switch closes, the HF2 Weld Control energizes the Air Actuated Weld Head, causing the Upper Electrode to descend and apply force to the parts. If the Foot Switch is released before the Weld Head applies the Preset Firing Force, the HF2 Weld Control will automatically return the Upper Electrode to its up position.
- 2 Connect a Unitek Model FS1L Foot Switch, reed relay, or the open collector of an opto coupler to the Foot Switch



Figure 4-3. Single-Level Foot Switch

connector to initiate the welding process. The emitter of the opto coupler must be connected to Pin 4.

3 When using a non-Unitek Peco Foot Switch, connect Pin 2 to Pin 3.

#### **Two-Level Foot Switch (Figure 4-4)**

When a Two -Level Foot Switch is pressed to the first level, the HF2 Weld Control energizes the Air Actuated Weld Head, causing the Upper Electrode to descend and apply force to the parts. If the Foot Switch is released before the operator presses the Foot Switch to the second level, the HF2 Weld Control will automatically return the Upper Electrode to its up position so that the parts can be re-positioned. Once the second level has been reached and the Force Firing Switch in the Weld Head has closed, Weld Current will



#### Figure 4-4. Two-Level Foot Switch

flow and the HF2 Weld Control will automatically return the Upper Electrode to its up position.

2 Connect a Unitek Model FS2L Foot Switch, reed relay, or the open collector of an opto coupler to the Foot Switch connector to initiate the welding process. The emitter of the opto coupler must be connected to Pin 4.

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 4-5

#### **Firing Switch Operation**

The HF2 Weld Control can use: (a) a Single Pole, Single Throw Switch (SPST); (b) a Single Pole, Double Throw (SPDT 3-wire) Switch; or (c) an Optical Switch as an input signal to indicate when the Weld Head has applied the proper force to the parts. Weld Heads with single pole Firing Switches should be connected to the Mechanical Firing Switch Connector. A 3-Wire Switch or Optical Firing Switch, either of which should be connected to the Optical Firing Switch Connector, eliminate switch bounce, which causes false triggering, and should be used when the welding speed exceeds 1.5 welds per second.

#### **MECHANICAL FIRING SWITCH Cable**

- The Mechanical Firing Switch Cable is 5 feet long, Type 2/C, 600 volt cable and contains 2 shielded, twisted 22 AWG conductors of high-flex stranded wire. The Firing Switch Connector is a 2-pin Amphenol 80-MC2FI (Unitek P/N: 520-011), with strain relief that mates with an Amphenol 80-MC2M (Unitek P/N: 520-001). Pin 2 is Digital Ground.
- 2 Connect a Unitek Model Weld Head Firing Switch, reed relay, or the open collector of an opto coupler to the Foot Switch connector to initiate weld



Figure 4-5. Mechanical Firing Switch

current. The emitter of the opto coupler must be connected to Digital Ground, Pin 2.

#### **OPTICAL FIRING SWITCH Connector**

The Optical Firing Switch Connector is a 5 pin AMP 212044-1 (Unitek P/N: 550-064) bulkhead connector and mates with an AMP Assembly consisting of an AMP 212437-3 Plug, 212435-7 Ferrule and 212800-1 Strain Relief. The Optical Firing Switch can be used in two configurations for initiating a welding process: a) Single Pole Double Throw (SPDT 3-wire); or b) Opto Coupler.

# Mechanical Firing Switch - 3-Wire Connection



Figure 4-6. Wire Firing Switch

A SPDT (3-wire) mechanical switch can be

connected to the Optical Firing Switch connector

to eliminate the use of Switch Debounce Time when welding at rates of 1.5 welds/second.

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 4-6 990-057

#### **Opto Coupler Firing Switch - 3-Wire Connection**

A SPDT opto coupler switch can be connected to the Optical Firing Switch connector to eliminate the use of Switch Debounce Time when welding at rates of greater than 1.5 welds/second.

#### **CONTROL SIGNALS Connector**

- A 15-pin, sub-miniature "D" Control Signals Connector includes inputs for:

   (a) Remotely selecting weld schedules 1
   through 127;
   (b) Inhibiting the HF2
   Weld Control from beginning a new
   welding process; and (c) Invoking an
   Emergency Stop Condition which abruptly terminates the welding process.
   The Control Signals inputs and outputs are designed to be used with a Programmable Logic Control (PLC) (see Figure 4-8) or a Host
   Computer in automated environments.
- 2 When an external chain control box is connected to the Control Signals Connector in place of a PLC, chained weld schedules can be implemented semiautomatically with an external chain control box (see Figure 4-9).
- 3 The Control Signals Connector also includes outputs for: a) One DC Solid State Relay; and b) One AC Solid State Relay.
- 4 The 15 pin connector is a Viking DMRST15RA05CG (Unitek P/N: 250-1-195). The mating connector is a TRW Cinch Connector comprised of a DA-15P (Unitek P/N: 250-1-199) male connector and a DE-51210-1 (Unitek P/N: 250-1-200) plastic junction shell. The mating connector is included in the HF2 Weld Control Shipping Kit.







Figure 4-8. Control Signals Connection



Figure 4-9. Remote Chain Control Box Input/Output Signals

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 4-7 5 Connect a reed relay, or the open collector of an opto coupler to the Control Signals connector to initiate the selection process. The emitter of the opto coupler must be connected to Pin 11. Keep the selected input closed to maintain the selection.

Control	Signals	- Pin	Assignments
---------	---------	-------	-------------

Pin No.	I/O	Description	
1	Input	PLC input: Remote Weld Schedule Selection, Control Line 20	
		Chain control box (CCB) input: Schedule Down (decrement number)	
2	Input	PLC input: Remote Weld Schedule Selection, Control Line 21	
		CCB input: Schedule Up (increment number)	
3	Input	PLC input: Remote Weld Schedule Selection, Control Line 22	
		CCB input: Reset (set schedule # to power up schedule #)	
4	Input	PLC input: Remote Weld Schedule Selection, Control Line 23	
		CCB input: Auto/Manual (enable/disable chain function)	
5	Input	Remote Weld Schedule Selection, Control Line 25	
6	Out-put	Relay K2, + 5-50 VDC (User must supply power)	
7	NC		
8	Out-put	Relay K1, 24-115 VAC (User must supply power)	
9	Input	Process Inhibit	
10	Input	Emergency Stop	
11	Input	Circuit Ground	
12	Input	Remote Weld Schedule Selection, Control Line 24	
13	Out-put	Relay K2, + 5-50 VDC Return	
14	Input	Remote Weld Schedule Selection, Control Line 26	
15	Out-put	Relay K1, 24-115 VAC Return	

#### **Control Signals - Remote Weld Schedule Selection Input**

All weld schedules must be entered and saved using the HF2 Weld Control Front Panel keys. After saving the desired weld schedules, each schedule can be recalled prior to initiating the welding process cycle. Using the PLC (Figure 4-8), remote weld schedule selection (chain schedule feature turned off) can be implemented by closing the binary Remote Schedule Select lines according to the following table:

WELD SCHED	2 <sup>⁰</sup> Pin 1	2 <sup>1</sup> Pin 2	2 <sup>2</sup> Pin 3	2 <sup>3</sup> Pin 4	2 <sup>4</sup> Pin 12	2⁵ Pin 5	2 <sup>6</sup> Pin 14
0	0	0	0	0	0	0	0
1	1	0	0	0	0	0	0
2	0	1	0	0	0	0	0
Binary progression from 3 to 126							
127	1	1	1	1	1	1	1

**NOTE:** 0 = Open; 1 = Closed

Using a remote chain control box in place of the PLC, a semi-automatic chain weld schedule can be used to control the remote schedule select lines through the Control Signals Connector in accordance with the following table:

Pin No.	Function	Description	
1	Schedule Down	Decrement the schedule number	
2	Schedule Up	Increment the schedule number	
3	Reset	Set the schedule number = power up schedule number	
4	Auto/Manual	Enable (Auto)/disable (Manual) the chain schedule function	

**Note:** If (Manual) is selected on pin 4, the chain control box will override the HF2 chain schedule on/off function and weld schedules can be selected manually from the chain control box (see Figure 4-9).

#### Control Signals - Emergency Stop Input (Figure 4-8)

Connect a reed relay, or the open collector of an opto coupler to Pin 10 of the Control Signals connector to immediately terminate the welding process. No welding process can be initiated until the switch closure has been removed. The emitter of the opto coupler must be connected to Pin 11.

#### Control Signals - Process Inhibit Input (Figure 4-8)

Connect a reed relay, or the open collector of an opto coupler to Pin 9 of the Control Signals connector to prevent a new welding process from beginning. No welding process can be initiated until the switch closure has been removed. The emitter of the opto coupler must be connected to Pin 11.

#### Control Signals - Output Relays (Figure 4-8)

There are two output relays which can be used to provide status or timing signals to a user Programmable Logic Control (PLC) or Host Computer. Relay K1 can switch a 24 to 115 VAC signal. Relay K2 can switch a 5 to 50 VDC signal. When used for status signals, these relays can be independently programmed to close (a) when the HF2 Weld Control is initiated; (b) when any portion of the welding process is completed; (c) when the Firing Switch opens; or (d) when the HF2 Weld Control is waiting for the welding process sequence to start.

#### Relay K1 (Figure 4-10)

- Connect a 24 to 115 VAC voltage source and PLC load to Pins 8 and 15 on the Control Signals Connector. Maximum relay current is limited to 250 ma.
- 2 Relay K1 is also used to control the Air Valve 2 Driver for sequentially activating a second Air Actuated Weld Head. Refer to *Chapter 3, Unitek Peco, Force Fired, Dual Air Actuated Weld Head System* for complete instructions to set up and operate two sequential action Air



Figure 4-10. Relay K and K2 Connections

Actuated Weld Heads. When MENU, OPTIONS 2, WELD HEAD TYPE: is set to DUAL AIR, the options for RELAY 1 must be either AIR HEAD 2 or NOT USED. Air Valve 2 Driver will be actuated in any Schedule in which RELAY 1 is defined as AIR HEAD 2. Air Valve 1 Driver is actuated in any Schedule in which RELAY 1 is defined as NOT USED.

#### Relay K2 (Figure 4-10)

Connect a 5 to 50 VDC voltage source and PLC load to Pins 6 (Positive) and 13 (Negative) on the Control Signals Connector. Maximum relay current is limited to 250 ma.

#### Accessory Port (Figure 4-2)

A 25-pin, sub-miniature D-type connector, located on the rear panel, is provided to control other devices contemplated for future expansion.

#### AIR VALVE 1 and AIR VALVE 2 Driver Connectors (Figure 4-11 and Figure 4-12)

#### Air Valve 1 Driver (Figures 4-11 and 4-12)

Each Air Valve Driver uses a 4-pin black plastic AMP 206430-1 (Unitek P/N: 550-062) bulkhead connector. The mating plug is an AMP 206429-1 (Unitek P/N: 520-107) which uses a cable clamp, Amp 206358-2 (Unitek P/N: 245-084) and 3 male pins AMP 66361-2 (Unitek P/N: 253-055). When using a non-Unitek Peco Air Actuated Weld Head, connect Pin 2 to Pin 4. The HF2 Weld Control can sequentially operate two separate Air Actuated Weld Heads using Air Valve 1 Driver and Air Valve 2 Driver outputs.

#### Air Valve 1 Driver (Figures 4-11 and 4-12)

The output of Air Valve 1 Driver is 12 VA at 115 or 24 volts VAC. The HF2 Weld Control automatically applies the correct solenoid voltage to the Air Actuated Weld Head connected to the Air Valve 1 Driver.

#### Air Valve 2 Driver (Figure 4-12)

Air Valve 2 Driver provides 24 VAC at 12 VA to power a second Air Actuated Weld Head. To provide 24 VAC to Air Valve 2 Driver, jumpers E10 and E11 on the control board must be moved to the correct positions. Refer to *Chapter 3. Unitek Peco, Force Fired, Dual Air* 









Actuated Weld Head System for complete instructions to set up and operate two sequential action Air Actuated Weld Heads. Note: When Air Valve 2 Driver is used, Relay K1 cannot be used for marking weld periods or activating alarm conditions.

# CHAPTER 5 PROGRAMMING MODES

### **Help Screens**

**NOTE:** We offer our non-English speaking users help screens written in various languages (refer to *Appendix D*). For further information, please contact the factory.

- The HF2 Weld Control offers the user context sensitive HELP when running or programming. Press [HELP] whenever you want information about a Menu Option or program variable. Press [HELP] again to return to the original screen. For example, if you press [HELP] from the RUN State, information on the function of the Weld Graph and Alphanumeric screens will appear.
- 2 To read the second page of help information, press the right horizontal cursor key [▶].





3 To return to the first page of help information, press the left horizontal cursor key [ $\blacktriangleleft$ ].

#### **Machine States**

The HF2 Weld Control has eight Machine States: RUN, NO WELD, STANDBY, ALARM, FIRE, MENU, PROGRAM, and HELP. The NO WELD State represents the positional status of the WELD/NO Switch on the front panel. The STANDBY, ALARM, and FIRE states are functions of MECHANICAL FIRING, OPTICAL FIRING, and FOOT SWITCH input states. The operator can force the HF2 Weld Control into the RUN, MENU, PROGRAM, and HELP states by pressing the [RUN], [MENU], [PROG] or [HELP] keys.

#### Weld Graph RUN State

In the Weld Graph RUN State, the HF2 Weld Control is ready to make a weld. You can select, but not change, any weld schedule by using the vertical cursor keys [ $\blacktriangle$ ] or [ $\checkmark$ ] on the Front Panel. Weld schedules may also be selected by using the numeric keypad to key in the desired weld schedule number: 000 through 127.

CURRENT	SCH:000	BASIC	WELD	
1.0				
0.8				
0.6				
0.4				
0.2				
0.0				
▲▼Select Sc	hedule			
-				

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 5-1

#### **Basic Weld Monitor Run State**

When MENU, OPTIONS 1, WELD MONITOR: is set to BASIC, pressing [CHNG] will cause the display screen to switch from the Weld Graph RUN screen to the Basic Weld Monitor RUN screen. Setting WELD MONITOR to LIMIT causes the Energy Limit Monitor screen to be displayed. See *Chapter 7* and *Chapter 8* for detailed instructions.

BASIC WE	LD MONITO	OR
SCHEDULE:000	WELD1	
MEASUREMENT :	CURRENT	
UPPER LIMIT:	none KA	Α
READING:	n/a KA	A
LOWER LIMIT:	none KA	A
INHIBIT WELD POWER:	OFF	
▲▼ Select Schedule		■ R U N ■

Pressing [CHNG] again causes the Basic Weld Monitor RUN screen to switch to the Alphanumeric RUN screen. Pressing [CHNG] once more returns the display screen to the Weld Graph RUN screen.

#### Alphanumeric RUN State

Pressing [CHNG] will cause the display screen to change from the Basic Weld Monitor RUN screen, if this option has been set to ON, to the Alphanumeric RUN screen. Pressing [CHNG] again will return the HF2 Weld Control to the Weld Graph screen. Welding can be performed in any RUN screen.

#### **NO WELD State**

Switching the WELD/NO WELD front panel switch to the NO WELD position prevents weld current from flowing but does permit the HF2 Weld Control to performing its electronic functions. Use the NO WELD State when adjusting the air regulators on Air Actuated Weld Heads.

#### **STANDBY State**

The HF2 Weld Control is waiting for a mandatory event to occur such as: (a) the Firing Switch in a Unitek Peco Air Actuated Weld Head to close; (b) the second level of a 2-Level Foot Switch to close; or (c) waiting to be reset to another schedule after a STOP Command in a Chained Schedule.

SCHEDULE: 000	BASIC I	WELD	
SYSTEM: AIR	AUTO		WELD:000000
SQZ	WELD	HOLD	
TIME (ms) :0000	0001	0000	
CURRENT :	0.05	KA	2.
AMP•SECONDS	LOWER	UPPER	SENTRY:
	none	none	OFF
▲▼ Select Sch	edule		■ R U N ■



**MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY** 5-2 990-057

#### **ALARM State**

The HF2 Weld Control automatically recognizes many alarm conditions which are described in detail under *Appendix C, Alarm Messages*. The ALARM FIRING SWITCH screen shown on the right is displayed when the Firing Switch of a Unitek Peco Air Actuated Weld Head does not close within 10 seconds.

#### **FIRE State**

Once weld current is flowing, the HF2 Weld Control is in the Fire State. Weld current can be terminated by: (a) removing the first level of a single-level Foot Switch; (b) removing the second level of a two-level Foot Switch; or (c) shorting the Emergency Stop Control Signals Input Pin 10 to Pin 11. Completion of the Firing State is indicated by momentary appearance of the END status message as shown in the example to the right.

#### **MENU State**

Pressing [MENU] puts the HF2 Weld Control in the MENU State, which offers you different options common to all weld schedules such as how the HF2 Weld Control interfaces with the Firing Switch, Foot Switch, and Weld Head. Like a tree with many branches, there are multiple Menu levels. Each new level is accessed by making an option selection, then pressing [ENTER]. To return to a previous Menu level, press [MENU]. For a complete description on Menu Options, refer to *Chapter 7*, *System Options*.







#### **PROGRAM State**

- 1 In the PROGRAM State, the HF2 Weld Control allows the user to change and save any weld schedule. In those units which include the Weld Sentry Option, the PROGRAM State also allows the user to change the Measurement Unit, the Limits related to each Weld Sentry program, as well as the other parameters associated with the Weld Sentry.
- 2 A single weld schedule uses one Weld Function. A Weld Function is defined as a series of user programmable time periods, some of which have programmable weld current, voltage, or power levels. Some periods such as SQUEEZE, COOL, QUENCH, HOLD, and OFF do not have any weld current values associated with them. For a complete description of all Weld Functions, their time periods, and limit values, refer to *Chapter 6, Advanced Welding Functions*.
- 3 SQUEEZE Time is automatically included as a weld schedule program variable when MENU OPTIONS 2, WELD HEAD TYPE: is set to AUTO, AIR, or DUAL AIR and an Air Actuated Weld Head is connected to the HF2 Weld Control. Squeeze Time allows sufficient time for a non-force fired Weld Head to apply the required weld force to the work pieces. Squeeze Time is not normally used with Unitek Peco force fired Weld Heads. The weld period will start as soon as the Squeeze Time expires. Squeeze Time can be set to any number between 0 and 2000 ms.

**NOTE:** There are two methods of programming the HF2 Weld Control: (a) use the Weld Graph PROGRAM State; or (b) use the Alphanumeric PROGRAM State.

#### Weld Graph PROGRAM State

- Use the vertical cursor keys [▲▼] to select the weld schedule that you want to modify. Press [PROG] to enter the Weld Graph PROGRAM State.
- Press [ENTER] to select the period that you want to modify. Note: the upper right-hand corner shows the selected period. Use the horizontal cursor keys [ ◄►] to increase or decrease the period time base which is also

CURREN	T: [NONE]	SCH:0	00 BA	SIC WE	ELD
1.0			1	SQUEE2	E:0000ms
0.8					
0.6					
0.4					
0.2					
0.0					
▲ <b>▼</b> KA,	<▶Time,	ENTER	Next,	CHING	Function

displayed in the upper right-hand corner following the selected period. You can also change the period time base by using the keypad to directly enter the exact time. Periods such as SQUEEZE, COOL, QUENCH, HOLD, and OFF do not have any weld current, voltage, or energy values. This example shows an Air Actuated Weld Head schedule with the SQUEEZE period set to 0000 ms.

- 3 Periods such as WELD, WELD1, WELD2, and TEMPER have user programmable time base values and weld current, voltage, or energy values. To change the Feedback Type for any of these weld periods, press the keypad decimal point [.] multiple times until the upper left-hand portion of the screen shows the desired Feedback Type. This example shows a WELD period of 15 ms with the weld CURRENT set to 0.5 kA.
- 4 To change the weld current, use the vertical cursor keys [▲▼] to increase or decrease the weld CURRENT. Note: when holding the vertical cursor keys down to change the weld CURRENT, the horizontal bar representing the weld CURRENT will not move to its new position until the vertical cursor keys





[ ◀▶ ] are released. However, the weld CURRENT value displayed in the upper left-hand corner will automatically scroll during this change process. In this example, weld CURRENT has been increased to 0.7 kA and WELD time has been increased to 20 ms.

5 Press [SAVE] to save the updated weld schedule. You are now back in the Weld Graph RUN State.

#### Alphanumeric PROGRAM State

- 1 Use the vertical cursor keys [▲▼] to select the weld schedule that you want to modify. From the Weld Graph RUN State or Basic Weld Monitor RUN State, press [PROG] multiple times to enter the Alphanumeric PROGRAM State. If you are already in the Alphanumeric PROGRAM State, press [PROG] once.
- 2 Use the vertical cursor keys [▲▼] and horizontal cursor keys [▲▶] to select the program value that you want to change. Use [CHNG] to select CURRENT, VOLTAGE or POWER Feedback. Use the numeric keypad to enter variable values. This example shows the alpha-numeric version of weld schedule 000 in the middle of this

000	BASIC	WELD	
AIR	AUTO		WELD:000000
SQZ	WELD	HOLD	
0000	0020	0000	
:	0.70	KA	
1DS	LOWER	UPPER	SENTRY :
	none	none	OFF
ect,	NUMBERS	Change	PROGRAM
	000 AIR SQZ 00000 IDS	000 BASIC AIR AUTO SQZ WELD 0000 0020 0.70 IDS LOWER none	000 BASIC WELD AIR AUTO SQZ WELD HOLD 0000 0020 0000 0.70 KA IDS LOWER UPPER none none ect, NUMBERS Change

page. Weld CURRENT is set to 0.7 kA and WELD time to 20 ms.

3 Press [SAVE] to save the updated weld schedule.

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 5-5

### CHAPTER 5: PROGRAMMING MODES

4 Press [CHNG] To operate the HF2 Weld Control in the Weld Graph State.

#### **Output Relays**

The HF2 Weld Control has two solid state relays which can be used to provide status or timing signals to a user Programmable Logic Control (PLC). For a full description on how to connect Relay K1 and Relay K2, refer to *Chapter 4, Control Signals, Output Relays*.

- 1 Relay K1 and Relay K2 can only be programmed in the Alphanumeric PROGRAM State.
- 2 Use the vertical cursor keys [▲▼] to select the weld schedule that you want to modify. From the Weld Graph RUN State or Basic Weld Monitor RUN State, press [PROG] multiple times to enter the Alphanumeric PROGRAM State. If you are already in the Alphanumeric PROGRAM State, press [PROG] once.

-----

- 3 Press [▼] until the RELAY 1 and RELAY 2 legends are displayed. Both relays can be activated in the SQUEEZE, WELD, and HOLD periods. Press [CHNG] to select ON. In this example, RELAY 1 will turn on during the WELD period.
- 4 There are four more RELAY 1 options listed under the SQZ period column. Press [CHNG] to select the RUN STATE option. In this example, notice that the RELAY 1 options for the WELD and HOLD periods disappear. Selecting the RUN STATE option will cause RELAY 1 to always be on when the HF2 is not making a weld.
- 5 Press [CHNG] until the ALARM (NO) option appears. An ALARM condition causes RELAY 1 to switch from the normally open (NO) state to the closed state. RELAY 1 automatically opens when the alarm condition is cleared by pressing [RUN] or when the next welding sequence begins.
- 6 Press [CHNG] until the ALARM (NC) option appears. An alarm condition causes RELAY 1 to switch. An alarm

SYSTEM: A	IR AUTO	1/53	WELD:000000
S	QZ WELD	HOLD	
TIME (ms) :00	00 0020	0000	
CURRENT :	0.70	KA	
RELAY 1 : O	FF ON	OFF	
RELAY 2 : O	FF OFF	OFF	
4476.3		-	_
Select	, NUMBERS	Change	PROGRAM
		10	
SCUEDILE. O	OO BASTO	UPI D	<u>*</u>
SCHEDULE: 0	UU DADIC I		
CVOTEM. A			WET D. 0000000
SYSTEM: A	IR AUTO		WELD:000000
SYSTEM: A	IR AUTO QZ WELD	HOLD	WELD:000000
SYSTEM: A S TIME(ms):00	IR AUTO QZ MWELD 00 0020	HOLD	WELD:000000
SYSTEM: A TIME (ms):00 CURRENT :	IR AUTO QZ WELD 00 0020 0.70	HOLD 0000 KA	WELD:000000
SYSTEM: A S TIME(ms):00 CURRENT : RELAY 1 : E	IR AUTO QZ WELD 00 0020 0.70 UN*STATE	HOLD 0000 KA	WELD:000000
SYSTEM: A S TIME(ms):00 CURRENT : RELAY 1 : R RELAY 2 : 0	IR AUTO QZ WELD 00 0020 0.70 UNSTATE FF OFF	HOLD 0000 KA OFF	WELD:000000
SYSTEM: A S TIME (ms):00 CURRENT : RELAY 1 : R RELAY 2 : O	IR AUTO QZ WELD 00 0020 0.70 UN*STATE FF OFF	HOLD 0000 KA OFF Change	WELD:000000
SYSTEM: A STIME(ms):00 CURRENT : RELAY 1 : R RELAY 2 : O	IR AUTO QZ WELD 00 0020 0.70 UN*STATE FF OFF , NUMBERS	HOLD 0000 KA OFF Change	WELD:000000
SYSTEM: A S TIME(ms):00 CURRENT : RELAY 1 : R RELAY 2 : O ◀▲♥▶Select	IR AUTO QZ WELD 00 0020 0.70 UN STATE FF OFF , NUMBERS	HOLD 0000 KA OFF Change	WELD:000000
SYSTEM: A STIME(ms):00 CURRENT : RELAY 1 : R RELAY 2 : O	IR AUTO QZ WELD 00 0020 0.70 UN*STATE FF OFF , NUMBERS	HOLD 0000 KA OFF Change	WELD:000000

-----

...



condition causes RELAY 1 to switch from the normally closed state (NC) to the normally open state. RELAY 1 automatically closes when the alarm condition is cleared by pressing [RUN] or when the next welding sequence begins.

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 5-6 990-057 7 Press (CHNG] until the END PROCESS option appears. RELAY 1 automatically turns ON for a period of 20 msec after the last TIME period.

#### **RELAY 1 - Dual Air Head Operation**

1 RELAY 1 has one additional option not shared with RELAY 2. RELAY 1 is also used to control the Air Valve 2 Driver for sequentially activating a second Air Actuated Weld Head. Refer to *Chapter 3, Unitek Peco, Force Fired, Dual Air Actuated Weld Head System* for complete instructions to set up and operate two sequential action Air Actuated Weld Heads.



- 2 When MENU OPTIONS 2, WELD HEAD TYPE: is set to 'DUAL AIR", the options for RELAY 1 must be either AIR HEAD 2 or NOT USED. Air Valve 2 Driver will be actuated in any Schedule in which RELAY 1 is defined as AIR HEAD 2. Air Valve 1 Driver is actuated in any Schedule in which RELAY 1 is defined as NOT USED. This example shows RELAY 1 set to turn on AIR HEAD 2.
- 3 Press [SAVE] to save the updated weld schedule.
- 4 Press [CHNG] to operate the HF2 Weld Control in the Weld Graph State.

# CHAPTER 6 ADVANCED WELD FUNCTIONS

### **Weld Functions**

A weld function is a unique heat profile created by weld current, voltage, or power that is applied over a fixed time period, to resistance weld different parts. Welding applications requiring the use of specialized weld functions include: (a) parts plated with cadmium, tin, zinc, or nickel; b) parts with heavy oxide coatings such as aluminum; (c) parts that are round or not flat; or (d) parts made of refractory metals such as molybdenum or tungsten.

The HF2 Weld Control is shipped with ten pre-programmed weld functions that are saved in Weld Schedules 001 through 010. While these factory pre-programmed weld functions do not contain sufficient weld time or weld energy for most welding applications, they are a useful starting point to begin welding. Please note that WELD/REPEAT will only work with Air Actuated Weld Heads. The table below lists each Weld Function and its general application.

Weld Function	Pre-Prog Schedule	Typical Application	
BASIC WELD	001	Make single spot welds on simple flat parts without plating.	
WELD/REPEAT	002	Make multiple semi-automatic spot welds using an operator.	
QUENCH/TEMPER	003	Spot weld flat or round parts that have minimum plating thickness.	
PRE/POSTHEAT	004	Forge weld heavily oxidized or refractory parts such as molybdenum or tungsten.	
UP/DOWNSLOPE	005	Weld round parts, parts that are not flat, spring steel parts, or heavily plated or oxidized parts such as aluminum.	
BRAZE	006	Reflow two parts together using a braze material.	
ROLLSPOT	007	Make automated multiple weld spots using automatic feeders and PLC or host computer.	
SEAM	008	Make automated hermetic seam welds using automatic feeders, and PLC or host computer control. Make manual or semi-automatic non-hermetic seam welds using an operator.	
DUAL PULSE	009	Use for best control of miniature and small parts spot welding with or without plating.	
PULSATION	010	Use only for spot welding simple parts where the total weld energy or weld time required to make an acceptable weld using any other Weld Function is marginal. Using the Pulsation Weld Function can damage the crystal structure of the parts.	

#### BASIC WELD (Figure 6-1)

Basic Weld is a term used by the industry to describe the simplest heat profile used in the majority of resistance spot welding applications. Use Basic Weld to make single spot welds on flat parts that do not have any plating or heavy oxides. Basic Weld can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.



Figure 6-1. Basic Weld

When Basic Weld is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Basic Weld is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens.

# Basic Weld - Weld Graph Run Screen (Figure 6-2)

Weld Schedule 001 is pre-programmed at the factory for Basic Weld operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

# Basic Weld - Alphanumeric Run Screen (Figure 6-3)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.



MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 6-2 990-057

#### WELD/REPEAT (Figure 6-4)

Weld/Repeat provides a repeat capability for simple automated Air Actuated Weld Head applications using an operator. This weld function is ideal for volume production, which requires a single schedule.

Weld/Repeat can only be used with an Air Actuated Weld Head. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.



Figure 6-4. Weld/Repeat

When Weld/Repeat is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Weld/Repeat is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens. Off Period, which is applicable only to Weld/Repeat, sets the cycling rate between spot welds by controlling how long the electrodes remain open to allow the parts to be repositioned before the entire weld process repeats.

# Weld/Repeat Weld Graph Run Screen (Figure 6-5)

Weld schedule 002 is pre-programmed at the factory for Weld/Repeat operation and will only function using an Air Actuated Weld Head.



# Weld/Repeat Alphanumeric Run Screen (Figure 6-6)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.

QUENCH/TEMPER (	(Figure 6-7)
-----------------	--------------

Quench/Temper is typically used to weld flat-toflat, round-to-round, or round-to-flat parts together that are plated. Properly used, Quench/Temper can significantly reduce weld splash and electrode sticking.

In the normal application of Quench/Temper, the Weld Period provides sufficient heat to displace the plating or oxides, seat the electrodes against the base metals, and force the parts into intimate contact. The Quench Period allows time to dissipate the heat generated during the Weld Period. The Temper Period completes the structural weld. The Temper Period weld

and the second	CONTRACTOR VICE	Service Mar	
SCHEDULE: 002	WELD/RI	EPEAT	
SYSTEM: AIR	AUTO		WELD:0000000
SQZ	WELD	HOLD	OFF RPT
TIME(ms):0000	0001	0000	1000
CURRENT :	0.50	KA	
AMP · SECONDS	LOWER	UPPER	SENTRY:
	none	none	OFF
▲▼ Select Sch	nedule		

Figure 6-6. Weld/Repeat Alphanumeric Screen.



#### Figure 6-7. Quench/Temper

current should be greater than the Weld Period weld current by a factor of two or three since the first bond significantly reduces the resistance of the interface between the parts.

Another use for Quench/Temper is to control grain refinement in the parts. In this application, the Weld Period weld current makes the structural weld. The parts cool during the Quench Period. The low level Temper Period weld current completes the heat treating process by providing sufficient heat to permit grain realignment. In this application, the weld current magnitudes for both the Weld and Temper Periods are completely opposite to those shown in Figure 6-7. 410 stainless steel is one of the materials which must be heat treated (annealed) in order to eliminate the brittle, crystalline structure caused by the weld current. This application of Quench/Temper is not usually used in the form just described for welding small parts.

Quench/Temper can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes. When Quench/Temper is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Quench/Temper is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens.

# Quench/Temper - Weld Graph Run Screen (Figure 6-8)

Weld schedule 003 is pre-programmed at the factory for Quench/Temper operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

#### Quench/Temper - Alphanumeric Run Screen (Figure 6-9)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.

### PRE/POSTHEAT (Figure 6-10)

Pre/Postheat is very similar to Quench/Temper. Pre/Postheat is also typically used to weld flat-toflat, round-to-round, or round-to-flat parts together that may or may not be plated. In addition, Pre/ Postheat works well to create forge type welds when welding refractory materials such as molybdenum and tungsten together. Pre/ Postheat is the most versatile of all of the weld functions. The user can construct a custom weld function by controlling the three Periods, Preheat,

Weld, and Postheat and their related weld currents.



#### Figure 6-8. Quench/Temper -Weld Graph Run Screen

SCHEDULE: 003	QUENCH	TEMPER		
SYSTEM: AIR	AUTO		WELD:00	00000
SQZ	WELD	QUENCH	TEMP	HOLD
TIME(ms):0000	0001	0001	0001	0000
CURRENT :	0.20	KA	0.50	KA
AMP · SECONDS	LOWER	UPPER	SENTRY:	
	none	none	OFF	
▲▼ Select Sch	nedule		R	UN
				1

Figure 6-9. Quench/Temper - Alphanumeric Screen





MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 990-057 6-5

### **CHAPTER 6: ADVANCED WELD FUNCTIONS**

Weld Periods not required can be set to zero. Properly used, Pre/Postheat can significantly reduce weld splash and electrode sticking.

In the normal application of Pre/Postheat, the Preheat Period provides sufficient heat to displace the plating or oxides, seat the electrodes against the base metals, and force the parts into intimate contact. The Preheat Period should be two or three times longer than the Weld Period, which completes the structural weld. The Weld Period weld current should be greater than the Preheat Period weld current by a factor of two or three since the first bond significantly reduces the resistance of the interface between the parts. The Postheat Period immediately follows to provide grain refinement in the parts.

Pre/Postheat can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.

When Pre/Postheat is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Pre/Postheat is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens.

# Pre/Postheat - Weld Graph Run Screen (Figure 6-11)

Weld schedule 004 is pre-programmed at the factory for Pre/Postheat operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

# Pre/Postheat - Alphanumeric Run Screen (Figure 6-12)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.



Figure 11. Pre/Postheat Weld Graph Screen



Figure 12. Pre/Postheat Alphanumeric Screen

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 6-6 990-057

#### UP/DOWNSLOPE (Figure 6-13)

Up/Downslope facilitates welding material combinations such as aluminum-to-aluminum or platinum-to-tungsten. Up Slope allows a reduction in electrode force, resulting in a cleaner appearance by reducing electrode indentation, material pickup and electrode deformation. Up Slope can also be used to displace plating and/or oxides, reduce flashing and spitting, or reduce thermal shock when welding parts containing glass-to-metal seals. Downslope assists in the grain refinement of certain heat-treatable steels and prevents cracking in aluminum and other materials by reducing the cooling rate.



Figure 13. Pre/Postheat Alphanumeric Screen

Up/Downslope can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.

When Up/Downslope is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Up/Downslope is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens.

# Up/Downslope - Weld Graph Run Screen (Figure 6-14)

Weld schedule 005 is pre-programmed at the factory for Up/Downslope operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.



Figure 14. Up/Downslope Weld Graph Screen

#### Up/Downslope - Alphanumeric Run Screen (Figure 6-15)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.

### BRAZE (Figure 6-16)

This function is ideal for brazing two parts together using a brazing alloy as a "sandwich" between the parts. The brazing alloy can be preformed for convenient handling or can be a tin or solder plating on both parts. To ensure complete solidification of the brazing alloy, use the Hold Period to cool the parts.

CAUTION - It is easy to exceed the duty cycle rating for the HF2 Weld Transformer using the Braze weld function. Refer to *Chapter 2, HF2 Weld Transformer Electrical Specifications*.



Figure 15. Up/Downslope Alphanumeric Run Screen





Braze can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.

When Braze is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Braze is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens.

# Braze - Weld Graph Run Screen (Figure 6-17)

Weld schedule 006 is pre-programmed at the factory for Braze operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

# Braze - Alphanumeric Run Screen (Figure 6-18)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.

#### **ROLLSPOT (Figure 6-19)**

Rollspot is a special form of seam welding. Typically, upper and lower wheel electrodes, in conjunction with an automatic parts feeder, are used to make a Rollspot weld. Because of the weld current shunting effect after the first weld, set the Weld2 Period weld current greater than Weld1 by a factor of 20% to 50%. Use the larger percentage for closer spacing. Assuming the rotational speed of the wheel is fixed, the Weld2 Period controls the length of the spot and the Cool Period controls the distance between spots.



#### Figure 6-17. Braze - Weld Graph Run Screen



#### Figure 6-18. Braze - Alphanumeric Run Screen



#### Figure 6-19. Rollspot.

**CAUTION:** It is easy to exceed the duty cycle rating for the HF2 Weld Transformer using the Rollspot weld function. Refer to *Chapter 2, HF2 Weld Transformer Electrical Specifications*.

Rollspot can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.

### **CHAPTER 6: ADVANCED WELD FUNCTIONS**

When Rollspot is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

Rollspot welding continues for as long as all switches remain closed. Hold has no meaning with Manually Actuated Weld Heads and does not appear on either the weld schedule Program or Run screens.

# Rollspot - Weld Graph Run Screen (Figure 6-20)

Weld schedule 007 is pre-programmed at the factory for Rollspot operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

# Rollspot - Alphanumeric Run Screen (Figure 6-21)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.

#### SEAM (Figure 6-22)

Seam can be used to make automated hermetic seam welds using automatic feeders, and PLC or host computer control. Seam can also be used to make manual or semi-automatic non-hermetic seam welds using an operator.

**CAUTION:** It is easy to exceed the duty cycle rating for the HF2 Weld Transformer using the Rollspot weld function. Refer to *Chapter 2, HF2 Weld Transformer Electrical Specifications.* 



Figure 6-20. Rollspot -Weld Graph Run Screen

SCHEDULE: 007	ROLLSPO	т		
SYSTEM: AIR	AUTO	(17-11)	WELD:0	000000
SQZ	WELD	1 COOL	WELD	2 RPT
TIME(ms):0000	0001	0001	0001	
CURRENT :	0.20		0.50	KA
AMP · SECONDS	LOWER	UPPER	SENTRY	:
	none	none	OFF	
▲▼ Select Schedule			R	UN





Figure 6-22. Seam

MODEL HF2 2 kHz HIGH FREQUENCY RESISTANCE WELDING POWER SUPPLY 6-10 990-057 Seam can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.

When Seam is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed. Weld Current flows as long as all switches remain closed. Hold Period has no meaning with Manually Actuated Weld Heads and does not appear on either the weld schedule Program or Run screens.

# Seam - Weld Graph Run Screen (Figure 6-23)

Weld schedule 008 is pre-programmed at the factory for Seam operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

# Seam - Alphanumeric Run Screen (Figure 6-24)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.



#### Figure 6-23. Seam Weld Graph Run Screen



Figure 6-24. Seam Alphanumeric Run Screen

### DUAL PULSE (Figure 6-25)

Dual Pulse combines the best features of Up/Downslope with Quench/Temper. Use Dual Pulse for best welding control of flat-to-flat, roundto-round, or round-to-flat small parts that may or may not be plated.

Adding Up Slope to the front of each weld period allows a reduction in electrode force, resulting in a cleaner appearance by reducing electrode indentation, material pickup and electrode deformation. Up Slope will also help to displace plating and/or oxides, reduce flashing and spitting, or reduce thermal shock when welding parts containing glass-to-metal seals.



Figure 6-25. Dual Pulse

In the normal application of Dual Pulse, the Weld1 Period provides sufficient heat to displace the plating or oxides, seat the electrodes against the base metals, and force the parts into intimate contact. The Cool Period allows time to dissipate the heat generated during the Weld1 Period.

The Weld2 Period completes the structural weld. The Weld2 Period weld current should be greater than the Weld1 Period weld current by a factor of 2 or 3 since the first bond significantly reduces the resistance of the interface between the parts. The only use for the Down Slope Period following the Weld2 Period is to control grain refinement in brittle parts by slowing reducing the Weld2 Period weld current to zero during the Down Slope Period.

Dual Pulse can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.

When Dual Pulse is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Dual Pulse is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens.

# Dual Pulse - Weld Graph Run Screen (Figure 6-26)

Weld schedule 009 is pre-programmed at the factory for Dual Pulse operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

#### Dual Pulse - Alphanumeric Run Screen (Figure 6-27)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner. Note: when programming the Dual Pulse weld function that uses an Air Actuated Weld Head, press [▶] to scroll the program screen to the right to access the Down and Hold periods.

### PULSATION (Figure 6-28)

Pulsation allows the HF2 Weld Control and largest HF2 Weld Transformer to be used for applications normally requiring more weld energy by pumping in more total weld heat through the use of many sequential weld pulses. The first Weld Period is followed by an alternating sequence of Cool and Weld Periods. The Pulsation number defines how many Cool/Weld Periods will follow the first Weld Period. Using the Pulsation can damage the crystal structure of the parts by making them more brittle.



#### Figure 6-26. Dual Pulse -Weld Graph Run Screen

SCHEDULE: 009 1	DUAL PULSE			
SYSTEM: AIR A	AUTO WELD:0000000			
SQZ	UP1 WELD1 COOL UP2 WELD2			
TIME (ms) :0000 (	0001 0001 0001 0001 0001			
CURRENT :	0.20 KA CURRENT: 0.50			
AMP•SECONDS 1	LOWER UPPER SENTRY:			
	none none OFF			
▲▼ Select Schedule ■ R U N ■				

Figure 6-27. Dual Pulse -Alphanumeric Run Screen



Figure 6-28. Pulsation

Pulsation can be used with Unitek Peco Force Fired Manual or Air Actuated Weld Heads. For Manually Actuated Weld Heads, weld current begins when the Force Firing Switch closes. For Force Fired Air

### **CHAPTER 6: ADVANCED WELD FUNCTIONS**

Actuated Weld Heads, weld current begins when both levels of a two-level Foot Switch are closed and the Force Firing Switch in the Air Actuated Weld Head closes.

When Pulsation is used with a Non-Force Fired Air Actuated Weld Head, the Squeeze (SQZ) Period must be used to allow sufficient time for the electrodes to close and apply the required weld force to the

parts before the Weld Period begins. Weld current begins when the Squeeze Period ends and both levels of a two-level Foot Switch are closed.

When Pulsation is used with any type of Air Actuated Weld Head, the Hold Period can be used to automatically keep the electrodes closed on the parts after weld current has terminated for the purpose of providing additional heat sinking or parts cooling. Squeeze and Hold Periods have no meaning with Manually Actuated Weld Heads and do not appear on either the weld schedule Program or Run screens.

# Pulsation - Weld Graph Run Screen (Figure 6-29)

Weld schedule 010 is pre-programmed at the factory for Pulsation operation. The HF2 Weld Control automatically recognizes the presence of a Manually or Air Actuated Weld Head before the first weld is made.

# Pulsation - Alphanumeric Run Screen (Figure 6-30)

To simultaneously view all pre-programmed time periods and energy settings, press [CHNG] to select the Alphanumeric Run screen. The 7 digit Weld Counter is displayed in the upper right corner.



# Figure 6-29. Pulsation Weld Graph Run Screen



Figure 6-30. Pulsation Alphanumeric Run Screen