Dry pump

SYMPTOM ORIGIN / DIAGNOSTIC REMEDY CONFIRMATION

Critical failure Chap. C

"Error/information indicator and display"

Contact customer service. No noise from the Problem on ACP 20/28 electrical module **ACP 20/28** NO **ACP 20/28 pump** Check the connections, overheating unplug and plug the cables on the electrical module. Check the cooling system. NO Mechanical jamming Contact customer service. ACP 20/28

ACP 20/28 pump has stopped during cycle

Power supply voltage is less than the minimum allowed, the pump turns into safe

Check the power supply voltage, stop the detector and restart the ACP 20/28 pump.