



Operator interface

SYMPTOM	ORIGIN / DIAGNOSTIC CONFIRMATION	REMEDY
*  Critical failure  Chap. C <i>"Error/information indicator and display"</i>		
" ! " or " i " appears at the end of line 1 on the LCD	Fault or information display activated	Press NEXT to display the clear message.*
Helium signal digital display flashing	Fault display activated (Or alternately displayed with helium signal)	Press NEXT to display the clear message.*
Password lost	Impossible to access to the CONFIGURATION menus	Contact customer service.
Timekeeper ram fail.	Supervisor board P0302 ram problem	Contact customer service.