

## Temperature

SYMPTOM	ORIGIN / DIAGNOSTIC CONFIRMATION	REMEDY
---------	-------------------------------------	--------

 **Minor fault**  **Chap. C**  
*"Error/information indicator and display"*

**Temperature too low**

**Temperature sensor**  
ambient temperature

Make sure the leak detector is used within ambient temperature tolerance.

 **A 80**

**Temperature too high**

**Temperature sensor**  
ambient temperature

Make sure the leak detector is used within ambient temperature tolerance.

 **A 80**