

## Maintenance operations introduction

### Safety recommendations



Standard precautions before any maintenance operations: disconnect supply and wait 5 minutes before working on this equipment.



Only authorized and enabled people can occur if the leak detector is switch on and covers opened.



The products are free of leaks when shipped from the factory, for normal operating conditions. The user is responsible for maintaining the level of tightness.

During disassembly and reassembly operations on vacuum lines, to avoid gettering due to dust or finger prints, you are advised to work:

- in a clean room,
- on lint free paper,
- with unpowdered vinyl gloves (clean room gloves),
- to dust each part with filtered dry air,
- to block all the openings in the vacuum lines.

## Maintenance operations introduction

### Icons used



2.5 mm Allen key



3.5 mm Allen key



3 mm Allen key



4 mm Allen key



5 mm Allen key



6 mm Allen key



12 mm stud



7 mm spanner



8 mm spanner



10 mm spanner



13 mm spanner



17 mm spanner



20 mm spanner



Philips head screwdriver



Screwdriver for slotted head screws



Voltmeter



Ohmmeter