

Preliminary remarks

Throughout this User's Manual, you could find this type of message "  **To access to level 4**  **C 40** ": it refers to a specific chapter of the User's Manual. Please read it for further information.

Introduction



■ The ASM 182 / 192 series.	A 10
■ ASM 182 TD+ detector operating principle	A 20
■ ASM 192 T2D+ detector operating principle	A 21
■ Analyzer cell operating principle	A 30
■ Testing methods	A 40
■ ASM 182 operator interface.	A 50
■ ASM 192 operator interface.	A 51
■ Options	A 60
■ Accessories	A 70
■ ASM 182 TD+ technical characteristics	A 80
■ ASM 192 T2D+ technical characteristics	A 81
■ Dimensions (mm, inch) ASM 182 TD+	A 90
■ Dimensions (mm, inch) ASM 192 T2D+	A 91

Installation



■ Precautions and unpacking	B 10
■ Controlling the detector with the I/O interface	B 20
■ Controlling the detector with a PC computer through the RS 232 interface	B 30
■ Connecting the detector directly to a printer through the RS 232 interface	B 40
■ ASM 182 TD+: Connecting the detector to the installation via the hardware interface	B 50
■ ASM 192 T2D+: Connecting the detector to the installation via the hardware interface	B 51
■ Before starting up the ASM 182 TD+	B 60
■ Before starting up the ASM 192 T2D+	B 61

General contents

ASM 182 TD+ - ASM 192 T2D+ User's Manual

Operation



■ Factory configuration of the leak detector parameters	C 10
■ Operating principle of the control panel	C 20
■ User interface level presentation	C 30
■ Access to level ④ - Password	C 40
■ Starting up / Switching off the leak detector	C 50
■ Basic operation of the leak detector	C 60
■ Advanced operation of the leak detector	C 61
■ Calibration of the leak detector	C 70
■ Basic internal auto-calibration of the leak detector	C 71
■ Advanced internal auto-calibration of the leak detector	C 72
■ External calibration of the leak detector	C 73
■ Correction factor	C 74
■ Calibrated leak values programming	C 75
■ Detector inlet: vent air or gas line	C 80
■ Bargraph zoom	C 90
■ Audio alarm	C 100
■ Cycle end	C 110
■ Zero function	C 120
■ Memo function	C 130
■ Helium pollution prevention	C 140
■ Digital voice	C 150
■ Date - Time - Language - Unit	C 160
■ Error/information indicator and display	C 170
■ Summary of screens	C 180
■ Remote control	C 190
■ Headphone and loudspeaker	C 200
■ Gas line option	C 210
■ 3 masses option	C 220

MANUAL REFERENCE: 109 229

EDITION: 04 - February 02

Software versions:

L115 v1.0 r.00 (ASM 182 TD+)

L116 v1.0 r.00 (ASM 192 T2D+)

General contents

ASM 182 TD+ - ASM 192 T2D+ User's Manual

Maintenance - Troubleshooting



■ Table of preventive maintenance intervals	■ D 10
■ Maintenance message	■ D 11
■ General troubleshooting guide	■ D 20
■ Power supply	■ D 30
■ Dry pump	■ D 40
■ Molecular pump (MDP 5011/5006 HDS)	■ D 50
■ Turbomolecular pump (ATP 100)	■ D 51
■ Turbomolecular pump (TMP 5154)	■ D 60
■ Analyzer cell	■ D 70
■ Inlet pressure (PI3C Pirani gauge)	■ D 80
■ Calibration	■ D 90
■ Helium measurement	■ D 100
■ Sniffing test mode	■ D 110
■ Operator interface	■ D 120
■ Temperature	■ D 130
■ Appearance of information messages	■ D 140

Maintenance sheets



■ Maintenance operations introduction	■ E 10
■ Access to internal detector components ASM 182 TD+	■ E 20
■ Access to internal detector components ASM 192 T2D+	■ E 21
■ Greasing the hybrid turbomolecular pump TMP 5154	■ E 30
■ Greasing the molecular drag pump MDP 5011/5006 HDS	■ E 40
■ Greasing the ATP 100 pump	■ E 45
■ Partial maintenance of the ACP 20/28 pump (ASM 182 TD+ leak detector)	■ E 50
■ Partial maintenance of the ACP 20/28 pump (ASM 192 T2D+ leak detector)	■ E 51
■ Basic maintenance of the analyzer cell	■ E 60
■ Replacement / Recalibration of the detector internal calibrated leak	■ E 70
■ LDS probe maintenance	■ E 80
■ Minisol and Bacosol valve installation and maintenance	■ E 85

MANUAL REFERENCE: 109 229

EDITION: 04 - February 02

Software versions:

L115 v1.0 r.00 (ASM 182 TD+)
L116 v1.0 r.00 (ASM 192 T2D+)

General contents

ASM 182 TD+ - ASM 192 T2D+ User's Manual

Components



■ Spare parts - Instructions of use	F 00
■ Repair kit	F 10
■ Standard tools	F 20
■ Specific tools	F 30
■ Monitoring and display (ASM 182 TD+)	F 40
■ Monitoring and display (ASM 192 T2D+)	F 41
■ Power and electrical supply	F 50
■ Automatic control system and electronic circuits (ASM 182 TD+)	F 60
■ Automatic control system and electronic circuits (ASM 192 T2D+)	F 61
■ Measurement (ASM 182 TD+)	F 70
■ Measurement (ASM 192 T2D+)	F 71
■ Pumping (ASM 182 TD+)	F 80
■ Pumping (ASM 192 T2D+)	F 81
■ Valves (ASM 182 TD+)	F 90
■ Valves (ASM 192 T2D+)	F 91
■ Pipes (ASM 182 TD+)	F 100
■ Pipes (ASM 192 T2D+)	F 101
■ Connections and seals (ASM 182 TD+)	F 110
■ Connections and seals (ASM 192 T2D+)	F 111
■ Cover (ASM 182 TD+)	F 120
■ Cover (ASM 192 T2D+)	F 121
■ Options and accessories	F 130
■ Components summary	F 140

Appendix



■ ASM 182 TD+ wiring diagrams	G 10
■ ASM 192 T2D+ wiring diagrams	G 11